

iEM3100 series / iEM3200 series

Energy meters User manual

DOCA0005EN-02
06/2013



The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2013 Schneider Electric. All rights reserved.

Safety information

Important information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **will** result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, **can** result in death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **can** result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury. The safety alert symbol shall not be used with this signal word.

Please note

Electrical equipment should be installed, operated, serviced and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Notices

FCC Part 15 notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

About the book

Document scope

This manual is intended for use by designers, system builders and maintenance technicians with an understanding of electrical distribution systems and monitoring devices.

Validity note

The energy meters are used to measure the amount of active energy consumed by an installation or a part of an installation.

This function meets the requirements for:

- consumption monitoring,
- evaluation of energy items (cost, accounting, etc.).

This function may also satisfy the power-saving incentives implemented by many countries.

Related documents

| Title of documentation | Reference number |
|--|---------------------|
| Instruction sheet: iEM3100 / iEM3110 / iEM3115 | S1B46581 / S1B62907 |
| Instruction sheet: iEM3150 / iEM3155 | S1B46583 / S1B62908 |
| Instruction sheet: iEM3200 / iEM3210 / iEM3215 | S1B46598 / S1B62910 |
| Instruction sheet: iEM3250 / iEM3255 | S1B46602 / S1B62911 |
| Installation sheet: iEM3135 | HRB68964 / HRB72100 |
| Installation sheet: iEM3165 | HRB68991 / HRB72106 |
| Installation sheet: iEM3175 | HRB68988 / HRB72103 |
| Installation sheet: iEM3235 | HRB68995 / HRB72108 |
| Installation sheet: iEM3265 | HRB69003 / HRB72111 |
| Installation sheet: iEM3275 | HRB68999 / HRB72109 |

You can download these technical publications and other technical information from www.schneider-electric.com.

Contents


| | | |
|------------------|---|-----------|
| Chapter 1 | Safety precautions | 9 |
| Chapter 2 | Overview | 11 |
| | Overview of meter functions | 11 |
| | Typical applications | 12 |
| | Physical description | 14 |
| Chapter 3 | Installation | 19 |
| | Dimensions | 19 |
| | DIN rail mounting and dismounting | 20 |
| | Input, output and communications wiring | 21 |
| | Power system wiring | 23 |
| Chapter 4 | Front panel display and meter setup | 29 |
| | Overview | 29 |
| | Data display | 29 |
| | Multi Tariff feature | 33 |
| | Meter status information | 33 |
| | The device clock | 33 |
| | Device configuration | 34 |
| | Modifying parameters | 36 |
| | Configuration mode menus | 37 |
| Chapter 5 | Communications via Modbus RS-485 | 51 |
| | Modbus communication overview | 51 |
| | Modbus functions | 52 |
| | Command interface | 53 |
| | Modbus register list | 57 |
| | Read Device Identification | 61 |
| Chapter 6 | Communications via LonWorks | 63 |
| | LonWorks communications overview | 63 |
| | LonWorks communication implementation | 63 |
| | Standard network variable types (SNVTs) and configuration properties for reading data | 64 |
| | Meter configuration properties | 68 |
| | Echelon LonMaker plug-in for data display and meter configuration | 71 |
| Chapter 7 | Communications via M-Bus | 75 |
| | M-Bus communications overview | 75 |
| | M-Bus protocol support | 76 |
| | M-Bus protocol implementation | 76 |
| | Variable data structure telegram information | 77 |


| | | |
|-------------------|---|------------|
| | Telegram information for data records | 79 |
| | Telegram information for meter configuration | 82 |
| | M-Bus tool for data display and meter configuration | 85 |
| Chapter 8 | Communications via BACnet | 89 |
| | BACnet communications overview | 89 |
| | BACnet protocol support | 90 |
| | BACnet communications implementation | 91 |
| | BACnet object and property information | 91 |
| Chapter 9 | Specifications | 97 |
| | Electrical characteristics | 97 |
| | Internal clock | 98 |
| | Measurement accuracy | 99 |
| | Environmental and mechanical characteristics | 99 |
| | Display and Energy pulsing LED characteristics | 99 |
| | Modbus communications | 99 |
| | LonWorks communications | 100 |
| | M-Bus communications | 100 |
| | BACnet communications | 100 |
| Chapter 10 | Troubleshooting | 101 |
| | Diagnostic codes | 101 |


Chapter 1 Safety precautions

Installation, wiring, testing and service must be performed in accordance with all local and national electrical codes.

Carefully read and follow the safety precautions outlined below.

| |
|---|
|  DANGER |
| HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH |
| <ul style="list-style-type: none">• Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. See NFPA 70E in the USA or applicable local standards.• This equipment must only be installed and serviced by qualified electrical personnel.• Turn off all power supplying this device and the equipment in which it is installed before working on the device or equipment.• Always use a properly rated voltage sensing device to confirm power is off.• Before performing visual inspections, tests, or maintenance on this equipment, disconnect all sources of electric power. Assume that all circuits are live until they have been completely de-energized, tested and tagged. Pay particular attention to the design of the power system. Consider all power supply sources, particularly the potential for backfeed.• Replace all devices, doors and covers before turning on power to this equipment. |
| Failure to follow these instructions will result in death or serious injury. |

| |
|--|
|  WARNING |
| UNINTENDED OPERATION |
| Do not use the meter for critical control or protection applications where human or equipment safety relies on the operation of the control circuit. |
| Failure to follow these instructions can result in death, serious injury or equipment damage. |

| |
|---|
|  WARNING |
| INACCURATE DATA RESULTS |
| <ul style="list-style-type: none">• Do not rely solely on data displayed on the front panel or in software to determine if the device is functioning correctly or compliant with all applicable standards.• Do not use data displayed on the front panel or in software as a substitute for proper workplace practices or equipment maintenance. |
| Failure to follow these instructions can result in death, serious injury or equipment damage. |

Chapter 2 Overview

What is in this chapter?

This chapter contains the following topics:

- Overview of meter functions** **11**
 - Main characteristics 11
- Typical applications** **12**
 - iEM31•• series 12
 - iEM32•• series 12
 - Typical applications 13
- Physical description** **14**
 - All meters: Meter sealing points 14
 - iEM3100 / iEM3110 / iEM3115 - Direct measurement up to 63 A 14
 - iEM3135 - Direct measurement up to 63 A and M-Bus communications 15
 - iEM3150 / iEM3155 / iEM3165- Direct measurement up to 63 A and Modbus or BACnet communications 15
 - iEM3175 - Direct measurement up to 63 A and LonWorks communications 16
 - iEM3200 / iEM3210 / iEM3215 - Measurement with CTs 16
 - iEM3235 - Measurement with CTs and M-Bus communications 17
 - iEM3250 / iEM3255 / iEM3265 - Measurement with CTs and Modbus or BACnet communications 17
 - iEM3275 - Measurement with CTs and LonWorks communications 18

Overview of meter functions

The energy meters provide the essential measurement capabilities (for example, current, voltage, and energy) required to monitor a 1- or 3-phase electrical installation.

The key features of the energy meters are:

- measurement of active and reactive energy,
- Multi Tariffs (up to 4) controlled by internal clock, digital inputs or communication,
- MID compliance (when installed in an IP51 or higher enclosure) for many of the energy meters,
- pulse outputs,
- display (currents, voltage, energies),
- communications via Modbus, LonWorks, M-Bus or BACnet protocols.

Main characteristics

| Function | iEM3100 | iEM3110 | iEM3115 | iEM3135 | iEM3150 | iEM3155 | iEM3165 | iEM3175 | iEM3200 | iEM3210 | iEM3215 | iEM3235 | iEM3250 | iEM3255 | iEM3265 | iEM3275 |
|--|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| Direct measurement (up to 63 A) | √ | √ | √ | √ | √ | √ | √ | √ | - | - | - | - | - | - | - | - |
| Measurement inputs through CTs (1 A, 5 A) | - | - | - | - | - | - | - | - | √ | √ | √ | √ | √ | √ | √ | √ |
| Measurement inputs through VTs | - | - | - | - | - | - | - | - | - | - | - | √ | √ | √ | √ | √ |
| Active Energy measurement accuracy class (total and partial kWh) | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 0.5S | 0.5S | 0.5S | 0.5S | 0.5S | 0.5S | 0.5S | 0.5S |
| Four Quadrant Energy measurements | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Electrical measurements (I, V, P, ...) | - | - | - | √ | √ | √ | √ | √ | - | - | - | √ | √ | √ | √ | √ |

| Function | | iEM3100 | iEM3110 | iEM3115 | iEM3135 | iEM3150 | iEM3155 | iEM3165 | iEM3175 | iEM3200 | iEM3210 | iEM3215 | iEM3235 | iEM3250 | iEM3255 | iEM3265 | iEM3275 |
|---|--|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| Multi Tariff | Controlled by internal clock | - | - | 4 | 4 | - | 4 | 4 | 4 | - | - | 4 | 4 | - | 4 | 4 | 4 |
| | Controlled by digital input(s) | - | - | 4 | 2 | - | 2 | 2 | 2 | - | - | 4 | 2 | - | 2 | 2 | 2 |
| | Controlled by communications | - | - | - | 4 | - | 4 | 4 | 4 | - | - | - | 4 | - | 4 | 4 | 4 |
| Measurement display (number of lines) | | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Digital inputs | Programmable (status, tariff control, or input monitoring) | - | - | - | 1 | - | 1 | 1 | 1 | - | - | - | 1 | - | 1 | 1 | 1 |
| | Tariff control only | - | - | 2 | - | - | - | - | - | - | - | 2 | - | - | - | - | - |
| Digital outputs | Programmable (energy pulsing or overload alarm) | - | - | - | 1 | - | 1 | 1 | - | - | - | - | 1 | - | 1 | 1 | - |
| | Pulse output only | - | 1 | - | - | - | - | - | - | - | 1 | - | - | - | - | - | - |
| Overload alarm | | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Communications | Modbus | - | - | - | - | √ | √ | - | - | - | - | - | - | √ | √ | - | - |
| | LonWorks | - | - | - | - | - | - | - | √ | - | - | - | - | - | - | - | √ |
| | M-Bus | - | - | - | √ | - | - | - | - | - | - | - | √ | - | - | - | - |
| | BACnet | - | - | - | - | - | - | √ | - | - | - | - | - | - | - | √ | - |
| MID compliant (when installed in an IP51 or higher enclosure) | | - | √ | √ | √ | - | √ | √ | √ | - | √ | √ | √ | - | √ | √ | √ |
| Width (18 mm module in DIN rail mounting) | | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 |

Typical applications

iEM31•• series

This range is a cost effective solution to monitor more feeders. These meters can monitor energy consumption by usage, by zone or by feeder in the cabinet. They can be used to monitor feeders in a main switchboard or to monitor the main in a distribution cabinet.

| Functions | Advantages |
|--|---|
| Can directly measure feeders up to 63 A Embedded current transformers (CTs) | Saves installation time and space in the cabinet No wiring to manage Clear distribution network |
| Adapted to be installed with Acti9 iC65 circuit breakers | Can be used in three-phase systems with or without neutral |
| Can be used for single-phase multi-circuit monitoring | 3 single feeders can be monitored with a single meter |

iEM32•• series

These meters cover a large range of applications.

| Functions | Advantages |
|------------------------|--|
| CT and VT connection | Can be used in low or medium voltage applications |
| Flexible configuration | Can be adapted to any distribution network with or without neutral |

Typical applications


The following table presents some of the functions of the different meters, the advantages and main applications.

| Functions | Advantages | Applications | Energy meter |
|---|---|--|--|
| Total and partial energy counters | Energy usage monitoring | Sub-billing management Metering applications | All |
| Internal clock | Saves the date and time of last reset | Provides the timestamp of the last reset of the partial energy accumulation | All (except iEM3100 and iEM3200) |
| Pulse output with a configurable pulse weight of up to 1 pulse per 1 Wh | Collect pulses from the meter with a Smartlink system, PLC or any basic acquisition system | Remote monitoring of energy consumption Integrate the meter in to a system monitoring of a large number of devices | iEM3110 / iEM3210 |
| Manages up to four tariffs, controlled by the digital input(s), internal clock or communications (depending on meter model) | Categorize energy consumption into On Peak and Off Peak, working days and weekends, or by different electricity sources (for example, from the utility and an electrical generator) | Energy demand management Sub-billing management Identification of local energy consumption behavior by zone, by usage or by feeder | iEM3115 / iEM3135 / iEM3155 / iEM3165 / iEM3175 iEM3215 / iEM3235 / iEM3255 / iEM3265 / iEM3275 |
| Measures essential electrical parameters like current, average voltage and total power. | Instantaneous measurements help you monitor the imbalance between phases. Total power allows you to monitor the feeder load level. | Monitoring of feeders or any sub-cabinet | iEM3135 / iEM3155 / iEM3165 / iEM3175 iEM3235 / iEM3255 / iEM3265 / iEM3275 |
| M-Bus communications | Communicate advanced parameters using M-Bus protocol | M-Bus network integration | iEM3135 / iEM3235 |
| Modbus communications | Communicate advanced parameters using Modbus protocol | Modbus network integration | iEM3150 / iEM3155 iEM3250 / iEM3255 |
| BACnet communications | Communicate advanced parameters using BACnet MS/TP protocol | BACnet network integration | iEM3165 / iEM3265 |
| LonWorks communications | Communicate advanced parameters using LonWorks communications | LonWorks network integration | iEM3175 / iEM3275 |
| Four quadrant calculation | Identification of imported and exported active and reactive energy allows you to monitor energy flow in both directions: delivered from the utility and produced on-site | Ideal for facilities with back-up generators or green power capabilities (for example, solar panels or wind turbines) | |
| Measurement of active, reactive and apparent energy. | Allows you to monitor energy consumption and production | Manage energy consumption and make informed investment to reduce your energy bill or penalties (for example, installing capacitor banks) | iEM3135 / iEM3155 / iEM3165 / iEM3175 iEM3235 / iEM3255 / iEM3265 / iEM3275 |
| Programmable digital input | Can be programmed to: <ul style="list-style-type: none"> Count pulses from other meters (gas, water, etc.) Monitor an external status Reset the partial energy accumulation and start a new period of accumulation | This allows for monitoring of: <ul style="list-style-type: none"> WAGES Intrusion (for example, doors opening) or equipment status Energy usage | |
| Programmable digital output | Can be programmed to: <ul style="list-style-type: none"> be an active energy (kWh) pulse output, with a configurable pulse weight Alarm on a power overload at a configurable pickup setpoint | This allows you to: <ul style="list-style-type: none"> Collect pulses from the meter with a Smartlink system, PLC or any basic acquisition system Monitor power levels at a detailed level and to help detect an overload before the circuit breaker trips | iEM3135 / iEM3155 / iEM3165 iEM3235 / iEM3255 / iEM3265 |

Physical description


All meters: Meter sealing points

All energy meters have sealing covers and sealing points to help prevent access to inputs and outputs and current and voltage connections.




iEM3100 / iEM3110 / iEM3115 - Direct measurement up to 63 A

The various features of the iEM3100 / iEM3110 / iEM3115 are shown in the diagram below:




iEM3135 - Direct measurement up to 63 A and M-Bus communications

The various features of the iEM3135 are shown in the diagram below:




iEM3150 / iEM3155 / iEM3165- Direct measurement up to 63 A and Modbus or BACnet communications

The various features of the iEM3150 / iEM3155 / iEM3165 are shown in the diagram below:




iEM3175 - Direct measurement up to 63 A and LonWorks communications

The various features of the iEM3175 are shown in the diagram below:




iEM3200 / iEM3210 / iEM3215 - Measurement with CTs

The various features of the listed energy meters (CTs 1 A or 5 A) are shown in the diagram below:




iEM3235 - Measurement with CTs and M-Bus communications

The various features of the iEM3235 (CTs 1 A or 5 A with M-Bus communications) are shown in the diagram below:




iEM3250 / iEM3255 / iEM3265 - Measurement with CTs and Modbus or BACnet communications

The various features of the iEM3150 / iEM3250 / iEM3265 (CTs 1 A or 5 A with Modbus or BACnet communication) are shown in the diagram below:



iEM3275 - Measurement with CTs and LonWorks communications

The various features of the iEM3275 (CTs 1 A or 5 A with LonWorks communications) are shown in the diagram below:



Chapter 3 Installation


What is in this chapter?

This chapter contains the following topics:


- Dimensions** 19
- DIN rail mounting and dismounting** 20
 - Mounting the meter on a DIN rail 20
 - Dismounting the meter from a DIN rail 20
- Input, output and communications wiring** 21
 - iEM3100 / iEM3110 / iEM3115 / iEM3200 / iEM3210 / iEM3215 21
 - iEM3150 / iEM3155 / iEM3250 / iEM3255 22
 - iEM3135 / iEM3235 22
 - iEM3165 / iEM3265 22
 - iEM3175 / iEM3275 22
- Power system wiring** 23
 - 63 A direct measurement meter wiring 24
 - 5 A / 1 A meter wiring 25

Dimensions

iEM3100 / iEM3110 / iEM3115 / iEM3200 / iEM3210 / iEM3215



iEM3135 / iEM3150 / iEM3155 / iEM3165 / iEM3175 / iEM3235 / iEM3250 / iEM3255 / iEM3265 / iEM3275



DIN rail mounting and dismounting

⚠ DANGER


HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. See NFPA 70E in the USA or applicable local standards.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Turn off all power supplying this device and the equipment in which it is installed before working on the device or equipment.
- Always use a properly rated voltage sensing device to confirm power is off.
- Replace all devices, doors and covers before turning on power to this equipment.
- Do not exceed the device's ratings for maximum limits.


Failure to follow these instructions will result in death or serious injury.

Mounting the meter on a DIN rail

1. Position the 2 upper slots on the rear of the energy meter onto the DIN rail.




2. Press the meter against the DIN rail until the locking mechanism engages. The meter is now attached to the rail. Make sure that the device is not tilted following installation.




Dismounting the meter from a DIN rail

1. Use a flat-tip screwdriver (≤ 6.5 mm / 0.25 in) to lower the locking mechanism and release the meter.



- Lift the meter out and up to free it from the DIN rail.



Input, output and communications wiring

This section describes the wiring of the digital inputs, digital and pulse outputs and the communications (as applicable).

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH


- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. See NFPA 70E in the USA or applicable local standards.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Turn off all power supplying this device and the equipment in which it is installed before working on the device or equipment.
- Always use a properly rated voltage sensing device to confirm power is off.
- Replace all devices, doors and covers before turning on power to this equipment.
- Do not exceed the device’s ratings for maximum limits.

Failure to follow these instructions will result in death or serious injury.

Related topics


- See “Power system wiring” on page 23 for information on wiring the voltage and current connections.

iEM3100 / iEM3110 / iEM3115 / iEM3200 / iEM3210 / iEM3215




- The pulse output is compatible with S0 format.
- The pulse output on the iEM3110 / iEM3210 can be directly connected to a 24 V DC (< 30 V DC) input on a Zelio or Twido PLC.
- The pulse output on the iEM3210 indicates the primary consumption with consideration of transformer ratios.
- For other concentrators, if $V\ DC/Rin > 15\ mA$, add a resistor $Radd = (V\ DC/0.01) - Rin\ \Omega$

iEM3150 / iEM3155 / iEM3250 / iEM3255




- The programmable digital output is compatible with S0 format when configured as a pulse output.
- The digital output of the iEM3155 / iEM3255 is polarity-independent.
- The digital input and output are electrically independent.

iEM3135 / iEM3235




- The programmable digital output is compatible with S0 format when configured as a pulse output.
- The digital output of the iEM3135 / iEM3235 is polarity-independent.
- The digital input and output are electrically independent.
- The M-Bus communications connection is polarity-independent.

iEM3165 / iEM3265



- The programmable digital output is compatible with S0 format when configured as a pulse output.
- The digital output of the iEM3165 / iEM3265 is polarity-independent.
- The digital input and output are electrically independent.

iEM3175 / iEM3275



Power system wiring

The diagrams below illustrate how to connect the meters to a single-phase or three-phase 3-wire or 4-wire power system.

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. See NFPA 70E in the USA or applicable local standards.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Turn off all power supplying this device and the equipment in which it is installed before working on the device or equipment.
- Always use a properly rated voltage sensing device to confirm power is off.
- Replace all devices, doors and covers before turning on power to this equipment.
- Do not exceed the device’s ratings for maximum limits.

Failure to follow these instructions will result in death or serious injury.

Voltage input protection

The meter’s voltage inputs must be wired to fuses/breakers and a disconnect switch. If using a voltage transformer (VT), both primary and secondary sides of the VT must be fused and switched.

- Clearly label the device’s disconnect circuit mechanism and install it within easy reach of the operator.
- Fuses and circuit breakers must be rated for the installation voltage and sized for the available fault current.
- Fuse for neutral is required if the source neutral connection is not grounded.

Current input protection for 1 A and 5 A meters


For all connected current inputs on 1 A and 5 A meters with external CTs, use a CT shorting block to short-circuit the secondary leads of the CTs before removing the current input connections to the meter.

NOTE: Ground any unused current inputs on 1 A and 5 A meters.

iEM31•• devices associated with a contactor

Connection requirements for iEM3100 / iEM3110 / iEM3115 / iEM3135 / iEM3150 / iEM3155 / iEM3165 / iEM3175:

- When the energy meter is associated with a contactor, connect the energy meter upstream of the contactor.
- The energy meter must be protected by a circuit breaker.



Related topics

- See “Input, output and communications wiring” on page 21 for information on wiring the digital inputs, digital or pulse outputs and communications for your device.

63 A direct measurement meter wiring

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Do not allow the total additive current flowing through the device to exceed 63 A.

Failure to follow these instructions will result in death or serious injury.

| Power system | Energy meters | Wiring |
|--------------|--|--------|
| 1PH2W L-N | iEM3100 iEM3150 iEM3110 iEM3155 iEM3115 iEM3165 iEM3135 iEM3175 | |
| 1PH2W L-L | iEM3100 iEM3150 iEM3110 iEM3155 iEM3115 iEM3165 iEM3135 iEM3175 | |
| 1PH3W L-L-N | iEM3100 iEM3150 iEM3110 iEM3155 iEM3115 iEM3165 iEM3135 iEM3175 | |
| 3PH3W | iEM3100 iEM3150 iEM3110 iEM3155 iEM3115 iEM3165 iEM3135 iEM3175 | |
| 3PH4W | iEM3100 iEM3150 iEM3110 iEM3155 iEM3115 iEM3165 iEM3135 iEM3175 | |

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Do not connect N' to the load when setting the wiring type on the meter to 1PH4W Multi L-N.

Failure to follow these instructions will result in death or serious injury.

| Power system | Energy meters | Wiring |
|---|---|--------|
| 1PH multiple loads with neutral (1PH4W Multi L-N) | iEM3135 iEM3150 iEM3155 iEM3165 iEM3175 | |

5 A / 1 A meter wiring

⚠ **DANGER**

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Never short the secondary of a voltage transformer (VT).
- Never open circuit a current transformer (CT); use the shorting block to short circuit the leads of the CT before removing the connection from the meter.

Failure to follow these instructions will result in death or serious injury.

Single-phase systems with CTs

- A** 250 mA fuses / disconnect switch
- B** Shorting block

| Power system | Energy meter | Wiring | |
|-----------------|--|--------|--|
| 1PH2W L-N | iEM3200 iEM3210 iEM3215 iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | | |
| 1PH2W L-L | iEM3200 iEM3210 iEM3215 iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | | |
| 1PH3W L-L-N | iEM3200 iEM3210 iEM3215 iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | | |
| 1PH4W multi L-N | iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | 2CTs | |
| | | 3CTs | |

Three-phase systems with CTs

- A** 250 mA fuses / disconnect switch
- B** Shorting block
- C** VT primary fuses and disconnect switch
- ♦ indicates wiring for a balanced system

| Power system | Energy meter | Wiring | | |
|--------------|--|------------|------------|------------|
| 3PH3W | iEM3200 iEM3210 iEM3215 iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | 1 CT ♦ | 2CTs | 3CTs |
| | | | | |
| | | ≤480 V L-L | ≤480 V L-L | ≤480 V L-L |
| 3PH4W | iEM3200 iEM3210 iEM3215 iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | 1 CT ♦ | 2 CTs ♦ | 3CTs |
| | | | | |
| | | ≤277 V L-N | ≤277 V L-N | ≤277 V L-N |

Three-phase systems with CTs and VTs

- A** 250 mA fuses / disconnect switch
- B** Shorting block
- C** VT primary fuses and disconnect switch
- ♦ indicates wiring for a balanced system

| Power system | Energy meter | Wiring | | |
|--------------|---|----------------|----------------|----------------|
| 3PH3W | iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | 2 VTs, 1 CT ♦ | 2 VTs, 2 CTs | 2 VTs, 3 CTs |
| | | | | |
| | | L1 L2 L3 | L1 L2 L3 | L1 L2 L3 |

| Power system | Energy meter | Wiring | | |
|--------------|---|----------------|----------------|--------------|
| 3PH4W | iEM3235 iEM3250 iEM3255 iEM3265 iEM3275 | 3 VTs, 1 CTs ◆ | 3 VTs, 2 CTs ◆ | 3 VTs, 3 CTs |
| | | | | |

Chapter 4 Front panel display and meter setup

What is in this chapter?

This chapter contains the following topics:

- Overview** 29
- Data display** 29
 - Available information 30
 - Data display screens 30
- Multi Tariff feature** 33
- Meter status information** 33
- The device clock** 33
 - Date/time format 34
 - Setting the clock initially 34
- Device configuration** 34
 - Available settings 34
 - Entering configuration mode 35
 - The front panel display in configuration mode 35
 - Com. Protection setting 35
- Modifying parameters** 36
 - Selecting a value from a list 36
 - Modifying a numerical value 36
 - Cancelling an entry 37
- Configuration mode menus** 37

Overview

The energy meter features a human machine interface (HMI) with signaling LEDs, a graphical display, and menu buttons that allow you to access the information required to operate the energy meter and modify parameter settings.

The HMI also allows you to display, configure and reset parameters.

Some energy meters have the Multi Tariff feature, which allows you to configure different tariffs.

Data display

| | |
|----------|--|
| A | Measurement |
| B | Ea / Er = active / reactive energy |
| C | Value |
| D | Active tariff (if applicable) |
| E | Scroll through the available screens |
| F | View more screens related to the measurement category (if available) |
| G | Go back to previous screen |
| H | Date and time (if applicable) |
| I | Unit |

Available information


The following information is available in display mode:

| Measurement/ Information | iEM3100 | iEM3110 | iEM3115 | iEM3135 | iEM3150 | iEM3155 | iEM3165 | iEM3175 | iEM3200 | iEM3210 | iEM3215 | iEM3235 | iEM3250 | iEM3255 | iEM3265 | iEM3275 |
|--|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| Total Active Energy Import | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |
| Total Active Energy Export | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Total Reactive Energy Import | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Total Reactive Energy Export | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Partial Active Energy Import | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |
| Partial Reactive Energy Import | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Active Energy Import per Tariffs (T1 - T4) | - | - | √ | √ | - | √ | √ | √ | - | - | √ | √ | - | √ | √ | √ |
| Average voltage | - | - | - | √ | √ | √ | √ | √ | - | - | - | √ | √ | √ | √ | √ |
| Current per phase | - | - | - | √ | √ | √ | √ | √ | - | - | - | √ | √ | √ | √ | √ |
| Active Power (kW) | - | - | - | √ | √ | √ | √ | √ | - | - | - | √ | √ | √ | √ | √ |
| Reactive Power (kVAR) | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Apparent Power (kVA) | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Power Factor | - | - | - | √ | √ | √ | √ | √ | - | - | - | √ | √ | √ | √ | √ |
| Frequency | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Operation Time | - | - | - | √ | - | √ | √ | √ | - | - | - | √ | - | √ | √ | √ |
| Diagnostics Code | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |

Data display screens

The following sections outline the data display screens available on the various meter models.


iEM3100 / iEM3110 / iEM3115 / iEM3200 / iEM3210 / iEM3215



Related topics

- See "Troubleshooting" on page 101 for a list of diagnostic codes.


iEM3150 / iEM3250



Related topics

- See “Troubleshooting” on page 101 for a list of diagnostic codes.

iEM3135 / iEM3155 / iEM3165 / iEM3175 / iEM3235 / iEM3255 / iEM3265 / iEM3275




Related topics

- See "Troubleshooting" on page 101 for a list of diagnostic codes.

Multi Tariff feature

The Multi Tariff feature is available on the following devices: iEM3115, iEM3135, iEM3155, iEM3165, iEM3175, iEM3215, iEM3235, iEM3255, iEM3265 and iEM3275.

The following table illustrates how the tariffs operate according to the tariff selection (2, 3 or 4 tariffs). These tariffs are stored in 4 different registers: T1, T2, T3 and T4.

















NOTE: T3 start = T1 start, T4 start = T2 start

Meter status information

Two LEDs on the front panel indicate the current status of the device: the green status LED and the yellow energy pulsing LED.

The icons in the table below indicate the LED state as follows:

-  = LED is off
-  = LED is on
-  = LED is flashing

| Status LED | Energy pulsing LED (500 or 5000 flashes / kWh, depending on the device) | Description |
|---|--|-------------------------------|
|  |  | Off |
|  |  1s >  | On, no pulse counting |
|  |  | On, with pulse counting |
|  |  | Error, pulse counting stopped |
|  |  | Abnormal, with pulse counting |

Related topics

See the section for the protocol of your device for information on the communication LED:

- “Communications LED indicator for Modbus devices” on page 52
- “LED indicators for LonWorks meters” on page 64
- “Communications LED indicator for M-Bus meters” on page 77
- “Communications LED indicator for BACnet meters” on page 91

The device clock

This section does not apply to the iEM3100 or iEM3200.

You must reset the time to account for any time change (for example, to switch the time from standard time to daylight savings time).

Clock behavior on power interruption

iEM3110, iEM3150, iEM3210, iEM3250: When power is interrupted, the date and time are reset. When power is restored, the device automatically displays the screen to set **Date and Time**.

iEM3115, iEM3135, iEM3155, iEM3165, iEM3175, iEM3215, iEM3235, iEM3255, iEM3265, iEM3275: When the power is interrupted, the device retains its date and time information for 3 days. If power is interrupted for longer than 3 days, the device automatically displays the screen to set **Date and Time** when power is restored.


Date/time format

The date is displayed in the following format: DD-MMM-YYYY.

The time is displayed using the 24-hour clock in the following format: hh:mm:ss.

Setting the clock initially

The following diagram illustrates how to set the clock when you initially power up the device or after a power failure. To set the clock during normal operation, see the section on device configuration.



NOTE: Password entry only applies to meters that support a password.

Related topics

- See “Device configuration” on page 34 for information on setting the clock during normal device operation.

Device configuration

Available settings

The following configuration menus are available in configuration mode:


| Function | iEM3100 | iEM3110 | iEM3115 | iEM3135 | iEM3150 | iEM3155 | iEM3165 | iEM3175 | iEM3200 | iEM3210 | iEM3215 | iEM3235 | iEM3250 | iEM3255 | iEM3265 | iEM3275 |
|-----------------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| Wiring | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |
| CT Ratio | - | - | - | - | - | - | - | - | √ | √ | √ | √ | √ | √ | √ | √ |
| CT & VT Ratio | - | - | - | - | - | - | - | - | - | - | √ | √ | √ | √ | √ | √ |
| Frequency | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |
| Date | - | √ | √ | √ | √ | √ | √ | √ | - | √ | √ | √ | √ | √ | √ | √ |
| Time | - | √ | √ | √ | √ | √ | √ | √ | - | √ | √ | √ | √ | √ | √ | √ |
| Multi Tariffs | - | - | √ | √ | - | √ | √ | √ | - | - | √ | √ | - | √ | √ | √ |
| Overload Alarm | - | - | - | √ | - | √ | √ | √ | - | - | √ | √ | - | √ | √ | √ |
| Digital Output | - | - | - | √ | - | √ | √ | - | - | - | √ | √ | - | √ | √ | - |
| Digital Input | - | - | - | √ | - | √ | √ | √ | - | - | √ | √ | - | √ | √ | √ |
| Pulse Output | - | √ | - | - | - | - | - | - | - | √ | - | - | - | - | - | - |
| Communication | - | - | - | √ | √ | √ | √ | - | - | - | √ | √ | √ | √ | √ | √ |
| Com. Protection | - | - | - | √ | - | √ | √ | √ | - | - | √ | √ | - | √ | √ | √ |
| Contrast | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |
| Password | - | √ | √ | √ | - | √ | √ | √ | - | √ | √ | √ | - | √ | √ | √ |
| Reset Config | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ | √ |

The default factory settings are listed in the following table:

| Menu | Factory settings |
|----------------|---|
| Wiring | iEM31••: 3PH4W iEM32••: 3PH4W; 3 CTs on I1, I2, and I3; Direct-No VT |
| CT Ratio | CT Secondary = 5 A; CT Primary = 5 A |
| CT & VT Ratio | CT Secondary = 5 A; CT Primary = 5 A VT Secondary = 100 V; VT Primary = 100 V (by communication) VT Secondary and Primary are not available on HMI. |
| Frequency | 50 Hz |
| Date | 1-Jan-2000 |
| Time | 00:00:00 |
| Multi Tariffs | Disable |
| Overload Alarm | Disable |
| Digital Output | Disable |
| Digital Input | Input Status |
| Pulse Output | 100 imp / kWh |
| Communication | Varies depending on protocol |
| Contrast | 5 |
| Password | 0010 |

Entering configuration mode

To enter the configuration mode, press and hold **OK** and **ESC** at the same time for about 2 seconds. Enter the meter password, if prompted.



The front panel display in configuration mode

The diagram below illustrates the various elements of the display in configuration mode:

| | | |
|--|----------|---|
| | A | Parameter |
| | B | Setting |
| | C | Configuration mode icon |
| | D | Indicates that the setting impacts the Multi Tariff feature |

Related topics

- See “Modifying parameters” on page 36 for instructions on using the front panel buttons to configure list and numeric value settings.
- See “Configuration mode menus” on page 37 for a diagram of your device’s configuration screens.

Com. Protection setting

For meters with communications capabilities, you can enable or disable the Com. Protection setting. If this setting is enabled, you can only configure energy-related settings (for example, wiring or frequency, etc.) using the front panel, not using communications.

Modifying parameters

There are two methods for modifying a parameter, depending on the type of parameter:

- selecting a value in a list (for example, selecting 1PH2W L-N from a list of available power systems), or
- modifying a numerical value, digit by digit (for example, entering a value for the date, time or VT primary).

NOTE: Before you modify any parameters, ensure that you are familiar with the HMI functionality and navigation structure of your device in configuration mode.

Related topics


- See “Configuration mode menus” on page 37 for information on navigating the configuration menus on your device.

Selecting a value from a list

1. Use the down button to scroll through the parameter values until you reach the desired value.
2. Press **OK** to confirm the new parameter value.

Example

To set the nominal frequency of the meter:



- Enter configuration mode and press the down button until you reach Frequency then press **OK** to access the frequency configuration.
- Press the down button to select the frequency you want then click **OK**. Press **OK** again to save your changes.

Modifying a numerical value

When you modify a numerical value, the digit on the far right side is selected by default (except for Date/Time).

The parameters listed below are the only ones for which you set a numerical value (if the parameter is available on your device):

- Date
- Time
- Pick Up Value for an overload alarm
- Voltage Transformer (VT) Primary
- Current Transformer (CT) Primary
- Password
- Address of the energy meter


To modify a numerical value:

1. Use the down button to modify the selected digit.
2. Press **OK** to shift to next digit. Modify the next digit, if needed, or press okay to move to the next digit. Continue to move through the digits until you reach the last digit then press **OK** again to confirm the new parameter value.

If you enter an invalid setting for the parameter, when you press **OK** after setting the left-most number, the cursor shifts back to the right-most number so you can enter a valid value.

Example

To set the password:



- Enter configuration mode and press the down button until you reach Password then press **OK** to access the password configuration.
- Press the down button to increment the selected digit or press **OK** to move to the next digit to the left. When you reach the left-most digit, press **OK** to move to the next screen. Press **OK** again to save your changes.

Cancelling an entry

To cancel the current entry, press the **ESC** button . The change is cancelled and the screen reverts to the previous display.

Configuration mode menus

The diagrams below show the configuration navigation for each device.

Related topics

- See “Modifying parameters” on page 36 for instructions on how to change settings.

Configuration menu for iEM3100 / iEM3110 / iEM3115

| | | |
|---------------------------------|--|---|
| Wiring | | |
| Type | | 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 3PH3W |
| Frequency | | |
| Frequency | | 50 60 |
| Date (iEM3110 / iEM3115) | | |
| Date | | DD-MMM-YYYY |
| Time (iEM3110 / iEM3115) | | |
| Time | | hh:mm |
| Pulse output (iEM3110) | | |
| Pulse Constant (imp/kWh) | | 100 200 1000 1 10 20 |
| Pulse Width (ms) | | 50 100 200 300 |

| | | | | | | |
|---|-------------------|-----------------------|--------------|--------------|-------|----------|
| Multi Tariffs (iEM3115) | | | | | | |
| Control mode | Disable | | | | | |
| | by Digital Input | | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm | |
| | | | | T2 start | hh:mm | |
| | | | by 3 tariffs | T1 start | hh:mm | |
| | | | | T2 start | hh:mm | |
| | | | by 4 tariffs | T1(T3) start | hh:mm | |
| T2(T4) start | | | | hh:mm | | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | | |
| Contrast | | | | | | |
| Contrast | | | | | | 1 - 9 |
| Password (iEM3110 / iEM3115) | | | | | | |
| Password | | | | | | 0 - 9999 |
| Reset Config | | | | | | |
| Reset Config | | | | | | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | | | | | |

Configuration menu for iEM3135

| | | | | | | |
|---|-------------------|-----------------------|--------------|----------|-------------|--|
| Wiring | | | | | | |
| Type | | | | | | 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 3PH3W 1PH4W Multi L-N |
| Frequency | | | | | | |
| Frequency | | | | | | 50 60 |
| Date | | | | | | |
| Date | | | | | | DD-MMM-YYYY |
| Time | | | | | | |
| Time | | | | | | hh:mm |
| Multi Tariffs | | | | | | |
| Control mode | Disable | | | | | |
| | by Communications | | | | | |
| | by Digital Input | | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm | |
| | | | | T2 start | hh:mm | |
| | | | by 3 tariffs | T1 start | hh:mm | |
| | | | | T2 start | hh:mm | |
| by 4 tariffs | | | T1(T3) start | hh:mm | | |
| | | | T2(T4) start | hh:mm | | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | | |
| Overload Alarm | | | | | | |
| Alarm | Disable | | | | | |
| | Enable | Pick Up Value (kW) | | | 1 - 9999999 | |

| Digital Output | | | | |
|---|----------------|-----------------------------|--|-------------------------------------|
| | DO Function | Disable for Alarm | | |
| | | for Pulse (kWh) | Pulse Constant (imp/kWh) | 100 200 1000 1 10 20 |
| | | | Pulse Width (ms) | 50 100 200 300 |
| | | Digital Input | | |
| DI Function | Input Status | | For example, OF, SD of a circuit breaker | |
| | Tariff Control | | | |
| | Input Metering | In. Pulse Const. (imp/unit) | 1 - 10000 | |
| | Partial Reset | | | |
| Communication | | | | |
| | Primary Addr. | | 0 - 255 | |
| | Baud Rate | | 2400 4800 9600 300 600 1200 | |
| Com.Protection | | | | |
| | Com.Protection | | Enable Disable | |
| Contrast | | | | |
| | Contrast | | 1 - 9 | |
| Password | | | | |
| | Password | | 0 - 9999 | |
| Reset Config | | | | |
| | Reset Config | | | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | | | |

Configuration menu for iEM3150 / iEM3155

| Wiring | | |
|-----------|-----------|--|
| | Type | 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 3PH3W 1PH4W Multi L-N |
| Frequency | | |
| | Frequency | 50 60 |
| Date | | |
| | Date | DD-MMM-YYYY |
| Time | | |
| | Time | hh:mm |

| Multi Tariffs (iEM3155) | | | | | | |
|---|-------------------|-----------------------------|--------------|----------|--|--|
| Control mode | Disable | | | | | |
| | by Communications | | | | | |
| | by Digital Input | | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm | |
| | | | | T2 start | hh:mm | |
| | | | by 3 tariffs | T1 start | hh:mm | |
| | | | | T2 start | hh:mm | |
| | by 4 tariffs | T1(T3) start | hh:mm | | | |
| T2(T4) start | | hh:mm | | | | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | | |
| Overload Alarm (iEM3155) | | | | | | |
| Alarm | Disable | | | | | |
| | Enable | Pick Up Value (kW) | 1 - 9999999 | | | |
| Digital Output (iEM3155 only) | | | | | | |
| DO Function | Disable | | | | | |
| | for Alarm | | | | | |
| | for Pulse (kWh) | Pulse Constant (imp/kWh) | 100 | | | |
| | | | 200 | | | |
| | | | 1000 | | | |
| | | | 1 | | | |
| | Pulse Width (ms) | 10 | | | | |
| | | 20 | | | | |
| 50 | | | | | | |
| 100 | | | | | | |
| 200 | | | | | | |
| 300 | | | | | | |
| Digital Input (iEM3155 only) | | | | | | |
| DI Function | Input Status | | | | For example, OF, SD of a circuit breaker | |
| | Tariff Control | | | | | |
| | Input Metering | In. Pulse Const. (imp/unit) | 1 - 10000 | | | |
| | Partial Reset | | | | | |
| Communication | | | | | | |
| Slave Address | 1 - 247 | | | | | |
| | Baud Rate | 19200 | | | | |
| | | 38400 9600 | | | | |
| Parity | Even | | | | | |
| | Odd | | | | | |
| | None | | | | | |
| NOTE: Number of stop bits = 1. | | | | | | |
| Com.Protection (iEM3155) | | | | | | |
| Com.Protection | Enable | | | | | |
| Disable | | | | | | |
| Contrast | | | | | | |
| Contrast | 1 - 9 | | | | | |
| Password (iEM3155) | | | | | | |
| Password | 0 - 9999 | | | | | |
| Reset Config | | | | | | |
| Reset Config | | | | | | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | | | | | |

Configuration menu for iEM3165

| | | | | | |
|---|-------------------|--------------------------------|--------------|--------------|--|
| Wiring | | | | | |
| Type | | | | | 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 3PH3W 1PH4W Multi L-N |
| Frequency | | | | | |
| Frequency | | | | | 50 60 |
| Date | | | | | |
| Date | | | | | DD-MMM-YYYY |
| Time | | | | | |
| Time | | | | | hh:mm |
| Multi Tariffs | | | | | |
| Control mode | Disable | | | | |
| | by Communications | | | | |
| | by Digital Input | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| | by Internal Clock | Schedule ¹ | by 3 tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| | by Internal Clock | Schedule ¹ | by 4 tariffs | T1(T3) start | hh:mm |
| | | | T2(T4) start | hh:mm | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | |
| Overload Alarm | | | | | |
| Alarm | Disable | | | | |
| | Enable | Pick Up Value (kW) | | | 1 - 9999999 |
| Digital Output | | | | | |
| DO Function | Disable | | | | |
| | for Alarm | | | | |
| | for Pulse (kWh) | Pulse Constant (imp/kWh) | 100 | | |
| | | | 200 | | |
| | | | 1000 | | |
| | | | 1 | | |
| | for Pulse (kWh) | Pulse Width (ms) | 10 | | |
| | | | 20 | | |
| 50 | | | | | |
| 100 | | | | | |
| | | | 200 | | |
| | | | 300 | | |
| Digital Input | | | | | |
| DI Function | Input Status | | | | For example, OF, SD of a circuit breaker |
| | Tariff Control | | | | |
| | Input Metering | In. Pulse Const. (imp/unit) | | | 1 - 10000 |
| | Partial Reset | | | | |
| Communication | | | | | |
| MAC Addr. | | | | | 1 - 127 |
| Baud Rate | | | | | 9600 |
| | | | | | 19200 |
| | | | | | 38400 |
| | | | | | 57600 |
| | | | | 76800 | |
| Device ID | | | | | 0 - 4194303 |

| | | |
|---|--|-------------------|
| Com.Protection | | |
| Com.Protection | | Enable Disable |
| Contrast | | |
| Contrast | | 1 - 9 |
| Password | | |
| Password | | 0 - 9999 |
| Reset Config | | |
| Reset Config | | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | |

Configuration menu for iEM3175

| | | | | | |
|---|-----------------------|-----------------------------|--------------|----------|--|
| Wiring | | | | | |
| Type | | | | | 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 3PH3W 1PH4W Multi L-N |
| Frequency | | | | | |
| Frequency | | | | | 50 60 |
| Date | | | | | |
| Date | | | | | DD-MMM-YYYY |
| Time | | | | | |
| Time | | | | | hh:mm |
| Multi Tariffs | | | | | |
| Control mode | Disable | | | | |
| | by Communications | | | | |
| | by Digital Input | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| | by Internal Clock | Schedule ¹ | by 3 tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| by Internal Clock | Schedule ¹ | by 4 tariffs | T1(T3) start | hh:mm | |
| | | | T2(T4) start | hh:mm | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | |
| Overload Alarm | | | | | |
| Alarm | Disable | | | | |
| | Enable | Pick Up Value (kW) | 1 - 9999999 | | |
| Digital Input | | | | | |
| DI Function | Input Status | | | | For example, OF, SD of a circuit breaker |
| | Tariff Control | | | | |
| | Input Metering | In. Pulse Const. (imp/unit) | 1 - 10000 | | |
| | Partial Reset | | | | |
| Com.Protection | | | | | |
| Com.Protection | | | | | Enable Disable |
| Contrast | | | | | |
| Contrast | | | | | 1 - 9 |
| Password | | | | | |
| Password | | | | | 0 - 9999 |

| | |
|---|--|
| Reset Config | |
| Reset Config | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | |

Configuration Menu for iEM3200 / iEM3210 / iEM3215

| | |
|---------------|---|
| Wiring | |
| Type | 3PH3W 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N |
| CT | 3CTs on I1, I2, I3 1 CT on I1 2 CTs on I1, I3 |

| | |
|-----------------|-----------|
| CT Ratio | |
| CT Secondary | 1 5 |
| CT Primary | 1 - 32767 |

| | |
|------------------|----------|
| Frequency | |
| Frequency | 50 60 |

| | |
|---------------------------------|-------------|
| Date (iEM3210 / iEM3215) | |
| Date | DD-MMM-YYYY |

| | |
|---------------------------------|-------|
| Time (iEM3210 / iEM3215) | |
| Time | hh:mm |

| | |
|-------------------------------|------|
| Pulse output (iEM3210) | |
| Pulse Constant (imp/kWh) | 0.01 |
| | 0.1 |
| | 1 |
| | 10 |
| | 100 |
| Pulse Width (ms) | 50 |
| | 100 |
| | 200 |
| | 200 |
| | 300 |

| | | | | | |
|--------------------------------|-----------------------|-----------------------|--------------|----------|-------|
| Multi Tariffs (iEM3215) | | | | | |
| Control mode | Disable | | | | |
| | by Digital Input | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| | by Internal Clock | Schedule ¹ | by 3 tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| by Internal Clock | Schedule ¹ | by 4 tariffs | T1(T3) start | hh:mm | |
| | | | T2(T4) start | hh:mm | |

¹The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1.

| | |
|-----------------|-------|
| Contrast | |
| Contrast | 1 - 9 |

| | |
|-------------------------------------|----------|
| Password (iEM3210 / iEM3215) | |
| Password | 0 - 9999 |

| | |
|---|--|
| Reset Config | |
| Reset Config | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | |

Configuration menu for iEM3235

| | | | | | |
|---|-----------------------|--------------------------|--------------|----------|--|
| Wiring | | | | | |
| Type | | | | | 3PH3W 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 1PH4W Multi L-N |
| VT | | | | | Direct-NoVT Wye(3VTs) Delta(2VTs) |
| CT | | | | | 3CTs on I1, I2, I3 1 CT on I1 2 CTs on I1, I3 |
| CT & VT Ratio | | | | | |
| CT Secondary | | | | | 1 5 |
| CT Primary | | | | | 1 - 32767 |
| VT Secondary | | | | | 100 110 115 120 |
| VT Primary | | | | | 1 - 1000000 |
| Frequency | | | | | |
| Frequency | | | | | 50 60 |
| Date | | | | | |
| Date | | | | | DD-MMM-YYYY |
| Time | | | | | |
| Time | | | | | hh:mm |
| Multi Tariffs | | | | | |
| Control mode | Disable | | | | |
| | by Communications | | | | |
| | by Digital Input | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| | by Internal Clock | Schedule ¹ | by 3 tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| by Internal Clock | Schedule ¹ | by 4 tariffs | T1(T3) start | hh:mm | |
| | | | T2(T4) start | hh:mm | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | |
| Overload Alarm | | | | | |
| Alarm | Disable | | | | |
| | Enable | Pick Up Value (kW) | | | 1 - 9999999 |
| Digital Output | | | | | |
| DO Function | Disable | | | | |
| | for Alarm | | | | |
| | for Pulse (kWh) | Pulse Constant (imp/kWh) | | | 0.01 0.1 1 10 100 500 |
| | | Pulse Width (ms) | | | 50 100 200 300 |
| | | | | | |

| | | | | |
|---|----------------|----------------|--|--|
| Digital Input | | | | |
| | DI Function | Input Status | | For example, OF, SD of a circuit breaker |
| | | Tariff Control | | |
| | | Input Metering | In. Pulse Const. (imp/unit) | 1 - 10000 |
| | | Partial Reset | | |
| Communication | | | | |
| | Primary Addr. | | 0 - 255 | |
| | Baud Rate | | 2400 4800 9600 300 600 1200 | |
| Com.Protection | | | | |
| | Com.Protection | | Enable Disable | |
| Contrast | | | | |
| | Contrast | | 1 - 9 | |
| Password | | | | |
| | Password | | 0 - 9999 | |
| Reset Config | | | | |
| | Reset Config | | | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | | | |

Configuration Menu for iEM3250 / iEM3255

| | | | |
|--------------------------|--------------|--|--|
| Wiring | | | |
| | Type | 3PH3W 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 1PH4W Multi L-N | |
| | VT | Direct-NoVT Wye(3VTs) Delta(2VTs) | |
| | CT | 3CTs on I1, I2, I3 1 CT on I1 2 CTs on I1, I3 | |
| CT & VT Ratio | | | |
| | CT Secondary | 1 5 | |
| | CT Primary | 1 - 32767 | |
| | VT Secondary | 100 110 115 120 | |
| | VT Primary | 1 - 1000000 | |
| Frequency | | | |
| | Frequency | 50 60 | |
| Date | | | |
| | Date | DD-MMM-YYYY | |
| Time | | | |
| | Time | hh:mm | |

| Multi Tariffs (iEM3255) | | | | | | | |
|---|-------------------|-----------------------------|--------------|--|--|------|--|
| Control mode | Disable | | | | | | |
| | by Digital Input | | | | | | |
| | by Communication | | | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm | | |
| | | | | T2 start | hh:mm | | |
| | | | by 3 tariffs | T1 start | hh:mm | | |
| | | | | T2 start | hh:mm | | |
| | by 4 tariffs | T1(T3) start | hh:mm | | | | |
| T2(T4) start | | hh:mm | | | | | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | | | |
| Overload Alarm (iEM3255) | | | | | | | |
| Alarm | Enable | Pick Up Value (kW) | 0 - 9999999 | | | | |
| | Disable | | | | | | |
| Digital Output (iEM3255) | | | | | | | |
| DO Function | Disable | | | | | | |
| | for Alarm | | | | | | |
| | for Pulse (kWh) | Pulse Constant (imp/kWh) | | | | 0.01 | |
| | | | | | | 0.1 | |
| | | | | | | 1 | |
| | | | | | | 10 | |
| | | | | | | 100 | |
| | Pulse Width (ms) | | | | 500 | | |
| | | | 50 | | | | |
| | | | 100 | | | | |
| | | | 200 | | | | |
| | | | 300 | | | | |
| Digital Input (iEM3255) | | | | | | | |
| DI Function | Input Status | | | | For example, OF, SD of a circuit breaker | | |
| | Tariff Control | | | | | | |
| | Input Metering | In. Pulse Const. (imp/unit) | 1 - 10000 | | | | |
| | Partial Reset | | | | | | |
| Communication | | | | | | | |
| Slave Address | | | | 1 - 247 | | | |
| Baud Rate | | | | 19200 38400 9600 | | | |
| Parity | | | | Even Odd None NOTE: Number of stop bits = 1. | | | |
| Com.Protection (iEM3255) | | | | | | | |
| Com.Protection | | | | Enable Disable | | | |
| Contrast | | | | | | | |
| Contrast | | | | 1 - 9 | | | |
| Password (iEM3255) | | | | | | | |
| Password | | | | 0 - 9999 | | | |
| Reset Config | | | | | | | |
| Reset Config | | | | | | | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | | | | | | |

Configuration menu for iEM3265

| | | | | | |
|---|-----------------------|-----------------------|--------------|----------|--|
| Wiring | | | | | |
| Type | | | | | 3PH3W 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 1PH4W Multi L-N |
| VT | | | | | Direct-NoVT Wye(3VTs) Delta(2VTs) |
| CT | | | | | 3CTs on I1, I2, I3 1 CT on I1 2 CTs on I1, I3 |
| CT & VT Ratio | | | | | |
| CT Secondary | | | | | 1 5 |
| CT Primary | | | | | 1 - 32767 |
| VT Secondary | | | | | 100 110 115 120 |
| VT Primary | | | | | 1 - 1000000 |
| Frequency | | | | | |
| Frequency | | | | | 50 60 |
| Date | | | | | |
| Date | | | | | DD-MMM-YYYY |
| Time | | | | | |
| Time | | | | | hh:mm |
| Multi Tariffs | | | | | |
| Control mode | Disable | | | | |
| | by Digital Input | | | | |
| | by Communication | | | | |
| | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| | by Internal Clock | Schedule ¹ | by 3 tariffs | T1 start | hh:mm |
| | | | | T2 start | hh:mm |
| by Internal Clock | Schedule ¹ | by 4 tariffs | T1(T3) start | hh:mm | |
| | | | T2(T4) start | hh:mm | |
| ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | | | | | |
| Overload Alarm | | | | | |
| Alarm | Enable | Pick Up Value (kW) | | | 0 - 9999999 |
| | Disable | | | | |

| Digital Output | | | | |
|---|----------------|-------------------|--|--|
| | DO Function | Disable for Alarm | | |
| | | for Pulse (kWh) | Pulse Constant (imp/kWh) | 0.01 |
| | | | | 0.1 |
| | | | | 1 |
| | | | | 10 |
| | | Pulse Width (ms) | 100 | |
| | | | 200 | |
| | | | 300 | |
| Digital Input | | | | |
| | DI Function | Input Status | | For example, OF, SD of a circuit breaker |
| | | Tariff Control | | |
| | | Input Metering | In. Pulse Const. (imp/unit) | 1 - 10000 |
| | | Partial Reset | | |
| Communication | | | | |
| | MAC Addr. | | 1 - 127 | |
| | Baud Rate | | 9600 19200 38400 57600 76800 | |
| | Device ID | | 0 - 4194303 | |
| Com.Protection | | | | |
| | Com.Protection | | Enable Disable | |
| Contrast | | | | |
| | Contrast | | 1 - 9 | |
| Password | | | | |
| | Password | | 0 - 9999 | |
| Reset Config | | | | |
| | Reset Config | | | |
| NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | | | |

Configuration Menu for iEM3275

| Wiring | | |
|--------|--|--|
| Type | | 3PH3W 3PH4W 1PH2W L-N 1PH2W L-L 1PH3W L-L-N 1PH4W Multi L-N |
| VT | | Direct-NoVT Wye(3VTs) Delta(2VTs) |
| CT | | 3CTs on I1, I2, I3 1 CT on I1 2 CTs on I1, I3 |

| | | | | | |
|--------------------------|---|-------------------|--------------------------------|---|--|
| CT & VT Ratio | | | | | |
| | CT Secondary | | 1 5 | | |
| | CT Primary | | 1 - 32767 | | |
| | VT Secondary | | 100 110 115 120 | | |
| | VT Primary | | 1 - 1000000 | | |
| Frequency | | | | | |
| | Frequency | | 50 60 | | |
| Date | | | | | |
| | Date | | DD-MMM-YYYY | | |
| Time | | | | | |
| | Time | | hh:mm | | |
| Multi Tariffs | | | | | |
| | Control mode | Disable | | | |
| | | by Communications | | | |
| | | by Digital Input | | | |
| | | by Internal Clock | Schedule ¹ | by 2 Tariffs | T1 start hh:mm T2 start hh:mm |
| | | | | by 3 tariffs | T1 start hh:mm T2 start hh:mm |
| | | | by 4 tariffs | | T1(T3) start hh:mm T2(T4) start hh:mm |
| | | | | ¹ The start time of the next tariff is the end time of the current tariff. For example, T2 start equals the end of T1. | |
| Overload Alarm | | | | | |
| | Alarm | Disable | | | |
| | | Enable | Pick Up Value (kW) | 1 - 9999999 | |
| Digital Input | | | | | |
| | DI Function | Input Status | | For example, OF, SD of a circuit breaker | |
| | | Tariff Control | | | |
| | | Input Metering | In. Pulse Const. (imp/unit) | 1 - 10000 | |
| | | Partial Reset | | | |
| Com.Protection | | | | | |
| | Com.Protection | | Enable Disable | | |
| Contrast | | | | | |
| | Contrast | | 1 - 9 | | |
| Password | | | | | |
| | Password | | 0 - 9999 | | |
| Reset Config | | | | | |
| | Reset Config | | | | |
| | NOTE: Settings are reset to their defaults, except for Password. Meter restarts. | | | | |

Chapter 5 Communications via Modbus RS-485

What is in this chapter?

This chapter contains the following sections:

- Modbus communication overview** 51
 - Modbus communications settings 51
 - Communications LED indicator for Modbus devices 52
- Modbus functions** 52
 - Function list 52
 - Table format 52
- Command interface** 53
 - Command interface overview 53
 - Command request 53
 - Command result 53
 - Command list 54
- Modbus register list** 57
- Read Device Identification** 61

Modbus communication overview

Modbus RTU protocol is available on the iEM3150, iEM3155, iEM3250 and iEM3255.

The information in this section assumes that you have an advanced understanding of Modbus communications, your communications network and the power system that your meter is connected to.

There are three different ways of using Modbus communication:

- by sending commands using the command interface (see “Command interface overview” on page 53)
- by reading the Modbus registers (see “Modbus register list” on page 57)
- by reading Device Identification (see “Read Device Identification” on page 61)

Modbus communications settings

Before communicating with the device using Modbus protocol, use the HMI to configure the following settings:

| Settings | Possible values |
|-----------|--|
| Baud rate | 9600 Baud 19 200 Baud 38 400 Baud |
| Parity | Odd Even None NOTE: number of stop bits = 1 |
| Address | 1–247 |

Communications LED indicator for Modbus devices

The yellow communications LED indicates the status of communication between the meter and the master as follows:

| If... | Then... |
|---------------------|---|
| The LED is flashing | Communication with the device has been established. NOTE: If there is an error online, the LED is also flashing. |
| The LED is off | There is no active communication between the master and the slave |

Related topics

- For more information on the Modbus protocol, see the Modbus organization website at www.modbus.org.
- See “Physical description” on page 14 for the location of the communications LED.

Modbus functions

Function list

The table below lists the three supported Modbus functions:

| Function code | | Function name |
|---------------|-------------|----------------------------|
| Decimal | Hexadecimal | |
| 3 | 0x03 | Read Holding Registers |
| 16 | 0x10 | Write Multiple Registers |
| 43/14 | 0x2B/0x0E | Read Device Identification |

For example:

- To read different parameters from the energy meter, use function 3 (Read).
- To change the tariff, use function 16 (Write) to send a command to the energy meter.

Table format

Register tables have the following columns:

| Register Address | Action (R/W/WC) | Size | Type | Units | Range | Description |
|------------------|-----------------|------|------|-------|-------|-------------|
|------------------|-----------------|------|------|-------|-------|-------------|

- *Register Address*: Modbus address of register encoded in the Modbus frame, in decimal (dec)
- *Action*: The read/write/write by command property of the register
- *Size*: The data size in Int16
- *Type*: The encoding data type
- *Units*: The unit of the register value
- *Range*: The permitted values for this variable, usually a subset of what the format allows
- *Description*: Provides information about the register and the values that apply

Unit table

The following data types appear in the Modbus register list:

| Type | Description | Range |
|----------|-------------------------|--|
| UInt16 | 16 bit unsigned integer | 0...65535 |
| Int16 | 16 bit signed integer | -32768...+32767 |
| UInt32 | 32 bit unsigned integer | 0...4 294 967 295 |
| Int64 | 64 bit unsigned integer | 0...18 446 744 073 709 551 615 |
| UTF8 | 8 bit field | multibyte character encoding for Unicode |
| Float32 | 32 bit value | Standard representation IEEE for floating number (with single precision) |
| Bitmap | — | — |
| DATETIME | See below | — |

DATETIME format:

| Word | Bits | | | | | | | | | | | | | | | | |
|----------------------------------|-------------------------|----|----|----|----------------|----|---|---|--|----------------|---|---|-----------------|---|---|---|--|
| | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| 1 | Reserved (0) | | | | | | | | R4 (0) | Year (0...127) | | | | | | | |
| 2 | 0 | | | | Month (1...12) | | | | WD (0) | | | | Day (1...31) | | | | |
| 3 | SU (0) | | 0 | | Hour (0...23) | | | | iV | | 0 | | Minute (0...59) | | | | |
| 4 | Millisecond (0...59999) | | | | | | | | | | | | | | | | |
| R4 : | | | | | | | | | Reserved Bit | | | | | | | | |
| Year : | | | | | | | | | 7 bits (year from 2000) | | | | | | | | |
| Month : | | | | | | | | | 4 bits | | | | | | | | |
| Day : | | | | | | | | | 5 bits | | | | | | | | |
| Hour : | | | | | | | | | 5 bits | | | | | | | | |
| Minute : | | | | | | | | | 6 bits | | | | | | | | |
| Millisecond : | | | | | | | | | 2 octets | | | | | | | | |
| WD (day of the week) : | | | | | | | | | 1-7: Sunday-Saturday | | | | | | | | |
| SU (summer time) : | | | | | | | | | Bit to 0 if this parameter is not used. | | | | | | | | |
| iV (validity of received data) : | | | | | | | | | Bit to 0 if this parameter is not valid or not used. | | | | | | | | |

Command interface

Command interface overview

The command interface allows you to configure the energy meter by sending specific command requests using Modbus function 16.

Command request

The following table describes a Modbus command request:

| Slave Number | Function Code | Command block | | CRC |
|--------------|---------------|-------------------|---|----------|
| | | Register Address | Command Description | |
| 1-247 | 16 | 5250 (up to 5374) | The command is made of a command number and a set of parameters. See the detailed description of each command in the command list. NOTE: All the reserved parameters can be considered as any value, e.g. 0. | Checking |

The following table describes the command block:

| Register Address | Content | Size (Int16) | Data (example) |
|------------------|----------------|--------------|---|
| 5250 | Command Number | 1 | 2008 (Set Tariff) |
| 5251 | (Reserved) | 1 | 0 |
| 5252-5374 | Parameter | n | 4 (Tariff=4) NOTE: Command number 2008 supports only one parameter with the size of 1. |

Command result

The command result can be obtained by reading registers 5375 and 5376.

The following table describes the command result:

| Register Address | Content | Size (Int16) | Data (example) |
|------------------|---|--------------|---------------------|
| 5375 | Requested Command Number | 1 | 2008 (Set Tariff) |
| 5376 | Result Command result codes: <ul style="list-style-type: none"> • 0 = Valid Operation • 3000 = Invalid Command • 3001 = Invalid Parameter • 3002 = Invalid Number of Parameters • 3007 = Operation Not Performed | 1 | 0 (Valid Operation) |

Command list

Set Date/Time

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|--------|------|-----------|-------------|
| 1003 | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | 2000–2099 | Year |
| | W | 1 | UInt16 | — | 1–12 | Month |
| | W | 1 | UInt16 | — | 1–31 | Day |
| | W | 1 | UInt16 | — | 23 | Hour |
| | W | 1 | UInt16 | — | 0–59 | Minute |
| | W | 1 | UInt16 | — | 0–59 | Second |
| | W | 1 | UInt16 | — | — | (Reserved) |

Set Wiring

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|---------|------|------------------------|--|
| 2000 | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | 0, 1, 2, 3, 11,13 | Power System Configuration 0 = 1PH2W L-N 1 = 1PH2W L-L 2 = 1PH3W L-L-N 3 = 3PH3W 11 = 3PH4W 13 = 1PH4W L-N |
| | W | 1 | UInt16 | Hz | 50, 60 | Nominal Frequency |
| | W | 2 | Float32 | – | – | (Reserved) |
| | W | 2 | Float32 | – | – | (Reserved) |
| | W | 2 | Float32 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 2 | Float32 | V | VT Secondary–1000000.0 | VT Primary NOTE: For iEM3250 / iEM3255. Reserved by iEM3150 / iEM3155 |
| | W | 1 | UInt16 | V | 100, 110, 115, 120 | VT Secondary NOTE: For iEM3250 / iEM3255. Reserved by iEM3150 / iEM3155 |
| | W | 1 | UInt16 | – | 1, 2, 3 | Number of CTs NOTE: For iEM3250 / iEM3255. Reserved by iEM3150 / iEM3155 |
| | W | 1 | UInt16 | A | 1–32767 | CT Primary NOTE: For iEM3250 / iEM3255. Reserved by iEM3150 / iEM3155 |
| | W | 1 | UInt16 | A | 1, 5 | CT Secondary NOTE: For iEM3250 / iEM3255. Reserved by iEM3150 / iEM3155 |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | – | (Reserved) |
| | W | 1 | UInt16 | – | 0, 1, 2 | VT Connection type: 0 = Direct Connect 1 = 3PH3W (2 VTs) 2 = 3PH4W (3 VTs) NOTE: For iEM3250 / iEM3255. Reserved by iEM3150 / iEM3155 |

Set Pulse Output (iEM3155 / iEM3255)

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|---------|-----------|---|--|
| 2003 | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | 0, 1 | Pulse Output enable / disable 0 = Disable 1 = Enable |
| | W | 2 | Float32 | pulse/kWh | iEM3155: 1, 10, 20, 100, 200, 1000 iEM3255: 0.01, 0.1, 1, 10, 100, 500 | Pulse constant |
| | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 2 | Float32 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 2 | Float32 | — | — | (Reserved) |
| 2038 | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | ms | 50, 100, 200, 300 | Pulse width |

Set Tariff (iEM3155 / iEM3255)

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|--------|------|------------|---|
| 2060 | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | 0, 1, 2, 4 | Multi Tariff Mode 0 = Disable Multi Tariff 1 = Use COM as Tariff Control (maximum 4 tariffs) 2 = Use Digital Input as Tariff Control (2 tariffs) 4 = Use Internal Clock as Tariff Control (maximum 4 tariffs) |
| 2008 | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | 1-4 | Tariff 1 = T1 2 = T2 3 = T3 4 = T4 NOTE: You can only set the tariff using this method if the Tariff Mode is set to by Communication. |

Set Digital Input as Partial Energy Reset (iEM3155 / iEM3255)

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|--------|------|-------|--|
| 6017 | W | 1 | UInt16 | — | — | (Reserved) |
| | W | 1 | UInt16 | — | 0, 1 | Digital Input to Associate: 0 = Disable 1 = Enable |

Input Metering Setup (iEM3155 / iEM3255)

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|---------|------|-------------------|---|
| 6014 | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | 1 | Input Metering Channel |
| | W | 20 | UTF8 | - | string size <= 40 | Label |
| | W | 2 | Float32 | - | 1-10000 | Pulse Weight |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | 0, 1 | Digital Input Association: 0 = Disable 1 = Enable |

Overload Alarm Setup (iEM3155 / iEM3255)

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|---------|------|----------|---|
| 7000 | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | 9 | Alarm ID |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | 0, 1 | 0 = Disable 1 = Enable |
| | W | 2 | Float32 | - | 0.0-1e10 | Pickup value |
| | W | 2 | UInt32 | - | - | (Reserved) |
| | W | 2 | Float32 | - | - | (Reserved) |
| | W | 2 | UInt32 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 4 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | - | (Reserved) |
| 20000 | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 2 | Float32 | - | - | (Reserved) |
| | W | 2 | UInt32 | - | - | (Reserved) |
| | W | 1 | Bitmap | - | 0,1 | Digital Output to Associate 0 = Unassociated 1 = Associated |
| 20001 | W | 1 | UInt16 | - | - | Acknowledge the Overload Alarm |

Communications Setup

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|--------|------|---------|---|
| 5000 | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | - | (Reserved) |
| | W | 1 | UInt16 | - | 1-247 | Address |
| | W | 1 | UInt16 | - | 0, 1, 2 | Baud Rate 0 = 9600 1 = 19200 2 = 38400 |
| | W | 1 | UInt16 | - | 0, 1, 2 | Parity 0 = Even 1 = Odd 2 = None |
| | W | 1 | UInt16 | - | - | (Reserved) |

Reset Partial Energy Counters

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|--------|------|-------|---|
| 2020 | W | 1 | UInt16 | – | – | (Reserved) iEM3150/iEM3250: Partial Active Energy and Phase Energy registers will be reset. iEM3155/iEM3255: Partial Active / Reactive Energy, Energy by tariff and Phase Energy registers will be reset. |

Reset Input Metering Counter (iEM3155 / iEM3255)

| Command Number | Action (R/W) | Size | Type | Unit | Range | Description |
|----------------|--------------|------|--------|------|-------|-------------|
| 2023 | W | 1 | UInt16 | – | – | (Reserved) |

Modbus register list

System

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|-------|----------|-------|---|
| 30 | R | 20 | UTF8 | – | Meter Name |
| 50 | R | 20 | UTF8 | – | Meter Model |
| 70 | R | 20 | UTF8 | – | Manufacturer |
| 130 | R | 2 | UInt32 | – | Serial Number |
| 132 | R | 4 | DATETIME | – | Date of Manufacture |
| 136 | R | 5 | UTF8 | – | Hardware Revision |
| 1637 | R | 1 | UInt16 | – | Present Firmware Version (DLF format): X.Y.ZTT |
| 1845–1848 | R/WC | 1 X 4 | UInt16 | – | Date/Time Reg. 1845: Year (b6:b0) 0–99 (year from 2000 to 2099) Reg. 1846: Month (b11:b8), Weekday (b7:b5), Day (b4:b0) Reg. 1847: Hour (b12:b8), Minute (b5:b0) Reg. 1848: Millisecond |

Meter Setup and Status

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|---------|--------|--|
| 2004 | R | 2 | UInt32 | Second | Meter Operation Timer Not applicable for iEM3150 / iEM3250 |
| 2014 | R | 1 | UInt16 | – | Number of Phases |
| 2015 | R | 1 | UInt16 | – | Number of Wires |
| 2016 | R/WC | 1 | UInt16 | – | Power System 0 = 1PH2W L–N 1 = 1PH2W L–L 2 = 1PH3W L–L with N 3 = 3PH3W 11 = 3PH4W 13 = 1PH4W multi L with N |
| 2017 | R/WC | 1 | UInt16 | Hz | Nominal Frequency |
| 2025 | R | 1 | UInt16 | – | Number VTs Not applicable for iEM3150 / iEM3155 |
| 2026 | R/WC | 2 | Float32 | V | VT Primary Not applicable for iEM3150 / iEM3155 |
| 2028 | R/WC | 1 | UInt16 | V | VT Secondary Not applicable for iEM3150 / iEM3155 |
| 2029 | R/WC | 1 | UInt16 | – | Number CTs Not applicable for iEM3150 / iEM3155 |
| 2030 | R/WC | 1 | UInt16 | A | CT Primary Not applicable for iEM3150 / iEM3155 |

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|--------|-------|--|
| 2031 | R/WC | 1 | UInt16 | A | CT Secondary Not applicable for iEM3150 / iEM3155 |
| 2036 | R/WC | 1 | UInt16 | - | VT Connection Type 0 = Direct Connect 1 = 3PH3W (2 VTs) 2 = 3PH4W (3 VTs) Not applicable for iEM3150 / iEM3155 |

Energy Pulse Output Setup (iEM3155 / iEM3255)

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|---------|-------------|--|
| 2129 | R/WC | 1 | UInt16 | Millisecond | Energy Pulse Duration |
| 2131 | R/WC | 1 | UInt16 | - | Digital Output Association 0 = Disable 1 = DO1 enable for active energy pulse output |
| 2132 | R/WC | 2 | Float32 | pulse/kWh | Pulse Weight |

Command Interface

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|--------|-------|---|
| 5250 | R/W | 1 | UInt16 | - | Requested Command |
| 5252 | R/W | 1 | UInt16 | - | Command Parameter 001 |
| 5374 | R/W | 1 | UInt16 | - | Command Parameter 123 |
| 5375 | R | 1 | UInt16 | - | Command Status |
| 5376 | R | 1 | UInt16 | - | Command Result codes: 0 = Valid Operation 3000 = Invalid Command 3001 = Invalid Parameter 3002 = Invalid Number of Parameters 3007 = Operation Not Performed |
| 5377 | R/W | 1 | UInt16 | - | Command Data 001 |
| 5499 | R | 1 | UInt16 | - | Command Data 123 |

Communication

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|--------|-------|---|
| 6500 | R | 1 | UInt16 | - | Protocol 0 = Modbus |
| 6501 | R/WC | 1 | UInt16 | - | Address |
| 6502 | R/WC | 1 | UInt16 | - | Baud Rate: 0 = 9600 1 = 19 200 2 = 38 400 |
| 6503 | R/WC | 1 | UInt16 | - | Parity: 0 = Even 1 = Odd 2 = None NOTE: number of stop bits = 1 |

Input Metering Setup (iEM3155 / iEM3255)

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|------|-------|-------------|
| 7032 | R/WC | 20 | UTF8 | - | Label |

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|---------|------------|--|
| 7052 | R/WC | 2 | Float32 | pulse/unit | Pulse Constant |
| 7055 | R/WC | 1 | UInt16 | – | Digital Input Association 0 = Disable for input metering 1 = Enable for input metering |

Digital Input (iEM3155 / iEM3255)

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|--------|-------|--|
| 7274 | R | 1 | UInt16 | – | Digital Input Control Mode: 0 = Normal (Input Status) 2 = Multi Tariff Control 3 = Input Metering 5 = All Energy Reset |
| 8905 | R | 2 | Bitmap | – | Digital Input Status (only Bit 1 is used): Bit 1 = 0, relay open Bit 1 = 1, relay closed |

Digital Output (iEM3155 / iEM3255)

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|--------|-------|---|
| 9673 | R | 1 | UInt16 | – | Digital Output Control Mode Status: 2 = for Alarm 3 = for Pulse (kWh) 0xFFFF = Disable |

Meter Data (iEM3150 / iEM3155 / iEM3250 / iEM3255)

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|---------|-------|--|
| Current | | | | | |
| 3000 | R | 2 | Float32 | A | I1: phase 1 current |
| 3002 | R | 2 | Float32 | A | I2: phase 2 current |
| 3004 | R | 2 | Float32 | A | I3: phase 3 current |
| 3010 | R | 2 | Float32 | A | Current Avg |
| Voltage | | | | | |
| 3020 | R | 2 | Float32 | V | Voltage L1–L2 |
| 3022 | R | 2 | Float32 | V | Voltage L2–L3 |
| 3024 | R | 2 | Float32 | V | Voltage L3–L1 |
| 3026 | R | 2 | Float32 | V | Voltage L–L Avg |
| 3028 | R | 2 | Float32 | V | Voltage L1–N |
| 3030 | R | 2 | Float32 | V | Voltage L2–N |
| 3032 | R | 2 | Float32 | V | Voltage L3–N |
| 3036 | R | 2 | Float32 | V | Voltage L–N Avg |
| Power | | | | | |
| 3054 | R | 2 | Float32 | kW | Active Power Phase 1 |
| 3056 | R | 2 | Float32 | kW | Active Power Phase 2 |
| 3058 | R | 2 | Float32 | kW | Active Power Phase 3 |
| 3060 | R | 2 | Float32 | kW | Total Active Power |
| 3068 | R | 2 | Float32 | kVAR | Total Reactive Power Not applicable for iEM3150 / iEM3250 |
| 3076 | R | 2 | Float32 | kVA | Total Apparent Power Not applicable for iEM3150 / iEM3250 |

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|--|-----------------|------|----------|-------|--|
| Power Factor | | | | | |
| 3084 | R | 2 | Float32 | – | Total Power Factor: -2 < PF < -1 = Quad 2, active power negative, capacitive -1 < PF < 0 = Quad 3, active power negative, inductive 0 < PF < 1 = Quad 1, active power positive, inductive 1 < PF < 2 = Quad 4, active power positive, capacitive |
| Frequency | | | | | |
| 3110 | R | 2 | Float32 | Hz | Frequency |
| Total Energy (cannot be reset) | | | | | |
| 3204 | R | 4 | Int64 | Wh | Total Active Energy Import |
| 3208 | R | 4 | Int64 | Wh | Total Active Energy Export Not applicable for iEM3150 / iEM3250 |
| 3220 | R | 4 | Int64 | VARh | Total Reactive Energy Import Not applicable for iEM3150 / iEM3250 |
| 3224 | R | 4 | Int64 | VARh | Total Reactive Energy Export Not applicable for iEM3150 / iEM3250 |
| Energy Reset (Partial Energy, Energy by Tariff, Phase Energy) | | | | | |
| 3252 | R | 4 | DATETIME | – | Energy Reset Date and Time |
| Partial Energy | | | | | |
| 3256 | R | 4 | Int64 | Wh | Partial Active Energy Import |
| 3272 | R | 4 | Int64 | VARh | Partial Reactive Energy Import Not applicable for iEM3150 / iEM3250 |
| Phase Energy | | | | | |
| 3518 | R | 4 | Int64 | Wh | Active Energy Import Phase 1 |
| 3522 | R | 4 | Int64 | Wh | Active Energy Import Phase 2 |
| 3526 | R | 4 | Int64 | Wh | Active Energy Import Phase 3 |
| Input Metering Counter | | | | | |
| 3554 | R | 4 | DATETIME | – | Input Metering Accumulation Reset Date and Time Not applicable for iEM3150 / iEM3250 |
| 3558 | R | 4 | Int64 | Unit | Input Metering Accumulation Not applicable for iEM3150 / iEM3250 |
| Energy by Tariff (iEM3155 / iEM3255only) | | | | | |
| 4191 | R/WC | 1 | UInt16 | – | MultiTariffs Energy Active Rate 0: multi tariff disabled 1 to 4: rate A to rate D NOTE: You can only set the tariff using this method if the Tariff Mode is set to by Communication. |
| 4196 | R | 4 | Int64 | Wh | Rate A Active Energy Import |
| 4200 | R | 4 | Int64 | Wh | Rate B Active Energy Import |
| 4204 | R | 4 | Int64 | Wh | Rate C Active Energy Import |
| 4208 | R | 4 | Int64 | Wh | Rate D Active Energy Import |

Overload Alarm (iEM3155 / iEM3255)

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|---------|-------|--|
| 45001 | R/WC | 1 | Bitmap | – | Overload Alarm Setup: 0x0000 = Disabled 0x0100 = Enabled |
| 45002 | R/WC | 2 | Float32 | kW | Pickup Setpoint |
| 45004 | R/WC | 1 | Bitmap | – | Digital Output to Associate: 0x0000 = Digital Output unassociated to overload alarm 0x0100 = Digital Output associated to overload alarm |
| 45005 | R | 1 | Bitmap | – | Activated Status: 0x0000 = Alarm is inactive 0x0100 = Alarm is active |

| Register Address | Action (R/W/WC) | Size | Type | Units | Description |
|------------------|-----------------|------|----------|-------|--|
| 45006 | R | 1 | Bitmap | – | Unacknowledged Status: 0x0000 = Historic alarm is acknowledged by the user 0x0100 = Historic alarm is unacknowledged by the user |
| 45007 | R | 4 | DATETIME | – | Last Alarm - Time Stamp |
| 45011 | R | 2 | Float32 | kW | Last Alarm - Value |

Read Device Identification

The energy meters supports the Read Device Identification function with the mandatory objects VendorName, ProductCode and Revision Number.

| Object ID | Name/Description | Length | Value | Note |
|-----------|--------------------|--------|--|--|
| 0x00 | VendorName | 16 | SchneiderElectric | – |
| 0x01 | ProductCode | 09 | A9MEM3100 A9MEM3110 A9MEM3115 A9MEM3150 A9MEM3155 A9MEM3200 A9MEM3210 A9MEM3215 A9MEM3250 A9MEM3255 | The ProductCode value is identical to the catalog number of each device. |
| 0x02 | MajorMinorRevision | 04 | V1.0 | Equivalent to X.Y in register 1637 |

The Read Device ID codes 01 and 04 are supported:

- 01 = request to get basic device identification (stream access)
- 04 = request to get one specific identification object (individual access)

The Modbus request and response are compliant with the Modbus Application Protocol Specification.

Chapter 6 Communications via LonWorks

What is in this chapter?

This chapter contains the following sections:

- LonWorks communications overview 63**
- LonWorks communication implementation 63**
 - External interface file (XIF) 63
 - The LonMaker plug-ins 64
 - LED indicators for LonWorks meters 64
 - Location of the service pin and Neuron ID 64
- Standard network variable types (SNVTs) and configuration properties for reading data 64**
 - General variables 65
 - System variables 65
 - Energy and energy by tariff measurements 65
 - Instantaneous (RMS) measurements 66
 - Meter status information 67
 - Resets 68
- Meter configuration properties 68**
 - Date/time setup 69
 - Basic setup 69
 - Digital input setup 69
 - Input metering setup 69
 - Overload alarm setup 70
 - Multi Tariff setup 70
 - Network propagation rate setup 70
- Echelon LonMaker plug-in for data display and meter configuration 71**
 - Installing and registering the LonMaker plug-in 71
 - Browsing the meter using the LonMaker plug-in 72
 - LonMaker plug-in interface 72

LonWorks communications overview

LonWorks communications is available on the iEM3175 and iEM3275.

The information in this section assumes that you have an advanced understanding of LonWorks communications, your communications network and the power system that your device is connected to.

Related topics

- See the LonMark International website at www.lonmark.org for more information on LonTalk protocol or LonWorks communications.

LonWorks communication implementation

External interface file (XIF)

The variables and configuration properties for the meter are documented in the external interface file (XIF). The XIF file is loaded onto the meter where your LNS (LonWorks Network Services) software can download it. You can also download the XIF file from www.schneider-electric.com if you need to manually add the XIF file to your software.

The LonMaker plug-ins

The iEM3175 and iEM3275 plug-ins allow you to configure the meter and view meter data in Echelon LonMaker.

LED indicators for LonWorks meters

The iEM3175 and iEM3275 have two LonWorks status LEDs: the red service LED and the green communications LED.

Red service LED

This LED provides the status of LonWorks operations.

| LED state | Description |
|---------------------|---|
| The LED is off | The meter is configured. It may be online or offline. |
| The LED is flashing | The meter is unconfigured but has an application. |
| The LED is on | <ul style="list-style-type: none"> The meter is unconfigured and without an application, or There is a defective internal memory issue. |

Green communications LED


This LED provides the status of the meter’s communications with the network.

| LED state | Description |
|---------------------|------------------------------|
| The LED is off | Communication is not active. |
| The LED is flashing | Communication is active. |

Location of the service pin and Neuron ID

The service pin is located on the front panel. Press this when requested by your LNS software in order to identify the meter to your LonWorks network.

You can also find the Neuron ID on the meter label if you need to manually enter it into your LNS software.



Related topics

- See “Physical description” on page 14 for the location of the communications LED.
- See “Input, output and communications wiring” on page 21 for information on wiring the device communications.
- See “Echelon LonMaker plug-in for data display and meter configuration” on page 71 for instructions on installing and using the LonMaker plug-in.

Standard network variable types (SNVTs) and configuration properties for reading data

The following sections outline the standard network variable types (SNVTs), the standard configuration property types (SCPTs), and user configuration property types (UCPTs) that you can access to read data from the meter.

Related topics

- See “Meter configuration properties” on page 68 for more information on configuring settings using LonWorks.

General variables

| Network variable label | Type | Description |
|------------------------|----------------|--------------------------------------|
| nviRequest | SCPTpartNumber | For LonWorks internal communication. |
| nvoStatus | SCPToemType | For LonWorks internal communication. |

System variables

| Network variable label | Type | Description |
|------------------------|---------------------------------|--|
| nvoFileDirectory | SNVT_address | Configuration parameter file directory address (LonMark) |
| nvoResponse | SNVT_count | Command result (LonMark) |
| nvoErrors | SNVT_state | Device error status Error bitmap: each bit of the bitmap provides error information about the device. If value of the bit = 1, that error is active. Bit0 = Code 101: EEPROM error Bit1 = Code 102: No calibration table Bit2 = Code 201: mismatch between frequency settings and frequency measurements Bit3 = Code 202: mismatch between wiring settings and wiring inputs Bit4 = Code 203: phase sequence reversed Bit5 = Not used Bit6 = Code 205: Date and time have been reset due to a power failure Bit7 = Not used Bit8 = Code 207: Abnormal internal clock function Bit9 = Internal data bus communications error Bit10 - 15: Not used |
| nciMeterModel | SNVT_str_asc (SCPTpartNumber) | Device model, stored as an ASCII string (for example, iEM3275) |
| nciMeterManf | SNVT_str_asc (SCPToemType) | Manufacturer name (Schneider Electric) |
| nciSerialNumber | SNVT_str_asc (SCPTserialNumber) | Device serial number |
| nciManfDateTime | SNVT_time_stamp (SCPTmanfDate) | Date of manufacture |
| nciDevMajVer | SCPTdevMajVer | LonWorks firmware major version (for example, 2.xx) This variable functions with nciDevMinVer to provide the device's LonWorks firmware version |
| nciDevMinVer | SCPTdevMinVer | LonWorks firmware minor version (for example, x.34) This variable functions with nciDevMajVer to provide the device's LonWorks firmware version |
| nciMeterVersion | SNVT_str_asc (UCPTMeterVersion) | Device firmware version, stored as an ASCII text string |

Related topics

- See “Troubleshooting” on page 101 for more information on the error codes.
- See “Network propagation rate setup” on page 70 for information on variables that control the network update rate.

Energy and energy by tariff measurements

Most energy values are available in both signed 32-bit integer and floating point format. The SNVT is appended with *_I* for 32-bit integer values and *_f* for floating point values.

For example, the SNVTs for total active energy import are as follows:

- 32-bit integer: SNVT_elec_kwh_I
- Floating point: SNVT_elec_whr_f

The energy and energy by tariff measurements listed below are preserved through power failures.

| Network variable label | Type | Description |
|------------------------|-----------------|---|
| nvoTotkWhImp | SNVT_elec_kwh_l | Total active energy import |
| nvoTotkWhExp | SNVT_elec_kwh_l | Total active energy export |
| nvoTotkVARhImp | SNVT_elec_kwh_l | Total reactive energy import |
| nvoTotkVARhExp | SNVT_elec_kwh_l | Total reactive energy export |
| nvoTotWhImp | SNVT_elec_whr_f | Total active energy import |
| nvoTotWhExp | SNVT_elec_whr_f | Total active energy export |
| nvoTotVARhImp | SNVT_elec_whr_f | Total reactive energy import |
| nvoTotVARhExp | SNVT_elec_whr_f | Total reactive energy export |
| nvoPartialkWh | SNVT_elec_kwh_l | Partial active energy import |
| nvoPartialkVARh | SNVT_elec_kwh_l | Partial reactive energy import |
| nvoPartialWh | SNVT_elec_whr_f | Partial active energy import |
| nvoPartialVARh | SNVT_elec_whr_f | Partial reactive energy import |
| nvoPh1kWh | SNVT_elec_kwh_l | Active energy import phase 1 |
| nvoPh2kWh | SNVT_elec_kwh_l | Active energy import phase 2 |
| nvoPh3kWh | SNVT_elec_kwh_l | Active energy import phase 3 |
| nvoPh1Wh | SNVT_elec_whr_f | Active energy import phase 1 |
| nvoPh2Wh | SNVT_elec_whr_f | Active energy import phase 2 |
| nvoPh3Wh | SNVT_elec_whr_f | Active energy import phase 3 |
| nvoTariffActRate | SNVT_count | Active tariff 0 = Multi Tariff feature is disabled 1 = rate A (tariff 1) active 2 = rate B (tariff 2) active 3 = rate C (tariff 3) active 4 = rate D (tariff 4) active |
| nvoTariffAkWh | SNVT_elec_kwh_l | Rate A (tariff 1) active energy import |
| nvoTariffBkWh | SNVT_elec_kwh_l | Rate B (tariff 2) active energy import |
| nvoTariffCkWh | SNVT_elec_kwh_l | Rate C (tariff 3) active energy import |
| nvoTariffDkWh | SNVT_elec_kwh_l | Rate D (tariff 4) active energy import |
| nvoTariffAWh | SNVT_elec_whr_f | Rate A (tariff 1) active energy import |
| nvoTariffBWh | SNVT_elec_whr_f | Rate B (tariff 2) active energy import |
| nvoTariffCWh | SNVT_elec_whr_f | Rate C (tariff 3) active energy import |
| nvoTariffDWh | SNVT_elec_whr_f | Rate D (tariff 4) active energy import |
| nvoInMeterAcc | SNVT_count_f | Input metering accumulation |
| nvoRstEnergyDT | SNVT_time_stamp | Date and time of last energy reset |

Related topics

- See “Resets” on page 68 for information on resetting values.
- See “Network propagation rate setup” on page 70 for information on variables that control the network update rate.

Instantaneous (RMS) measurements

| Network variable label | Type | Description |
|------------------------|--------------|---------------------------------|
| nvoActPowerPh1 | SNVT_power_f | Active power Phase 1 |
| nvoActPowerPh2 | SNVT_power_f | Active power Phase 2 |
| nvoActPowerPh3 | SNVT_power_f | Active power Phase 3 |
| nvoActPowerSum | SNVT_power_f | Total active power |
| nvoRctPowerSum | SNVT_power_f | Total reactive power |
| nvoAppPowerSum | SNVT_power_f | Total apparent power |
| nvoVoltsL1N | SNVT_volt_f | Voltage L1-N |
| nvoVoltsL2N | SNVT_volt_f | Voltage L2-N |
| nvoVoltsL3N | SNVT_volt_f | Voltage L3-N |
| nvoVoltsLNAvg | SNVT_volt_f | Average voltage line-to-neutral |
| nvoVoltsL1L2 | SNVT_volt_f | Voltage L1-L2 |
| nvoVoltsL2L3 | SNVT_volt_f | Voltage L2-L3 |
| nvoVoltsL3L1 | SNVT_volt_f | Voltage L3-L1 |
| nvoVoltsLLAvg | SNVT_volt_f | Average voltage line-to-line |
| nvoCurrentPh1 | SNVT_amp_f | Phase 1 current |

| Network variable label | Type | Description |
|------------------------|------------------|--------------------|
| nvoCurrentPh2 | SNVT_amp_f | Phase 2 current |
| nvoCurrentPh3 | SNVT_amp_f | Phase 3 current |
| nvoCurrentAvg | SNVT_amp_f | Average current |
| nvoAvgPwrFactor | SNVT_count_inc_f | Total power factor |
| nvoFrequency | SNVT_freq_f | Frequency |

Related topics

- See “Network propagation rate setup” on page 70 for information on variables that control the network update rate.

Meter status information

You can read the following network variables to obtain configuration and status information about the meter. For information on configuring the meter, see the sections on meter configuration properties and the LonWorks plug-in.

| Network variable label | SNVT / UCPT type | Description |
|--|------------------|--|
| Basic information and meter configuration | | |
| nvoDateTime | SNVT_time_stamp | Meter date and time (DD/MM/YYYY hh:mm:ss) |
| nvoOpTimer | SNVT_count_32 | Meter operation timer: the time in seconds since the meter was last powered up |
| System configuration information | | |
| nciSystemType | SNVT_count | Power system configuration: 0 = 1PH2W L-N 1 = 1PH2W L-L 2 = 1PH3W L-L with N 3 = 3PH3W 11 = 3PH4W 13 = 1PH4 wire multi L-N |
| nciWireNum | SNVT_count | Number of wires 2, 3, 4 |
| nciPhaseNum | SNVT_count | Number of phases 1, 3 |
| nciCtNum | SNVT_count | Number of CTs 1, 2, 3 NOTE: only applies to the iEM3275 |
| nciVtNum | SNVT_count | Number of VTs 0-10 NOTE: only applies to the iEM3275 |
| nciVtPrimary | SNVT_count_32 | VT Primary NOTE: only applies to the iEM3275 |
| nciVTSecondary | SNVT_count | VT Secondary NOTE: only applies to the iEM3275 |
| nciCtPrimary | SNVT_count | CT Primary NOTE: only applies to the iEM3275 |
| nciCtSecondary | SNVT_count | CT Secondary NOTE: only applies to the iEM3275 |
| nciVtConnType | SNVT_count | VT connection type 0 = Direct connection, no VTs 1 = 3PH3W (2VTs) 2 = 3PH4W (3VTs) |
| nciNominalFreq | SNVT_freq_hz | System frequency 50, 60 |

| Network variable label | SNVT / UCPT type | Description |
|---|------------------|--|
| Digital input configuration and status information | | |
| nciDICtrMode | SNVT_count | Digital input control mode 0 = Normal (input status) 2 = Multi Tariff control 3 = Input metering 5 = All partial energy reset (configure to reset all partial energy logs) |
| nciDIPulseConst | SNVT_count_32 | Pulse constant (pulses/unit) |
| nvoDIStatus | SNVT_count | Digital input status (only Bit 1 is used) 0 = relay open 1 = relay closed NOTE: The information provided by this variable only applies if the digital input control mode is set to Input Status. |
| Alarm status | | |
| nvoAlmStatus | SNVT_count | Alarm status (only Bit 1 is used) 0 = Alarm is inactive 1 = Alarm is active |
| nvoAlmUnAckState | SNVT_count | Acknowledgement status (only Bit 1 is used): 0 = historic alarm is acknowledged by the user 1 = historic alarm is unacknowledged by the user |
| nvoAlmLastTime | SNVT_time_stamp | Timestamp of last alarm (DD/MM/YYYY hh:mm:ss) |
| nvoAlmLastValue | SNVT_power_f | Value at last alarm |
| nciAlmEnable | SNVT_count | Overload alarm configuration: 0 = disabled 1 = enabled |
| nciAlmPkUpSetPt | SNVT_power_f | Active power alarm pickup setpoint in kW |

Related topics

- See “Meter configuration properties” on page 68 for information on SCPTs and UCPTs that you can use to configure the meter.
- See “Echelon LonMaker plug-in for data display and meter configuration” on page 71 for instructions on using the LNS plug-in to configure the meter.

Resets

| Network variable label | Type | Description | Action |
|------------------------|-------------|--|-------------------------------------|
| nciRstPartEnergy | SNVT_switch | Resets all partial energy accumulators to 0: <ul style="list-style-type: none"> • Partial active energy import (nvoPartialkWh, nvoPartialWh) • Partial reactive energy import (nvoPartialkVARh, nvoPartialVARh) • Rate A active energy import (nvoTariffAkWh, nvoTariffAWh) • Rate B active energy import (nvoTariffBkWh, nvoTariffBWh) • Rate C active energy import (nvoTariffCkWh, nvoTariffCWh) • Rate D active energy import (nvoTariffDkWh, nvoTariffDWh) • Active energy import phase 1 (nvoPh1kWh, nvoPh1Wh) • Active energy import phase 2 (nvoPh2kWh, nvoPh2Wh) • Active energy import phase 3 (nvoPh3kWh, nvoPh3Wh) | To reset, set the state field to 1. |
| nciRstInMeterAcc | SNVT_switch | Resets input metering accumulation (nvolnMeterAcc) to 0 | To reset, set the state field to 1. |

Meter configuration properties

You can configure the meter using the configuration properties listed in this section. However, it is recommended that you use the Echelon LonMaker plug-in if you are configuring the meter using LonWorks communications.

NOTE: If Com. Protection is enabled, you may receive an error response when you try to configure the meter over communications.

Related topics

- See “Com. Protection setting” on page 35 for more information on the Com. Protection feature.
- See “Echelon LonMaker plug-in for data display and meter configuration” on page 71 for instructions on using the LNS plug-in to configure the device.

Date/time setup

| Function profile | UCPT | Struct Members | Range / options |
|------------------|--------------|----------------|-----------------|
| nciCfgDateTime | UCPTDateTime | year | 2000 - 2099 |
| | | month | 1 - 12 |
| | | day | 1 - 31 |
| | | hour | 0 - 23 |
| | | minute | 0 - 59 |
| | | second | 0 - 59 |

Basic setup

| Function profile | UCPT | Struct Members | Range / options | Description |
|------------------|------------|----------------|--------------------|--|
| nciCfgWiring | UCPTWiring | SystemType | 0, 1, 2, 3, 11, 13 | 0 = 1PH2W L-N 1 = 1PH2W L-L 2 = 1PH3W L-L with N 3 = 3PH3W 11 = 3PH4W 13 = 1PH4 wire multi L with N |
| | | NominFreq | 50, 60 | Nominal frequency in Hz |
| | | VtPrimary | 0 - 1000000.0 | The minimum value for VtPrimary must be equal to or greater than the value set for VtSecondary. |
| | | VtSecondary | 100, 110, 115, 120 | — |
| | | CtNum | 1, 2, 3 | — |
| | | CtPrimary | 1 - 32767 | — |
| | | CtSecondary | 1, 5 | — |
| | | VtConnType | 0, 1, 2 | VT connection type 0 = Direct connection 1 = 3PH3W (2VTs) 2 = 3PH4W (3VTs) |

Digital input setup

| Function profile | UCPT | Struct Members | Range / options | Description |
|------------------|------------------|----------------|-----------------|---|
| nciCfgDigitInpt | UCPTDigitalInput | — | 0, 1 | Associates the digital input to reset partial energy data: 0 = Digital input is not associated with the partial energy reset. 1 = Digital input is associated with the partial energy reset. Setting this property to 1 also updates nciDICTrlMode (UCPTDiCtrlMode) to All Energy Reset. |

Input metering setup

| Function profile | UCPT | Struct Members | Range / options | Description |
|------------------|-------------------|--------------------|-----------------|--|
| nciCfgInptMetAcc | UCPTInputMetering | PulseWeight | 1 - 10000 | Sets the pulse weight (1 - 10000 ms) Setting this property also sets nciDIPulseConst (UCPTDiPulseConst) to the same value. |
| | | DigitalAssociation | 0, 1 | Associates the digital input with input metering: 0 = Digital input is not associated with input metering. 1 = The digital input is associated with input metering. Setting this property to 1 also updates nciDICTrlMode (UCPTDiCtrlMode) to Input Metering. |

Overload alarm setup

| Function profile | UCPT | Struct Members | Range / options | Description |
|------------------|--------------------|----------------|-----------------|--|
| nciCfgOvLoadAlm | UCPTOverLoadAlarm | AlmEnable | 0, 1 | Enable or disable the overload alarm: 0 = Disabled 1 = Enabled |
| | | PkUpSetpoint | 1 - 9999999 | The pickup value for the overload alarm |
| nciCfgOvLoadAck | UCPTOverLoadAlmAck | — | 0, 1 | Acknowledgement status (only Bit 1 is used): 0 = historic alarm is acknowledged by the user 1 = historic alarm is unacknowledged by the user |

Multi Tariff setup

| Function profile | UCPT | Struct Members | Range / options | Description |
|------------------|------------------|----------------|-----------------|---|
| nciCfgCommTariff | UCPTTariffMode | — | 0, 1 | Set Multi Tariff control mode to Disabled or by Communication 0 = Disabled 1 = by Communication NOTE: To configure the Multi Tariff feature to be controlled by the digital input or device clock, use the HMI. |
| nciCfgTariffSel | UCPTTariffSelect | — | 1, 2, 3, 4 | Set the active tariff 1 = Rate A (tariff 1) 2 = Rate B (tariff 2) 3 = Rate C (tariff 3) 4 = Rate D (tariff 4) NOTE: You can only set the tariff using this method if the Tariff Mode is set to by Communication. |

Network propagation rate setup

The following configuration properties help control network traffic by controlling the rate at which variable values are sent to your LNS.

| nci variable | UCPTs/SCPTs | Applies to... | Description |
|-------------------|-----------------|--|---|
| nciMaxNvSntPerSec | UCPTNVUptLimit | <ul style="list-style-type: none"> nciErrors nciAllEnergy nciAllPower nciAllVoltage nciAllCurrent nciAllPowerFactor nciFrequency. | Limits the total number of updates sent per second for listed nci variables. If more than the specified number of updates are queued to be sent out in any 1 second period, the excess updates are delayed until the next second to reduce network traffic. The number of updates sent per second varies depending on the connection type updates from network variables that are not controlled by this configuration property. |
| nciErrors | SCPTmaxSendTime | <ul style="list-style-type: none"> nvoErrors | Maximum interval, in seconds, between transmissions of error values to the network. The value of the applicable variable is sent after the interval has elapsed, regardless of whether or not the value of the variable has changed. The counter is reset to 0. |

| nci variable | UCPTs/SCPTs | Applies to... | Description |
|-------------------|-----------------|--|---|
| nciAllEnergy | SCPTminSendTime | Floating-point energy values: <ul style="list-style-type: none"> nvoTotWhImp nvoTotWhExp nvoTotVARhImp nvoTotVARhExp nvoPartialWh nvoPartialVARh nvoPh1Wh nvoPh2Wh nvoPh3Wh nvoTariffAWh nvoTariffBWh nvoTariffCWh nvoTariffDWh | The minimum interval, in seconds, between consecutive transmissions of the listed variable values to the network. No updates to the value of the applicable variables are sent over the network until the minimum interval has elapsed, regardless of whether or not the value of the variable has changed. After an update is sent, the counter is reset to 0. |
| nciAllPower | SCPTminSendTime | <ul style="list-style-type: none"> nvoActPowerPh1 nvoActPowerPh2 nvoActPowerPh3 nvoActPowerSum nvoRctPowerSum nvoAppPowerSum | |
| nciAllVoltage | SCPTminSendTime | <ul style="list-style-type: none"> nvoVoltsL1N nvoVoltsL2N nvoVoltsL3N nvoVoltsLNAvg nvoVoltsL1L2 nvoVoltsL2L3 nvoVoltsL3L1 nvoVoltsLLAvg | |
| nciAllCurrent | SCPTminSendTime | <ul style="list-style-type: none"> nvoCurrentPh1 nvoCurrentPh2 nvoCurrentPh3 nvoCurrentAvg | |
| nciAllPowerFactor | SCPTminSendTime | <ul style="list-style-type: none"> nvoAvgPwrFactor | |
| nciFrequency | SCPTminSendTime | <ul style="list-style-type: none"> nvoFrequency | |

Echelon LonMaker plug-in for data display and meter configuration

The information in this section assumes that you have an advanced understanding of system administration using Echelon LonMaker.

The LonMaker plug-in provides a graphical user interface where you can view meter values and configure meter settings. Once you install and register the plug-in with LonMaker, it opens instead of the default LonMaker browser when you browse the meter in LonMaker.

To add devices to LonMaker, you need access to the device service pin when commissioning the device or your need the device Neuron ID recorded in an accessible location.

Related topics

- Refer to <http://www.echelon.com/products/tools/integration/lonmaker/> and the LonMaker documentation for more information on using LonMaker.
- See “Location of the service pin and Neuron ID” on page 64 for the location of the service pin and Neuron ID.

Installing and registering the LonMaker plug-in

Before you install the plug-in:

- Download the plug-in and XIF file for your device from www.schneider-electric.com or contact your sales representative to obtain these files.
- Make sure Echelon LonMaker is closed.

- Navigate to the location where you saved the plug-in. Extract the files if they are in a .zip file.
- Double-click setup.exe. A welcome screen appears. Click **Next**.
- Select the installation folder where you want to install the plug-in. Click **Browse** if you want to select a different location. Click **Next**. A confirmation screen appears.
- Click **Next** to begin the installation.

NOTE: If LonMaker is open, a message appears instructing you to close LonMaker and restart the plug-in installation.

A screen appears when the installation is complete. Click **Close**.

5. Navigate to **Start > Programs > Schneider Electric** and select the registration entry for the plug-in you installed (for example, **Schneider Electric iEM3275 Plugin Registration**). The **LNS Plugin Registration** dialog box appears, indicating that registration is complete.

Make sure that the plug-in appears in the list of registered plug-ins in LonMaker before you try to connect to a meter using the plug-in. If it does not appear, you may need to re-register the plug-in.

Once the plug-in is installed and registered, add the meter to LonMaker. You can either read the template (.XIF) from the device during commissioning or select the EnergyMeter5A or EnergyMeter63A template when you add the device to LonMaker.

Related topics

- Refer to the Echelon LonMaker documentation for information on registering the plug-in.

Browsing the meter using the LonMaker plug-in


In order to use the plug-in to view data and configure the meter:

- The plug-in must be installed and registered.
- The meter must be added to LonMaker and commissioned.

1. Open LonMaker.
2. Right-click the meter icon and select **Browse**. The meter plug-in appears.

NOTE: If the meter-specific plug-in does not open, the plug-in may not be correctly registered or the meter may not be properly commissioned in LonMaker. Double-check the registration and meter commissioning. Refer to the Echelon LonMaker documentation for more information.

LonMaker plug-in interface



The plug-in has the following tabs:

| Tab name | Description |
|----------------|---|
| Meter Info | This tab provides basic information about the meter (for example, model and serial number) and any active error codes. |
| Energy Measure | This tab provides total and partial energy values as well as energy per phase and energy by tariff information. You can also reset energy and input metering accumulations on this tab. |
| RMS Measure | This tab provides power, current, and voltage values as well as frequency and power factor information. |

| Tab name | Description |
|--------------|---|
| Meter Status | This tab provides information on the settings and status of the digital input and alarms as well as existing power system settings. |
| Meter Config | This tab provides access to the meter configuration properties, allowing you to configure power system, digital input, alarm, Multi Tariff and time settings. NOTE: If you see a message that the configuration was unsuccessful, make sure: 1) the meter is properly commissioned in LonMaker and the plug-in is communicating with the meter, and 2) that Com. Protection is disabled on the meter. |
| Diagnostics | This tab provides LonMaker diagnostics information related to the meter. |

Chapter 7 Communications via M-Bus

What is in this chapter?

This chapter contains the following sections:

- M-Bus communications overview** 75
- M-Bus protocol support** 76
- M-Bus protocol implementation** 76
 - M-Bus tool for viewing data and configuring the meter 76
 - Communications LED indicator for M-Bus meters 77
- Variable data structure telegram information** 77
 - Fixed data header 77
 - Data record header information 77
- Telegram information for data records** 79
 - Meter information 79
 - Energy and energy by tariff measurements 79
 - Instantaneous measurements 80
 - Meter status information 80
- Telegram information for meter configuration** 82
- M-Bus tool for data display and meter configuration** 85
 - Installing the M-Bus tool 85
 - Accessing the meter using the tool 86
 - Viewing meter data using the M-Bus tool 86
 - Configuring the meter using the M-Bus tool 87

M-Bus communications overview

M-Bus is a master / slave communications protocol where the master initiates transactions and the slave(s) respond with the requested information or action. Data is transferred using hexadecimal telegrams.

Communications via M-Bus protocol is available on the iEM3135 and iEM3235.

The information in this section is intended for users with an advanced understanding of M-Bus protocol, their communications network and their power system.

Configuring basic communications settings

Before communicating with the meter via M-Bus protocol, use the HMI to configure the following settings:

| Setting | Possible values |
|-----------------|-----------------|
| Baud rate | 300 |
| | 600 |
| | 1200 |
| | 2400 |
| | 4800 |
| | 9600 |
| Primary address | 1–250 |

Key terms

| Term | Definition |
|-------------------|--|
| C-Field | The control or function field of the telegram. It provides information about the telegram, such as the direction of data flow (master to slave or slave to master), the status of the data flow and the function of the message. |
| CI-Field | The control information field of the telegram. It defines the type and sequence of data to be transmitted. |
| Fixed data header | Contains device and manufacturer identification information. |
| DIF | Data information field. The DIF contains information about the function of the data (for example, instantaneous versus maximum) and the data format (for example, 16-bit integer). |
| DIFE | Data information field extension. A DIFE contain additional information about the data, such as tariff and subunit. |
| Master | A device that issues commands and receives responses from slave devices. There can be only one master per serial network. |
| Slave | A device that provides information or performs actions in response to requests from the master. |
| VIF / VIFE | Value information field and value information field extension. The VIF and VIFE contain information about the value (for example, whether it is an energy or power value). The meter uses both primary VIFE (as detailed in the M-Bus protocol documentation) and manufacturer-specific VIFE. |

Related topics

- See the M-Bus organization website at www.m-bus.com for more information on the M-bus protocol.
- See “Physical description” on page 14 for the location of the communications LED.
- See “Communications setup” on page 84 for information on setting the baud rate using a telegram.

M-Bus protocol support

The meter supports the M-Bus protocol as follows:

- Mode 1 communications (least significant bit first).
- Telegram formats:
 - Single character
 - Short frame
 - Long frame
- Function codes (C-field bits 3-0):
 - SND_NKE: Initiates of communications between the master and slave.
 - SND_UD: The master sends user data to the slave.
 - REQ_UD2: The master requests Class 2 user data from the slave.
 - RSP_UD: The slave sends requested data to the master.
- Secondary addressing in accordance with the M-Bus standard.
- Broadcast telegrams.

Related topics

- See the M-Bus organization website at www.m-bus.com for more information on the M-Bus protocol, including secondary addressing procedures.
- See “Fixed data header” on page 77 for the meter-specific information required for secondary addressing (for example, identification number, manufacturer and medium).

M-Bus protocol implementation

M-Bus tool for viewing data and configuring the meter

The M-Bus tool provides a graphical user interface where you can view meter data and configure meter settings. To obtain the tool, go to www.schneider-electric.com and search for your meter model then select Downloads or contact your local Schneider Electric representative.

Communications LED indicator for M-Bus meters

The communications LED indicates the status of the communications between the meter and the network as follows:

| LED state | Description |
|---------------------|--|
| The LED is flashing | Communication with the meter has been established. NOTE: The LED flashes even if there is a communications error. |
| The LED is off | There is no active communication. |

Related topics

- See “Physical description” on page 14 for the location of the communications LED.
- See “M-Bus tool for data display and meter configuration” on page 85 for information on obtaining and using the M-Bus tool.

Variable data structure telegram information

Fixed data header

| Byte 1-4 Identification No. | Byte 5-6 Manufacturer | Byte 7 Version | Byte 8 Medium | Byte 9 Access No. | Byte 10 Status | Byte 11-12 Signature |
|---|----------------------------------|--|----------------------|---------------------------------------|------------------------------------|-------------------------|
| Serial number of the meter in an 8-digit, BCD coded format The serial number can also be found on the meter front panel. | 4CA3 hex = Schneider Electric | Firmware version of the communications board 10 = version 1.0 | 02 hex (electricity) | Counter of successful access attempts | Indicates M-Bus application errors | Not used |

Data record header information

Data formats used by the meter (DIF bits 3-0)

NOTE: x in the hex value is determined by bits 7-4 of the DIF.

| Format | bin | hex |
|-----------------|------|-----|
| No data | 0000 | x0 |
| 8-bit integer | 0001 | x1 |
| 16-bit integer | 0010 | x2 |
| 24-bit integer | 0011 | x3 |
| 32-bit integer | 0100 | x4 |
| 32-bit real | 0101 | x5 |
| 48-bit integer | 0110 | x6 |
| 64-bit integer | 0111 | x7 |
| Variable length | 1101 | xD |

Data function types used by the meter (DIF bits 5-4)

| Function type | bin |
|---------------|-----|
| Instantaneous | 00 |
| Maximum | 01 |

Primary VIF used by the meter

NOTE: E denotes the extension bit; x in the hex value is determined by bits 7-4 of the VIF.

| Primary VIF | bin | hex | Description |
|-------------|-----------|-----|---|
| Energy | E000 0011 | x3 | Wh with a resolution of 10 ⁰ |
| Power | E000 1110 | xE | kW with a resolution of 10 ³ |
| Time point | E110 1101 | xD | Date and time in data type F, as detailed in the M-Bus protocol documentation |
| Bus address | E111 1010 | xA | Data type C (unsigned integer), as detailed in the M-Bus protocol documentation |

| Primary VIF | bin | hex | Description |
|----------------------------|-----------|-----|--|
| Primary VIFE | 1111 1101 | FD | Indicates that the first VIFE is a primary VIF extension |
| Manufacturer-specific VIFE | 1111 1111 | FF | Indicates that the next VIFE is manufacturer specific |

Primary VIFE codes used by the meter

The primary VIFE codes in the table below are used by the meter when the VIF equals FD hex (1111 1101 bin).

NOTE: E denotes the extension bit; x in the hex value is determined by bits 7-4 of the VIFE.

| Primary VIFE codes | bin | hex | Additional information |
|--------------------|-----------|-----|--|
| Manufacturer | E000 1010 | xA | — |
| Model | E000 1100 | xC | — |
| Voltage | E100 1001 | x9 | Volts with a resolution of 10 ⁰ |
| Current | E101 1100 | xC | Amps with a resolution of 10 ⁰ |
| Digital output | E001 1010 | xA | — |
| Digital input | E001 1011 | xB | — |
| Cumulation counter | E110 0001 | x1 | Input metering accumulation |
| Error flag | E001 0111 | x7 | — |

Manufacturer-specific VIFE codes

The manufacturer-specific VIFE codes in the table below are used by the meter when the VIF equals FF hex (1111 1111 bin).

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Description | bin | hex |
|---|-----------|-----|
| L1 value | E000 0001 | 01 |
| L2 value | E000 0010 | 02 |
| L3 value | E000 0011 | 03 |
| Export energy value | E000 1001 | 09 |
| Partial energy value | E000 1101 | 0D |
| Average current | E000 0000 | 00 |
| L-N Avg | E000 0100 | 04 |
| L1-L2 | E000 0101 | 05 |
| L2-L3 | E000 0110 | 06 |
| L3-L1 | E000 0111 | 07 |
| L-L Avg | E000 1000 | 08 |
| Power Factor | E000 1010 | 0A |
| Frequency | E000 1011 | 0B |
| Energy reset date and time | E000 1100 | 0C |
| Input metering reset date and time | E000 1110 | 0E |
| Input metering accumulation | E000 1111 | 0F |
| Active tariff (Energy active rate) | E001 0000 | 10 |
| Tariff control mode | E001 0001 | 11 |
| Meter operation timer | E010 0000 | 20 |
| Number of phases | E010 0001 | 21 |
| Number of wires | E010 0010 | 22 |
| Power system configuration | E010 0011 | 23 |
| Nominal frequency | E010 0100 | 24 |
| Number of VTs | E010 0101 | 25 |
| VT primary | E010 0110 | 26 |
| VT secondary | E010 0111 | 27 |
| Number of CTs | E010 1000 | 28 |
| CT Primary | E010 1001 | 29 |
| CT Secondary | E010 1010 | 2A |
| VT connection type | E010 1011 | 2B |
| Energy pulse duration | E010 1100 | 2C |
| Digital output association with active energy pulsing | E010 1101 | 2D |

| Description | bin | hex |
|--|-----------|-----|
| Pulse weight | E010 1110 | 2E |
| Pulse constant | E010 1111 | 2F |
| Digital input association | E011 0000 | 30 |
| Digital input status | E011 0010 | 32 |
| Overload alarm setup | E011 0100 | 34 |
| Pickup setpoint | E011 0101 | 35 |
| Digital output association with overload alarm | E011 0110 | 36 |
| Activated status | E011 0111 | 37 |
| Acknowledgement | E011 1000 | 38 |
| Date and time of last alarm | E011 1001 | 39 |
| Value at last alarm | E011 1010 | 3A |

Telegram information for data records

The following sections outline the telegram information used in data records. The tables contain the following information (if applicable):

- Data format in hex (for example, 16-bit integer)
- Primary VIF in hex
- Primary VIFE codes in bin and hex
- Manufacturer-specific VIFE codes in bin and hex

Meter information

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Data format | Primary VIF Extension | | Description |
|-------------|-----------------------|-----|--|
| | bin | hex | |
| 0D | E000 1010 | 0A | Manufacturer 18-bit ASCII = Schneider Electric |
| 0D | E000 1100 | 0C | Model |
| 03 | E0001 0111 | 17 | Meter error codes: 0 = Code 101: EEPROM error 1 = Code 102: No calibration table 2 = Code 201: Mismatch between frequency settings and frequency measurements 3 = Code 202: Mismatch between wiring settings and wiring inputs 4 = Code 203: Phase sequence reversed 5 = Code 204: Total active energy negative due to incorrect voltage or current connections 6 = Code 205: Date and time are reset due to a power failure 7 = Code 206: Pulse missing due to overspeed of energy pulse output 8 = Code 207: Abnormal internal clock function 9 = Internal data bus communications error |

Related topics

- See “Troubleshooting” on page 101 for more information on the diagnostics codes.

Energy and energy by tariff measurements

The energy and energy by tariff measurements listed below are preserved through power failures.

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Data format | DIFE | Primary VIF | Primary VIFE | | Manufacturer-specific VIFE | | Description |
|-------------|------|-------------|--------------|-----|----------------------------|-----|------------------------------|
| | | | bin | hex | bin | hex | |
| 07 | — | 03 | — | — | — | — | Total active energy import |
| 07 | — | 83 | — | — | E000 1001 | 09 | Total active energy export |
| 87 | 40 | 03 | — | — | — | — | Total reactive energy import |
| 87 | 40 | 83 | — | — | E000 1001 | 09 | Total reactive energy export |

| Data format | DIFE | Primary VIF | Primary VIFE | | Manufacturer-specific VIFE | | Description |
|-------------|-------|-------------|--------------|-----|----------------------------|-----|---|
| | | | bin | hex | bin | hex | |
| 07 | — | 83 | — | — | E000 1101 | 0D | Partial active energy import |
| 87 | 40 | 83 | — | — | E000 1101 | 0D | Partial reactive energy import |
| 07 | — | 83 | — | — | E000 0001 | 01 | Active energy import phase 1 |
| 07 | — | 83 | — | — | E000 0010 | 02 | Active energy import phase 2 |
| 07 | — | 83 | — | — | E000 0011 | 03 | Active energy import phase 3 |
| 03 | — | — | — | — | E001 0000 | 10 | Active tariff 0 = Multi Tariff feature is disabled 1 = rate A (tariff 1) active 2 = rate B (tariff 2) active 3 = rate C (tariff 3) active 4 = rate D (tariff 4) active |
| 87 | 10 | 03 | — | — | — | — | Rate A (tariff 1) active energy import |
| 87 | 20 | 03 | — | — | — | — | Rate B (tariff 2) active energy import |
| 87 | 30 | 03 | — | — | — | — | Rate C (tariff 3) active energy import |
| 87 | 80 10 | 03 | — | — | — | — | Rate D (tariff 4) active energy import |
| 07 | — | — | E110 0001 | 61 | — | — | Input metering accumulation |
| 04 | — | ED | — | — | E000 1100 | 0C | Date and time of last partial energy reset |
| 04 | — | ED | — | — | E000 1110 | 0E | Date and time of last input metering reset |

Instantaneous measurements

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Data format | DIFE | Primary VIF | Primary VIFE | | Manufacturer-specific VIFE | | Description |
|-------------|-------|-------------|--------------|-----|----------------------------|-----|---------------------------------|
| | | | bin | hex | bin | hex | |
| 05 | — | AE | — | — | E000 0001 | 01 | Active power Phase 1 |
| 05 | — | AE | — | — | E000 0010 | 02 | Active power Phase 2 |
| 05 | — | AE | — | — | E000 0011 | 03 | Active power Phase 3 |
| 05 | — | 2E | — | — | — | — | Total active power |
| 85 | 40 | 2E | — | — | — | — | Total reactive power |
| 85 | 80 40 | 2E | — | — | — | — | Total apparent power |
| 05 | — | — | E100 1001 | C9 | E000 0001 | 01 | Voltage L1-N |
| 05 | — | — | E100 1001 | C9 | E000 0010 | 02 | Voltage L2-N |
| 05 | — | — | E100 1001 | C9 | E000 0011 | 03 | Voltage L3-N |
| 05 | — | — | E100 1001 | C9 | E000 0100 | 04 | Average voltage line-to-neutral |
| 05 | — | — | E100 1001 | C9 | E000 0101 | 05 | Voltage L1-L2 |
| 05 | — | — | E100 1001 | C9 | E000 0110 | 06 | Voltage L2-L3 |
| 05 | — | — | E100 1001 | C9 | E000 0111 | 07 | Voltage L3-L1 |
| 05 | — | — | E100 1001 | C9 | E000 1000 | 08 | Average voltage line-to-line |
| 05 | — | — | E101 1100 | DC | E000 0001 | 01 | Phase 1 current |
| 05 | — | — | E101 1100 | DC | E000 0010 | 02 | Phase 2 current |
| 05 | — | — | E101 1100 | DC | E000 0011 | 03 | Phase 3 current |
| 05 | — | — | E101 1100 | DC | E000 0000 | 00 | Average current |
| 05 | — | — | — | — | E000 1010 | 0A | Total power factor |
| 05 | — | — | — | — | E000 1011 | 0B | Frequency |

Meter status information

Use the following information to read system and status information from the meter. See the section regarding telegram information for meter configuration for more information on writing to the meter.

Date and time information

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Data format | Primary VIF | Manufacturer-specific VIFE | | Description |
|-------------|-------------|----------------------------|-----|---|
| | | bin | hex | |
| 04 | 6D | — | — | Meter date and time (DD/MM/YYYY hh:mm:ss) |
| 06 | — | E010 0000 | 20 | Meter operation timer: the time in seconds since the device was last powered up |

Power system configuration information

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Data format | Manufacturer-specific VIFE | | Description |
|-------------|----------------------------|-----|---|
| | bin | hex | |
| 03 | E010 0011 | 23 | Power system configuration: 0 = 1PH2W L-N 1 = 1PH2W L-L 2 = 1PH3W L-L with N 3 = 3PH3W 11 = 3PH4W 13 = 1PH4 wire multi L with N |
| 03 | E010 0010 | 22 | Number of wires 2, 3, 4 |
| 03 | E010 0001 | 21 | Number of phases 1, 3 |
| 03 | E010 1000 | 29 | Number of CTs 1, 2, 3 NOTE: only applies to the iEM3235 |
| 03 | E010 0101 | 25 | Number of VTs 0-10 NOTE: only applies to the iEM3235 |
| 05 | E010 0110 | 26 | VT Primary NOTE: only applies to the iEM3235 |
| 03 | E010 0111 | 27 | VT Secondary NOTE: only applies to the iEM3235 |
| 03 | E010 1001 | 29 | CT Primary NOTE: only applies to the iEM3235 |
| 03 | E010 1010 | 2A | CT Secondary NOTE: only applies to the iEM3235 |
| 03 | E010 1011 | 2B | VT connection type 0 = Direct connection, no VTs 1 = 3PH3W (2VTs) 2 = 3PH4W (3VTs) |
| 03 | E010 0100 | 24 | Nominal frequency 50, 60 |

Digital input and output status information

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Data format | Primary VIFE | | Manufacturer-specific VIFE | | Description |
|-------------|--------------|-----|----------------------------|-----|---|
| | bin | hex | bin | hex | |
| 03 | E001 1011 | 1B | — | — | Digital input control mode: 0 = Normal (Input Status) 2 = Multi Tariff control 3 = Input metering 5 = All partial energy logs reset |
| 05 | — | — | E010 1111 | 2F | Pulse constant (pulses/unit) |

| Data format | Primary VIFE | | Manufacturer-specific VIFE | | Description |
|-------------|--------------|-----|----------------------------|-----|--|
| | bin | hex | bin | hex | |
| 02 | — | — | E011 0010 | 32 | Digital input status: 0 = relay open 1 = relay closed NOTE: This information only applies if the digital input control mode is set to Input Status. |
| 03 | — | — | E011 0000 | 30 | Digital input association with partial energy data reset 0 = Digital input is not associated with the partial energy reset 1 = Digital input is associated with the partial energy reset |
| 03 | — | — | E010 1100 | 2C | Energy pulse duration in milliseconds NOTE: This information only applies if the digital output mode is set to energy pulsing. |
| 05 | — | — | E010 1110 | 2E | Pulse weight of the digital output NOTE: This information only applies if the digital output mode is set to energy pulsing. |
| 03 | E001 1010 | 1A | — | — | Digital output control mode 2 = for Alarm 3 = for Pulse (kWh) 0xFFFF = Disabled |
| 03 | — | — | E010 1101 | 2D | Digital output association with energy pulsing: 0 = Digital output disabled 1 = for Pulse (digital output is associated with active energy pulse output) |
| 02 | — | — | E011 0110 | 36 | Digital output association with overload alarm: 0x0000 = digital output disabled 0x0100 = for Alarm (digital output is associated with the overload alarm) |

Alarm status information

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| Data format | Primary VIF | Manufacturer-specific VIFE | | Description |
|-------------|-------------|----------------------------|-----|---|
| | | bin | hex | |
| 02 | — | E011 0111 | 37 | Alarm status: 0x0000 = Alarm is inactive 0x0100 = Alarm is active |
| 02 | — | E011 1000 | 38 | Acknowledgement status: 0x0000 = historic alarm is acknowledged by the user 0x0100 = historic alarm is unacknowledged by the user |
| 04 | ED | E011 1001 | 39 | Timestamp of last alarm (DD/MM/YYYY hh:mm:ss) |
| 05 | — | E011 1010 | 3A | Value at last alarm |
| 02 | — | E011 0100 | 34 | Overload alarm configuration: 0x0000 = disabled 0x0100 = enabled |
| 05 | — | E011 0101 | 35 | The pickup setpoint in kW for the overload alarm |

Telegram information for meter configuration

You can use the information provided in this section to write to the meter using a SND_UD function.

NOTE: If Com. Protection is enabled, you may receive an error response when you try to configure the meter over communications.

You can also configure the meter using the M-Bus tool available from www.schneider-electric.com.

Supported VIFE codes for meter configuration

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| VIFE code | | Action | Description |
|-----------|-----|-------------------|--|
| bin | hex | | |
| E000 0000 | 00 | Write and replace | Replaces the old value with the new value. |
| E000 0111 | 07 | Clear | Resets an accumulated value to 0 (zero). |

Related topics

- See “Configuration mode menus” on page 37 for information on enabling and disabling Com. Protection.
- See “M-Bus tool for data display and meter configuration” on page 85 for information on the M-Bus tool.

Date/time setup

| Data format | Primary VIF | Description |
|-------------|-------------|--|
| 04 | 6D | Type F data type, as described in the M-Bus protocol documentation. Supports the date and time in the following format YYYY:MM:DD hh:mm:ss. |

Power system setup

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| SND_UD code | Data format | Manufacturer-specific VIFE | | Range/options | Description |
|-------------|-------------|----------------------------|-----|--------------------------|---|
| | | bin | hex | | |
| 00 | 02 | E010 0011 | 23 | 0, 1, 2, 3, 11, 13 | Power system configuration: 0 = 1PH2W L-N 1 = 1PH2W L-L 2 = 1PH3W L-L with N 3 = 3PH3W 11 = 3PH4W 13 = 1PH4 wire multi L with N |
| 00 | 02 | E010 0100 | 24 | 50, 60 | Nominal frequency |
| 00 | 05 | E010 0110 | 26 | VT Secondary - 1000000.0 | VT Primary (iEM3235 only) |
| 00 | 02 | E010 0111 | 27 | 100, 110, 115, 120 | VT Secondary (iEM3235 only) |
| 00 | 02 | E010 1000 | 28 | 1, 2, 3 | Number of CTs (iEM3235 only) |
| 00 | 02 | E010 1001 | 29 | 1-32767 | CT Primary (iEM3235 only) |
| 00 | 02 | E010 1010 | 2A | 1, 5 | CT Secondary (iEM3235 only) |
| 00 | 02 | E010 1011 | 2B | 0, 1, 2 | VT Connection Type (iEM3235 only) 0 = direct connect 1 = 3PH3W (2 VTs) 2 = 3PH4W (3 VTs) |

Multi Tariff setup

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| SND_UD code | Data format | Manufacturer-specific VIFE | | Range/options | Description |
|-------------|-------------|----------------------------|-----|---------------|---|
| | | bin | hex | | |
| 00 | 02 | E001 0001 | 11 | 0,1 | Set Multi Tariff control mode to Disabled or by Communication: 0 = Disabled 1 = by Communication NOTE: To configure the Multi Tariff feature to be controlled by the digital input or device clock, use the HMI. |
| 00 | 02 | E001 0000 | 10 | 1, 2, 3, 4 | Set the active tariff: 1 = Rate A (tariff 1) 2 = Rate B (tariff 2) 3 = Rate C (tariff 3) 4 = Rate D (tariff 4) NOTE: You can only set the tariff using this method if the Tariff Mode is set to by Communication. |

Communications setup

| SND_UD code | Data format | Primary VIF | Range/options | Description |
|-------------|-------------|-------------|---------------|-----------------|
| 00 | 01 | 7A | 0-250 | Primary address |

To change the baud rate via communications, send a telegram to the meter with the appropriate value in the CI-field:

| Baud rate | Hex value for CI-field |
|-----------|------------------------|
| 300 | B8 |
| 600 | B9 |
| 1200 | BA |
| 2400 | BB |
| 4800 | BC |
| 9600 | BD |

Digital input setup

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| SND_UD code | Data format | Manufacturer-specific VIFE | | Range/options | Description |
|-------------|-------------|----------------------------|-----|---------------|---|
| | | bin | hex | | |
| 00 | 02 | E001 1011 | 1B | 0, 3, 5 | Digital input control mode 0 = Normal (Input Status) 3 = Input metering 5 = Partial energy reset |
| 00 | 05 | E010 1111 | 2F | 1-10000 | Pulse constant (pulses/unit; applicable when the digital input is used for input metering) |

Digital output setup

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| SND_UD code | Data format | Manufacturer-specific VIFE | | Range/options | Description |
|-------------|-------------|----------------------------|-----|---------------|---|
| | | bin | hex | | |
| 00 | 02 | E001 1010 | 1A | 2, 3, 0xFFFF | Digital output control mode 2 = Alarm 3 = Energy (energy pulsing) 0xFFFF = Disable |

| SND_UD code | Data format | Manufacturer-specific VIFE | | Range/options | Description |
|-------------|-------------|----------------------------|-----|---|---|
| | | bin | hex | | |
| 00 | 05 | E010 1110 | 2E | iEM3135: 1, 10, 20, 100, 200, 1000 iEM3235: 0.01, 0.1, 1, 10, 100, 500 | Pulse constant NOTE: This information only applies if the digital output control mode is set to for Pulse. |
| 00 | 02 | E010 1100 | 2C | 50, 100, 200, 300 | Pulse width in ms NOTE: This information only applies if the digital output control mode is set to for Pulse. |

Overload alarm setup and acknowledgment

Use the information in the table below to configure the overload alarm.

NOTE: E denotes the extension bit; the hex value assumes E = 0.

| SND_UD code | Data format | Manufacturer-specific VIFE | | Range/options | Description |
|-------------|-------------|----------------------------|-----|---------------|--|
| | | bin | hex | | |
| 00 | 05 | E011 0101 | 35 | 0 - 9999999 | The pickup setpoint in kW for the overload alarm |
| 00 | 02 | E011 0100 | 34 | 0,1 | Overload alarm setup: 0 = Disable 1 = Enable |

Use the information in the table below to acknowledge the overload alarm.

NOTE: E denotes the extension bit; the hex value assumes E = 1.

| SND_UD code | Data format | Manufacturer-specific VIFE | | Range/options | Description |
|-------------|-------------|----------------------------|------------------|---------------|-------------------|
| | | bin | hex ¹ | | |
| 07 | 00 | E011 1000 | B8 | — | Acknowledge alarm |

Resets

NOTE: E denotes the extension bit; the hex value assumes E = 1.

| SND_UD code | Data format | Primary VIFE | | Manufacturer-specific VIFE | | Description |
|-------------|-------------|--------------|-----|----------------------------|-----|--|
| | | bin | hex | bin | hex | |
| 07 | 00 | — | — | E000 1101 | 8D | Resets partial energy accumulation to 0. |
| 07 | 00 | E110 0001 | E1 | — | — | Resets input accumulation to 0. |

M-Bus tool for data display and meter configuration

The M-Bus tool provides a graphical user interface where you can view meter data and configure meter settings. To obtain the tool, go to www.schneider-electric.com and search for your meter model then select Downloads or contact your local Schneider Electric representative.

If you access a different meter without closing and re-opening the M-Bus tool, the fields displayed in the tool may not match the device you are accessing. The M-Bus tool may indicate a setting was changed without the setting on the meter actually changing.

| |
|---|
| NOTICE |
| <p>INACCURATE DEVICE SETTINGS</p> <p>Do not rely on the configuration information displayed in the M-Bus tool to determine if the associated device is correctly configured.</p> <p>Failure to follow these instructions can result in inaccurate device settings and data results.</p> |

Installing the M-Bus tool

Before you install the tool, you need to download it from www.schneider-electric.com or obtain it from your sales representative.


1. Navigate to the location where you saved the installation files.
2. Double-click **setup.exe**. A welcome screen appears. Click **Next**.
3. Confirm the installation location for the tool. Click **Browse** if you want to select a different location. Click **Next**. A confirmation screen appears.
4. Click **Next** to begin the installation. A screen appears when the installation is complete.
5. Click **Close**.

Accessing the meter using the tool

Before you access the meter using the M-Bus tool, make sure that you:

- connect the meter to a level converter (for a direct serial connection) or a level converter and gateway (for connection via a serial or Ethernet network).
 - set the address of the device to a value other than 0 (zero) using the HMI.
 - install the M-Bus tool on your computer.
1. Select **Start > Programs > Schneider Electric > Mbus config tool** (or navigate to the location where you installed the program) and click **SE_iEM3135_3235 Mbus Tool** to open the tool.
The login screen appears.
 2. Select the port on your computer that you are using to connect to the meter and select the baud rate that matches the meter's configuration.
 3. Click **Test Com** to open the communications port.
 4. Type the device address in the **Address** field.
 5. Select the communications mode that you want the tool to start in:
 - **Monitor(Automatic)**: The tool automatically sends read requests to and receives data from the meter. You can set the interval at which these read requests are sent.
 - **Monitor(Manual)**: You must manually send a read request to get data from the meter.
 - **Config**: The tool opens in configuration mode.You can change the mode from within the tool, if needed.
 6. Click **OK** to start the M-Bus tool and access the meter.

Viewing meter data using the M-Bus tool



You can use two modes to view data from the device:


- Automatic mode: Select the update interval from the **Interval** dropdown list.
- Manual mode: Press **Req_UD2** to request data from the meter.

To switch modes, select **Setup > Monitor** then select the mode you want to use.

The tool has the following tabs for viewing meter information:

| Tab name | Description |
|----------------|--|
| Meter Info | This tab provides basic information about the meter (for example, model and serial number) and any active error codes. Click Clear to remove the error codes from the display. This does not resolve the errors. |
| Energy Measure | This tab provides total and partial energy, energy per phase and energy by tariff information, as well as input accumulations and the date and time of the last input metering and partial energy resets. |
| RMS Measure | This tab provides power, current, and voltage values as well as frequency and power factor information. |
| Meter Status | This tab provides information on the settings and status of the digital input, digital outputs and alarms as well as existing power system settings. |

Configuring the meter using the M-Bus tool



1. Select **Setup > Config** to switch to configuration mode.
2. Set the values that you want to change then click **Send** for that value or section. For example, to change the nominal frequency, select a different value from the list then click **Send** in **Set Wiring**.

Some values may be unavailable based on existing settings.

NOTE: If Com. Protection is enabled, you may receive a message that the configuration failed. Use the HMI to either: 1) configure the meter, or 2) disable Com. Protection then configure the meter using the tool.

The configuration screen has the following sections:

| Section | Description |
|--------------------|--|
| Set Wiring | Configure power system settings (for example, power system configuration and nominal frequency). |
| Set Digital Input | Set the digital input mode and pulse constant. |
| Set Digital Output | Enable / disable the digital output and set the control mode, pulse weight and duration. |
| Set Multi Tariff | Disable the Multi Tariff feature or set the control mode to by Communication and set the active tariff if the control mode is set to by Communication. |
| Set Power Alarm | Enable / disable to the overload alarm, enter the setpoint, and acknowledge alarms. |
| Reset | Reset partial energy and input metering accumulations. |
| Set Date Time | Set the date and time or send a time synchronization signal to set the meter to the computer time. |
| Set Baudrate | Set the baud rate. |
| Set Address | Set the meter address. |

Chapter 8 Communications via BACnet

What is in this chapter?

This chapter contains the following sections:

- BACnet communications overview 89**
- BACnet protocol support 90**
- BACnet communications implementation 91**
 - Configuring basic communication parameters 91
 - Communications LED indicator for BACnet meters 91
 - Change of Value (COV) subscriptions 91
- BACnet object and property information 91**
 - Device object 91
 - Analog Input objects 92
 - Analog Value object 95
 - Binary Input objects 95

BACnet communications overview

Communications via BACnet MS/TP protocol is available on the iEM3165 and iEM3265.

The information in this section is intended for users with an advanced understanding of BACnet protocol, their communications network and their power system.

Key terms

| Term | Definition |
|---------------------------|---|
| APDU | Application protocol data unit, that data portion of a BACnet message. |
| Confirmed message | A message for which the device expects an answer. |
| COV | Change of value, sets the amount by which a value has to change in order for the meter to send a subscription notification. |
| Device | A BACnet device is a unit that is designed to understand and use BACnet protocol (for example, a BACnet-enabled meter or software program). It contains information about the device and device data in objects and object properties. Your meter is a BACnet device. |
| MS/TP | Master-slave/token-passing over RS-485. |
| Object | Represents the device and device data. Each object has a type (for example, analog input or binary input) and has a number of properties. |
| Present value | The current value of an object. |
| Property | The smallest piece of information in BACnet communications, it consists of a name, data type and value. |
| Service | Messages from one BACnet device to another. |
| Subscription | Creates a relationship between the server and the meter, so that when the present value property of an object changes by more than the configured COV threshold (COV_Increment), a notification is sent. |
| Subscription notification | The message the meter sends to indicate a COV event has occurred. |
| Unconfirmed message | A message for which the device does not expect an answer. |

Related topics

- See www.bacnet.org for more information on the BACnet protocol.

BACnet protocol support

Go to www.schneider-electric.com and search for your meter model to access the PICS (Protocol Implementation Conformance Statement) for your meter.

The meter supports the BACnet protocol as follows:

| BACnet component | Description |
|---|--|
| Protocol version | 1 |
| Protocol revision | 6 |
| Standardized device profile (Annex L) | BACnet Application Specific Controller (B-ASC) |
| BACnet Interoperability Building Blocks (Annex K) | DS-RP-B (Data Sharing - Read Property - B) |
| | DS-RPM-B (Data Sharing - Read Property Multiple - B) |
| | DS-WP-B (Data Sharing - Write Property - B) |
| | DS-COV-B (Data Sharing - COV - B) |
| | DM-DDB-B (Device Management - Dynamic Device Binding - B) |
| | DM-DOB-B (Device Management - Dynamic Object Binding - B) |
| | DM-DCC-B (Device Management - Device Communication Control - B) |
| Data link layer options | MS/TP master (clause 9) Baud rates 9600, 19200, 38400, 57600, 76800 |
| Character set | ANSI X3.4 |
| Supported services | subscribeCOV readProperty readPropertyMultiple writeProperty deviceCommunicationControl who-HAS who-Is I-Am I-Have Confirmed COV notification Unconfirmed COV notification |
| Segmentation | The meter does not support segmentation |
| Static device address binding | The meter does not support static device address binding |
| Networking options | None |

The following standard object types are supported:

| Object type | Optional properties supported | Writable properties supported | Proprietary properties |
|---------------------|--|---|----------------------------|
| Device Object | Max_Master Max_Info_Frames Description Location Local_Date Local_Time Active_COV_Subscriptions Profile Name | Object_Name Max_Master Max_Info_Frames Description Location APDU_Timeout Number_Of_APDU_Retries | ID_800 ID_801 ID_802 |
| Analog Input Object | COV_Increment | COV_Increment | — |
| Analog Value Object | — | Present_Value | — |
| Binary Input Object | — | — | — |

Related topics

- See “Device object” on page 91 for information on the proprietary properties in the Device object.

BACnet communications implementation

Configuring basic communication parameters

Before communicating with the meter via BACnet protocol, use the front panel to configure the following settings:

| Setting | Possible values |
|-------------|--|
| Baud rate | 9600 19200 38400 57600 76800 |
| Mac Address | 1 - 127 |
| Device ID | 0 - 4194303 |

Make sure that the Mac Address is unique on the serial loop and the Device ID is unique in your BACnet network.

Communications LED indicator for BACnet meters

The LED indicates the status of the meter's communications with the network.

| LED state | Description |
|---------------------|---|
| The LED is off | Communication is not active. |
| The LED is flashing | Communication is active. NOTE: The LED flashes even if there is a communications error. |

Change of Value (COV) subscriptions

The meter supports up to 14 COV subscriptions. You can add COV subscriptions to Analog Input and Binary Input objects using your BACnet-compatible software.

Related topics

- See "Physical description" on page 14 for the location of the communications LED.
- See "Device configuration" on page 34 for information on configuring the meter using the front panel.

BACnet object and property information

The following sections outline the supported objects and properties available on the meter.

Device object

The following table outlines the properties of the Device object, whether a property is read-only or read-write, and if the value of the property is stored in the meter's non-volatile onboard memory.

| Device object property | R/W | Stored | Possible values | Description |
|------------------------------|-----|--------|--------------------|---|
| Object_Identifier | R | — | configurable | The unique device ID number for the meter, in the format of <device, #>. NOTE: You must use the front panel to configure the device ID number. |
| Object_Name | R/W | √ | configurable | A configurable name for the meter. The meter ships from the factory with a name of <model name>_<serial number> (for example, iEM3265_0000000000). |
| Object_Type | R | — | Device | The object type for the meter |
| System_Status | R | — | Operational | This value of this property is always Operational. |
| Vendor_Name | R | — | Schneider Electric | Meter manufacturer |
| Vendor_Identifier | R | — | 10 | The BACnet vendor identifier for Schneider Electric |
| Model_Name | R | — | iEM3165 or iEM3265 | Device model (for example, iEM3265) and serial number in the format <model name>_<serial number> (for example, iEM3265_0000000000). |
| Firmware_Revision | R | — | varies | BACnet firmware version, stored in an x.x.x format (for example, 1.7.2). |
| Application_Software_Version | R | — | varies | Meter firmware version, stored in an x.x.xxx format (for example, 1.0.305). |

| Device object property | R/W | Stored | Possible values | Description |
|---------------------------------|-----|--------|---|--|
| Description | R/W | √ | configurable | Optional description of the meter, limited to 64 characters. |
| Location | R/W | √ | configurable | Optional description of the meter's location, limited to 64 characters. |
| Protocol_Version | R | — | varies | BACnet protocol version (for example, version 1) |
| Protocol_Revision | R | — | varies | BACnet protocol revision (for example, revision 6) |
| Protocol_Services_Supported | R | — | 0000 0100 0000 1011 0100 0000 0000 0000 0110 0000 | The BACnet services supported by the meter: subscribeCOV, readProperty, readPropertyMultiple, writeProperty, deviceCommunicationControl, who-HAS, who-Is |
| Protocol_Object_Types_Supported | R | — | 1011 0000 1000 0000 0000 0000 0000 0000 | The BACnet object types supported by the meter: analog input, analog value, binary input, device |
| Object_list | R | — | varies | List of objects in the meter: iEM3165: DE1, AI0-AI48, AV0, BI0-BI6 iEM3265: DE1, AI0-AI55, AV0, BI0-BI6 |
| Max_APDU_Length_Accepted | R | — | 480 | The maximum packet size (or application protocol data unit) that the meter can accept, in bytes |
| Segmentation_Supported | R | — | 0x03 | The meter does not support segmentation. |
| Local_Date | R | — | configurable | Date NOTE: You must use the front panel to set the meter's date. |
| Local_Time | R | — | configurable | Time NOTE: You must use the front panel to set the meter's time. |
| APDU_Timeout | R/W | √ | 1000 - 30000 | The amount of time (in milliseconds) before the meter tries to resend a confirmed message that has not been answered. |
| Number_Of_APDU_Retries | R/W | √ | 1 - 10 | The number of times the meter tries to resend an unanswered confirmed request. |
| Max_Master | R/W | √ | 1 - 127 | The highest master address the meter will try to discover when the next node is unknown. |
| Max_Info_Frames | R/W | √ | 1 - 14 | Maximum number of messages the meter can send before it must pass the token. |
| Device_Address_Binding | R | — | — | Device address binding table is always blank because the meter does not initiate the who-Is service. |
| Database_Revision | R | √ | varies | A number that increments when the object database on the meter changes (for example, when an object is created or deleted or the ID of an object changes). |
| Active_COV_Subscriptions | R | — | varies | List of COV subscriptions currently active on the meter. |
| Profile_Name | R | — | varies | Device identifier, used on these meters to record the meter manufacturer, the meter family and the specific meter model (for example, 10_iEM3000_iEM3265). |
| ID 800 | R | — | varies | Date and time of last energy reset |
| ID 801 | R | — | varies | Date and time of last input metering accumulation reset |
| ID 802 | R | — | varies | Date and time of the last alarm (DD/MM/YYYY hh:mm:ss) |

Related topics

- See “Device configuration” on page 34 for information on configuring the meter using the front panel.

Analog Input objects

The following tables list the Analog Input (AI) objects along with the units and default COV value for each AI object (if applicable).

NOTE: The Value Type for all AI objects is Real.

Energy and energy by tariff measurements

The energy and energy by tariff measurements listed below are preserved through power failures.

| Object ID | Units | Default COV | Object name / description |
|-----------|-------|-------------|---------------------------------------|
| 27 | Wh | 100 | AI27 - Total active energy import |
| 28 | Wh | 100 | AI28 - Total active energy export |
| 29 | Wh | 100 | AI29 - Total reactive energy import |
| 30 | Wh | 100 | AI30 - Total reactive energy export |
| 31 | Wh | 100 | AI31 - Partial active energy import |
| 32 | Wh | 100 | AI32 - Partial reactive energy import |
| 33 | Wh | 100 | AI33 - Active energy import phase 1 |
| 34 | Wh | 100 | AI34 - Active energy import phase 2 |
| 35 | Wh | 100 | AI35 - Active energy import phase 3 |

| Object ID | Units | Default COV | Object name / description |
|-----------|-------|-------------|--|
| 36 | — | 10 | AI36 - Accumulation Input metering accumulation |
| 37 | — | 1 | AI37 - Tariff Energy Active Rate Denotes the active tariff: 0 = Multi Tariff feature is disabled 1 = rate A (tariff 1) active 2 = rate B (tariff 2) active 3 = rate C (tariff 3) active 4 = rate D (tariff 4) active |
| 38 | Wh | 100 | AI38 - Rate A (Tariff 1) active energy import |
| 39 | Wh | 100 | AI39 - Rate B (Tariff 2) active energy import |
| 40 | Wh | 100 | AI40 - Rate C (Tariff 3) active energy import |
| 41 | Wh | 100 | AI41 - Rate D (Tariff 4) active energy import |

Instantaneous (RMS) measurements

| Object ID | Units | Default COV | Object name / description |
|-----------|-------|-------------|-----------------------------|
| 7 | A | 50 | AI07 - Current Phase 1 |
| 8 | A | 50 | AI08 - Current Phase 2 |
| 9 | A | 50 | AI09 - Current Phase 3 |
| 10 | A | 50 | AI10 - Current Average |
| 11 | V | 10 | AI11 - Voltage L1-L2 |
| 12 | V | 10 | AI12 - Voltage L2-L3 |
| 13 | V | 10 | AI13 - Voltage L3-L1 |
| 14 | V | 10 | AI14 - Voltage Average L-L |
| 15 | V | 10 | AI15 - Voltage L1-N |
| 16 | V | 10 | AI16 - Voltage L2-N |
| 17 | V | 10 | AI17 - Voltage L3-N |
| 18 | V | 10 | AI18 - Voltage Average L-N |
| 19 | kW | 10 | AI19 - Active Power Phase 1 |
| 20 | kW | 10 | AI20 - Active Power Phase 2 |
| 21 | kW | 10 | AI21 - Active Power Phase 3 |
| 22 | kW | 10 | AI22 - Active Power Total |
| 23 | kVAR | 10 | AI23 - Reactive Power Total |
| 24 | kVA | 10 | AI24 - Apparent Power Total |
| 25 | — | 0.2 | AI25 - Power Factor Total |
| 26 | Hz | 10 | AI26 - Frequency |

Meter information

The following AI objects display information about the meter and its configuration.

NOTE: You can access the meter’s configuration information over BACnet communications. However, you must use the front panel to configure the meter’s settings.

| Object ID | Units | Default COV | Object name / description |
|-----------|---------|-------------|---|
| 44 | Seconds | 10 | AI44 - Meter operation time The time in seconds since the meter was last powered up |
| 45 | — | 1 | AI45 - Number of phases 1, 3 |
| 46 | — | 1 | AI46 - Number of wires 2, 3, 4 |
| 47 | — | 1 | AI47 - Power system type 0 = 1PH2W L-N 1 = 1PH2W L-L 2 = 1PH3W L-L with N 3 = 3PH3W 11 = 3PH4W 13 = 1PH4 wire multi L-N |

| Object ID | Units | Default COV | Object name / description |
|-----------|-------|-------------|---|
| 48 | Hz | 1 | AI48 - Nominal frequency 50, 60 |
| 49 | — | 1 | AI49 - Number of VTs 0 - 10 NOTE: only applies to the iEM3265 |
| 50 | V | 1 | AI50 - VT Primary NOTE: only applies to the iEM3265 |
| 51 | V | 1 | AI51 - VT Secondary NOTE: only applies to the iEM3265 |
| 52 | — | 1 | AI52 - Number of CTs 1, 2, 3 NOTE: only applies to the iEM3265 |
| 53 | A | 1 | AI53 - CT Primary NOTE: only applies to the iEM3265 |
| 54 | A | 1 | AI54 - CT Secondary NOTE: only applies to the iEM3265 |
| 55 | — | 1 | AI55 - VT connection type 0 = Direct connection, not VTs 1 = 3PH3W (2VTs) 2 = 3PH4W (3VTs) |

Communications settings information

The following AI objects display information about the meter’s communications settings.

NOTE: You can access the meter’s communications configuration information over BACnet communications. However, you must use the front panel to configure the meter’s settings.

| Object ID | Units | Default COV | Object name / description |
|-----------|-------|-------------|---------------------------|
| 00 | — | 1 | AI00 - BACnet MAC Address |
| 01 | — | 1 | AI01 - BACnet Baud Rate |

Digital input and output setting information

The following AI objects display information about the meter’s I/O settings.

NOTE: You can access the meter’s I/O configuration information over BACnet communications. However, you must use the front panel to configure the meter’s settings.

| Object ID | Units | Default COV | Object name / description |
|-----------|-------|-------------|---|
| 02 | ms | 1 | AI02 - Pulse Duration The energy pulse duration (or pulse width), in milliseconds, of the digital output. NOTE: This information only applies if the digital output mode is set to energy pulsing. |
| 03 | — | 1 | AI03 - Pulse Weight The pulses/unit setting of the digital input when it is configured for input metering. NOTE: This information only applies if the digital input mode is set to Input Metering. |
| 04 | — | 1 | AI04 - Pulse Constant The pulses/kWh setting of the digital output. NOTE: This information only applies if the digital output mode is set to energy pulsing. |
| 05 | — | 1 | AI05 - Digital Input Mode 0 = Normal (input status) 2 = Multi Tariff control 3 = Input metering 5 = All partial energy logs reset |
| 06 | — | 1 | AI06 - Digital Output Mode 2 = Alarm 3 = Energy 0xFFFF (65535 dec) = Disabled |

| Object ID | Units | Default COV | Object name / description |
|-----------|-------|-------------|--|
| 42 | kW | 10 | AI42 - Pickup Setpoint Active power alarm pickup setpoint in kW |
| 43 | kW | 10 | AI43 - Last Alarm Value |

Related topics

- See “Device configuration” on page 34 for information on configuring the meter using the front panel.
- See “Binary Input objects” on page 95 for information on reading the statuses of the input, output and alarm.

Analog Value object

There is one Analog Value (AV) object available on the meter, named AV00 - Command. The available commands are listed in the following table. Enter the number in the Present_Value column in the Present_Value property of the AV object to write the associated command to the meter.

| Command | Present_Value entry | Object name / description |
|------------------------------|---------------------|--|
| Acknowledge Overload Alarm | 20001.00 | Acknowledge an overload alarm. The alarm indicator disappears from the front panel display after you acknowledge the alarm; however, this does not address the state that caused the alarm. |
| Reset Partial Energy Counter | 2020.00 | Reset partial energy accumulation to 0. Partial Active / Reactive Energy, Energy by Tariff and Phase Energy registers are reset. |
| Reset Input Metering Counter | 2023.00 | Resets input metering accumulation to 0. |

Binary Input objects

The following table lists the Binary Input (BI) objects available on the meter.

NOTE: The Value Type for all BI objects is Boolean.

| Object ID | Object name / description |
|-----------|--|
| 0 | BI00 - Digital Output Enable Indicates whether or not the digital output functions as an energy pulse output: 0 = Digital output disabled 1 = Digital output is associated with active energy pulse output |
| 1 | BI01 - Digital Input Association Enable Indicates whether or not the digital input is associated with input metering: 0 = Digital input is not associated with input metering. 1 = Digital input is associated with input metering. |
| 2 | BI02 - Digital Input Status 0 = relay open 1 = relay closed NOTE: This information only applies if the digital input is set to Input Status. |
| 3 | BI03 - Alarm Enable Indicates whether the overload alarm is enabled or disabled: 0 = disabled 1 = enabled |
| 4 | BI04 - Digital Output Association Enable Indicates if the digital output is configured for alarming: 0 = digital output disabled 1 = for Alarm (digital output is associated with the overload alarm) |
| 5 | BI05 - Alarm Status 0 = Alarm is inactive 1 = Alarm is active |
| 6 | BI06 - Unacknowledged status 0 = historic alarm is acknowledged 1 = historic alarm is unacknowledged |

Chapter 9 Specifications

What is in this chapter?

This chapter contains the following sections:

- Electrical characteristics** 97
 - Power system inputs: iEM32•• meters 97
 - Power system inputs: iEM31•• meters 97
 - Inputs and outputs 98
- Internal clock** 98
- Measurement accuracy** 99
- Environmental and mechanical characteristics** 99
- Display and Energy pulsing LED characteristics** 99
- Modbus communications** 99
- LonWorks communications** 100
- M-Bus communications** 100
- BACnet communications** 100

Electrical characteristics

Power system inputs: iEM32•• meters

| | Characteristic | Value |
|----------------------------|-------------------------------------|---|
| Voltage inputs | Label | V1, V2, V3, Vn |
| | Measured voltage | Wye: 100 - 277 V L-N, 173 - 480 V L-L ±20% Delta: 173 - 480 V L-L ±20% |
| | Maximum voltage | 332 V L-N or 575 V L-L |
| | Impedance | 3 MΩ |
| | Frequency | 50 or 60 Hz ±10% |
| | Measurement category | III |
| | Electromagnetic environmental class | E2 |
| | Mechanical environmental class | M1 |
| | Wire | 2.5 mm ² / 14 AWG |
| | Wire strip length | 8 mm / 0.31 in |
| Torque | 0.5 Nm / 4.4 in lb | |
| Current inputs | Label | I1, I2, I3 |
| | Nominal current | 1 A or 5 A |
| | Measured current | 5 mA to 6 A |
| | Withstand | 10 A continuous, 20 A at 10 sec/hr |
| | Impedance | < 0.3mΩ |
| | Frequency | 50 or 60 Hz ±10% |
| | Burden | < 0.024 VA at 10 A |
| | Wire | 6 mm ² / 10 AWG |
| | Wire strip length | 8 mm / 0.31 in |
| | Torque | 0.8 Nm / 7.0 in-lb |
| Maximum device consumption | < 10 VA | |

Power system inputs: iEM31•• meters

| Characteristic | Value |
|------------------|---|
| Label | L1, L2, L3, N |
| Measured voltage | Wye: 100 - 277 V L-N, 173 - 480 V L-L ±20% Delta: 173 - 480 V L-L ±20% |

| Characteristic | Value |
|-------------------------------------|----------------------------|
| Maximum current | 63 A |
| Measured current | 0.5 A to 63 A |
| Maximum voltage | 332 V L-N or 575 V L-L |
| Voltage impedance | 3 MΩ |
| Current impedance | < 0.3 mΩ |
| Frequency | 50 or 60 Hz ±10% |
| Installation category | III |
| Electromagnetic environmental class | E2 |
| Mechanical environmental class | M1 |
| Burden | < 10 VA at 63 A |
| Wire | 16 mm ² / 6 AWG |
| Wire strip length | 11 mm / 0.43 in |
| Torque | 1.8 Nm / 15.9 in lb |

Inputs and outputs

| Characteristic | | Value | Energy meters | |
|-----------------------------|----------------------|--|---|--|
| Programmable digital output | Type | Form A | iEM3135/ iEM3155 / iEM3165 / iEM3235/ iEM3255 / iEM3265 | |
| | Load voltage | 5 – 40 V DC | | |
| | Maximum load current | 50 mA | | |
| | Output resistance | 0.1 – 50 Ω | | |
| | Wire | 1.5 mm ² / 16 AWG | | |
| | Wire strip length | 6 mm / 0.23 in | | |
| | Torque | 0.5 Nm / 4.4 in lb | | |
| Pulse output | Type | S0 form (IEC 62053-31 compatible) | iEM3110 / iEM3210 | |
| | Pulses / kWh | Configurable | | |
| | Voltage | 5 – 30 V DC | | |
| | Current | 1 – 15 mA | | |
| | Pulse width | Configurable Minimum width is 50 ms | | |
| | Isolation | 3.75 kV rms | | |
| | Wire | 1.5 mm ² / 16 AWG | | |
| | Wire strip length | 6 mm / 0.23 in | | |
| | Torque | 0.5 Nm / 4.4 in lb | | |
| Programmable digital input | Number - Type | 2 - Type 1 (IEC 61131-2) | iEM3115 / iEM3215 | |
| | | 1 - Type 1 (IEC 61131-2) | iEM3135 / iEM3155 / iEM3165 / iEM3175 / iEM3235 / iEM3255 / iEM3265 / iEM3275 | |
| | Maximum input | Voltage | 40 V DC | iEM3115/ iEM3135 / iEM3155 / iEM3165 / iEM3175 / iEM3215 / iEM3235 / iEM3255 / iEM3265 / iEM3275 |
| | | Current | 4 mA | |
| | Voltage OFF | 0 - 5 V DC | | |
| | Voltage ON | 11 - 40 V DC | | |
| | Nominal voltage | 24 V DC | | |
| | Isolation | 3.75 kV rms | | |
| | Wire | 1.5 mm ² / 16 AWG | | |
| | Wire strip length | 6 mm / 0.23 in | | |
| | Torque | 0.5 Nm / 4.4 in lb | | |

Internal clock

| Characteristic | Value | Energy meters |
|----------------|--|---|
| Type | Quartz crystal based Backup by supercapacitor | iEM3115 / iEM3135 / iEM3155 / iEM3165 / iEM3175 / iEM3215 / iEM3235 / iEM3255 / iEM3265 / iEM3275 |
| Time error | < 2.5 s/day (30 ppm) at 25°C (77°F) | |
| Backup time | > 3 days at 25°C (77°F) | |

Measurement accuracy

| Characteristic | | Value | Energy Meters |
|------------------------|---|---|---|
| Active energy | Class 1 conforming to IEC 62053-21 and IEC 61557-12 (PMD DD): $I_{max}=63\text{ A}$, $I_b=10\text{ A}$, and $I_{st}=0.04\text{ A}$ | | iEM31** |
| | Class B conforming to EN 50470-3: $I_{max}=63\text{ A}$, $I_{ref}=10\text{ A}$, $I_{min}=0.5\text{ A}$, and $I_{st}=0.04\text{ A}$ | | iEM31** |
| Reactive energy | | Class 2 conforming to IEC 62053-23 and IEC 61557-12 (PMD DD): $I_{max}=63\text{ A}$, $I_b=10\text{ A}$, and $I_{st}=0.05\text{ A}$ | iEM3135 / iEM3155 / iEM3165 / iEM3175 |
| for x/1A current input | Active energy | Class 1 conforming to IEC 62053-21 and IEC 61557-12 (PMD SD): $I_{max}=1.2\text{ A}$, $I_n=1\text{ A}$, and $I_{st}=0.002\text{ A}$ | iEM3200 / iEM3210 / iEM3215 |
| | | Class 1 conforming to IEC 62053-21 and IEC 61557-12 (PMD Sx): $I_{max}=1.2\text{ A}$, $I_n=1\text{ A}$, and $I_{st}=0.002\text{ A}$ | iEM3235 / iEM3250 / iEM3255 / iEM3265 / iEM3275 |
| | | Class B conforming to EN 50470-3: $I_{max}=1.2\text{ A}$, $I_n=1\text{ A}$, $I_{min}=0.01\text{ A}$, and $I_{st}=0.002\text{ A}$ | iEM32** |
| | Reactive energy | Class 2 conforming to IEC 62053-23 and IEC 61557-12 (PMD Sx): $I_{max}=1.2\text{ A}$, $I_n=1\text{ A}$, and $I_{st}=0.003\text{ A}$ | iEM3235 / iEM3255 / iEM3265 / iEM3275 |
| for x/5A current input | Active energy | Class 0.5S conforming to IEC 62053-22 and IEC 61557-12 (PMD SD): $I_{max}=6\text{ A}$, $I_n=5\text{ A}$, and $I_{st}=0.005\text{ A}$ | iEM32** |
| | | Class 0.5S conforming to IEC 62053-22 and IEC 61557-12 (PMD Sx): $I_{max}=6\text{ A}$, $I_n=5\text{ A}$, and $I_{st}=0.005\text{ A}$ | iEM3235 / iEM3250 / iEM3255 / iEM3265 / iEM3275 |
| | | Class C conforming to EN 50470-3: $I_{max}=6\text{ A}$, $I_n=5\text{ A}$, $I_{min}=0.05\text{ A}$, and $I_{st}=0.005\text{ A}$ | iEM32** |
| | Reactive energy | Class 2 conforming to IEC 62053-23 and IEC 61557-12 (PMD Sx): $I_{max}=6\text{ A}$, $I_n=5\text{ A}$, and $I_{st}=0.015\text{ A}$ | iEM3235 / iEM3255 / iEM3265 / iEM3275 |


Environmental and mechanical characteristics

| Characteristic | | Value | Energy Meters |
|----------------------------------|-------------|------------------------------------|-------------------|
| Degree of protection (IP rating) | Front panel | IP40 | iEM31** / iEM32** |
| | Casing | IP20 | |
| Operating temperature | | -25°C to +55°C (K55) | |
| Storage temperature | | -40°C to +85°C | |
| Pollution degree | | 2 | |
| Relative humidity | | 5% – 95% non-condensing | |
| Altitude | | < 3000 m (9843 ft) above sea level | |
| Impact rating | | IK08 | |

Display and Energy pulsing LED characteristics

| Characteristic | Value | Energy Meters |
|-----------------------------|--|---------------|
| Active energy display range | In kWh or MWh up to 99999999 MWh | iEM32** |
| | In kWh: 8 + 1 digits up to 99999999.9 | iEM31** |
| Energy pulsing LED (yellow) | 500 flashes / kWh | iEM31** |
| | 5000 flashes / kWh without consideration of transformer ratios | iEM32** |

Modbus communications

| Characteristic | Value | Energy meters |
|-------------------|---|---------------------------------------|
| Number of ports | 1 | iEM3150 / iEM3155 / iEM3250 / iEM3255 |
| Labels | 0V, D0/-, D1/+  (shield) | |
| Parity | Even, Odd, None | |
| Baud rate | 9600, 19200, 38400 | |
| Isolation | 4 kV rms | |
| Wire | 2.5 mm ² / 14 AWG shielded twisted pair | |
| Wire strip length | 7 mm / 0.28 in | |
| Torque | 0.5 Nm / 4.4 in lb | |

Related topics

- See “Communications via Modbus RS-485” on page 51 for information on Modbus communications.

LonWorks communications

| Characteristic | Value | Energy meters |
|-------------------|------------------------------|-------------------|
| Number of ports | 1 | iEM3175 / iEM3275 |
| Isolation | 3.75 kV rms | |
| Wire | 2.5 mm ² / 14 AWG | |
| Wire strip length | 7 mm / 0.28 in | |
| Torque | 0.5 Nm / 4.4 in lb | |

Related topics

- See “Communications via LonWorks” on page 63 for information on LonWorks communications.

M-Bus communications

| Characteristic | Value | Energy meters |
|-------------------|---------------------------------------|-------------------|
| Number of ports | 1 | iEM3135 / iEM3235 |
| Parity | Even, Odd, None | |
| Baud rate | 300, 600, 1200, 2400, 4800, 9600 baud | |
| Isolation | 3.75 kV rms | |
| Wire | 2.5mm ² / 14 AWG | |
| Wire strip length | 7 mm / 0.28 in | |
| Torque | 0.5 Nm / 4.4 in lb | |

Related topics

- See “Communications via M-Bus” on page 75 for information on M-Bus communications.

BACnet communications

| Characteristic | Value | Energy meters |
|-------------------|---|-------------------|
| Number of ports | 1 | iEM3165 / iEM3265 |
| Labels | 0V, D0/-, D1/+ ⊕ (shield) | |
| Baud rate | 9600, 19200, 38400, 57600, 76800 baud | |
| Isolation | 4.0 kV rms | |
| Wire | 2.5mm ² / 14 AWG shielded twisted pair | |
| Wire strip length | 7 mm / 0.28 in | |
| Torque | 0.5 Nm / 4.4 in lb | |

Related topics

- See “Communications via BACnet” on page 89 for information on BACnet communications.

Chapter 10 Troubleshooting

The meter does not contain any user-serviceable parts. If the meter requires service, contact your local sales representative.

NOTICE

RISK OF DAMAGE TO THE ENERGY METER

- Do not open the energy meter case.
- Do not attempt to repair any components of the energy meter.

Failure to follow these instructions can result in equipment damage.

Do not open the meter. Opening the meter voids the warranty.

Diagnostic codes

To find any current diagnostic codes on the HMI, press the down button until you reach the Diagnosis screen.

If the diagnostics code persists after following the instructions below, please contact Technical Support.

| Diagnostic code ¹ | Description | Possible solution |
|------------------------------|--|--|
| – | LCD display is not visible. | Check and adjust LCD contrast. |
| – | Push buttons do not respond. | Restart the energy meter by powering off and powering on again. |
| 101 | Metering stops due to an EEPROM error. Press OK to display total energy consumption. | Enter configuration mode and select Reset Config . |
| 102 | Metering stops due to a lack of a calibration table. Press OK to display total energy consumption. | Enter configuration mode and select Reset Config . |
| 201 | Metering continues. Mismatch between frequency settings and frequency measurements. | Correct the frequency settings according to the nominal frequency of the power system. |
| 202 | Metering continues. Mismatch between wiring settings and wiring inputs. | Correct the wiring settings according to wiring inputs. |
| 203 | Metering continues. Phase sequence reversed. | Check the wire connections and correct the wiring settings if needed. |
| 204 | Metering continues. Total active energy is negative due to incorrect voltage and current connections. | Check the wire connections and correct the wiring settings if needed. |
| 205 | Metering continues. Date and Time have been reset due to a loss of power. | Set the Date and Time. |
| 206 | Metering continues. Pulse is missing due to overload on energy pulse output. | Check the energy pulse output settings and correct if needed. |
| 207 | Metering continues. Abnormal internal clock function. | Restart the energy meter by powering off and powering on again then reset the date and time. |

¹ Not all diagnostic codes apply to all devices.

Related topics

- See “Data display” on page 29 for more information on navigating to the Diagnosis screen.

Schneider Electric

35, rue Joseph Monier

CS30323

F - 92506 Rueil Malmaison Cedex

www.schneider-electric.com

As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.

© 2013 Schneider Electric. All rights reserved.

DOCA0005EN-02 – 06/2013