

Power Harmonics Analyser PHS50



Instruction Manual

Version 2, Code No. 20 750 715

Contents

SAFETY CONSIDERATIONS.....	5
GENERAL.....	5
APPLICABLE STANDARDS.....	5
GENERAL INFORMATION.....	6
1. INTRODUCTION	6
2. DESCRIPTION	7
2.1. FRONT PANEL.....	7
2.2. CONNECTOR PANEL (on side of Meter).....	8
2.3. BOTTOM VIEW	9
2.4. Standard accessories	10
2.5. Optional accessories	10
3. SPECIFICATIONS.....	11
3.1. INPUTS.....	11
3.1.1 AC VOLTAGES	11
3.1.2 AC CURRENTS.....	11
3.1.3 REFERENCE CONDITIONS	11
3.2. OUTPUTS.....	12
3.2.1. Communication.....	12
3.2.2. Display	12
3.3. POWER SUPPLY	12
3.3.1. AC power supply.....	12
3.3.2. DC power supply.....	12
3.4. NON - VOLATILE MEMORY	12
3.5. HARMONICS MEASUREMENT	12
3.6. DIGITAL HARDWARE SPECIFICATIONS.....	13
3.7. GENERAL SPECIFICATIONS.....	13
3.8. MAINTENANCE.....	13
3.8.1. Batteries.....	13
3.8.2. Cleaning.....	13
3.8.3. Periodic calibration	14
3.8.4. Service.....	14
INTERNAL OPERATION	15
1. INTRODUCTION	15
2. MEASUREMENT METHODS.....	15
OPERATION MANUAL	17
1. GENERAL	17
2. OFF	19
3. CONFIG	19
3.1. PASSWORD.....	20
3.2. SYSTEM sub-menu :.....	20
3.3. RECORDER (Data Logging) sub-menu.....	21
3.4. SIGNALS and HARMONICS sub-menus.....	23
3.5. METER sub-menu	24
4. RECORDER (DATA LOGGING)	25
5. ENERGY	27
6. SPECTRUM (HARMONIC ANALYSIS)	28

7. METER.....	28
8. SCOPE (OSCILLOSCOPE FUNCTION)	29
9. FREQUENCY AND OVERLOAD INFORMATION METER, SCOPE AND SPECTRUM SCREENS	30
CONNECTION TO POWER SYSTEMS	31
PC SOFTWARE	34
1. INSTRUMENT SET-UP	35
2. DATA LOGGING & ANALYSIS.....	38
3. DIRECT LINK	41
THEORY OF OPERATION.....	43
1 GENERAL	43
2. STATISTICAL ANALYSIS	43
3. PERIODIC ANALYSIS.....	43
4. VOLTAGE ANOMALY RECORDING.....	51
5. POWER BREAKS RECORDING.....	52
6. MEMORY USAGE	52
MODEM DATA TRANSFER.....	54
1. INTRODUCTION.....	54
2. MODEMS	54
3. MODEM, INSTRUMENT AND POWER LINK CONFIGURATION	55
3.1. Power Link configuration	55
3.2. Modem configuration at the PC side.....	56
3.3. Modem configuration at the instrument side	56
3.4. Instrument configuration for modem communication.....	57
4. MODEM CONNECT. WITH PC AND INSTRUMENT.....	58
5. CONNECTING AND DISCONNECTING MODEMS	59
6. SMS MESSAGES	59

POWER HARMONICS ANALYSER

The Power Harmonics Analyser is a portable multifunction instrument for measurement and analysis of three-phase power systems.




fig. 1






Main features

- Comprehensive real time monitoring, recording and analysis of 3 ϕ power systems.
- Wide range of functions:
 - True rms Voltage,
 - True rms Current,
 - Power (Watt, var and VA),
 - Power Factor,
 - Energy,
 - Power Scope
- Harmonic Analysis.
- Monitoring of Voltage and power supply interruptions with analysis of recorded data.
- In recording mode, measured values are stored in memory for later analysis.
- Minimum, average & maximum value calculations for recorded quantities, with various pre-formatted reports.
- Oscilloscope mode for displaying waveforms, both in real time and for stored waveform analysis.
- Harmonic distortion analysis up to 63rd harmonic, both on line and on recorded data.
- Energy monitoring and analysis.
- Internal rechargeable batteries.
- RS232 communication port for connection to a PC.
- Windows software for data analysis and instrument control.

SAFETY CONSIDERATIONS

GENERAL

To ensure operator safety while using the Power Harmonics Analyser, and to minimise the risk of damage to the instrument, please note the following general warnings:

-  **The Instrument has been designed to ensure maximum operator safety. Use in a fashion other than as specified in this Manual may increase the risk of harm to the operator!**
-  **Do not use the instrument and/or any accessories if there is any damage visible!**
-  **The Instrument contains no user serviceable parts. Service or calibration must only be carried out only by an authorized dealer!**
-  **All normal safety precautions MUST be taken in order to avoid risk of electric shock when working on electric installations!**
-  **Only use approved accessories, which are available from your distributor!**

APPLICABLE STANDARDS

The Power Harmonics Analyser is designed in accordance to the following European standard:

Safety: • EN 61010-1

Electromagnetic compatibility (noise and immunity):

- EN 50081 –1
- EN 50082 –1

Measurements according to European standard:

- EN 50160

SECTION I

GENERAL INFORMATION

1. INTRODUCTION

This manual provides information for the connection, operation, programming, data analysis and maintenance of the Power Harmonics Analyser (shown in *fig. 1*).

The manual is divided into five sections, each covering a particular aspect of the operation of the Power Harmonics Analyser.

Section	Topic
I	General information
II	Internal Operation
III	Meter Operation
IV	Connection to Power System
V	PC Software
VI	Theory of operation

2. DESCRIPTION

2.1. FRONT PANEL




fig. 2: Front panel

Front Panel Layout:

1..... **FUNCTION switch**, selects one of seven functional/operating menus:

- **OFF** Power OFF
- **CONFIG** Instrument configuration menu
- **RECORD** Recording menu
- **ENERGY** Energy measurement
- **SPECTRUM** Harmonic analysis menu
- **METER** Basic power, current & voltage measurements
- **SCOPE** Waveforms display & control

2..... **LCD** Graphic display with LED backlight, 160x116 pixels.

3..... **ESC key:** To exit any procedure

4..... **ENTER key:** To confirm new settings, start recording procedure

5..... **SELECT key:** Enable selected signals

6..... **ARROW keys:** Move cursor and select parameters

7..... **LIGHT key:** LCD backlight ON/OFF


(Backlight automatically turns OFF after 30 sec. if no key action occurs)

LIGHT + ↑ Increase display contrast

LIGHT + ↓ Decrease display contrast

8..... **HOLD key** : Display screen is temporary frozen
(SCOPE ,METER and SPECTRUM functions only)

9..... **BELT slot**, For attachment of a carry strap.



2.2. CONNECTOR PANEL (on side of Meter)

- Use safety test leads only!
- Max. permissible voltage between voltage input terminals and ground is 300 V_{rms}
Max. permissible voltage between voltage input terminals is 600 V_{rms}

fig. 3: Connector panel

Connector Panel Layout:

- 1..... Current Clamp-on CTs/Transformers (I_1 , I_2 , I_3) input terminals
- 2..... Voltage (L_1 , L_2 , L_3) input terminals
- 3..... RS 232 connection (for connection of the Power Harmonics Analyser to a PC)

*fig. 4: External power socket***2.3. BOTTOM VIEW***fig. 5: Bottom view*

Bottom View Layout:

- 2 Plastic cover (fixes nylon strap to the instrument). There is a screw under this cover that needs to be unscrewed when opening the instrument for service or calibration purposes.



The instrument contains no user serviceable parts. Service or calibration must only be carried out only by an authorized dealer



- 3 Screw (unscrew to remove carrying strip or to open the instrument).
- 4 Label with measurement ranges.
- 5 Battery/fuse compartment cover.
- 6 Retaining screw (unscrew to replace batteries or blown fuse).
- 7 Rubber foot.

2.4. Standard accessories**Current probes:**

- Current clamp-on CTs, model S 1000 A / 1 V, 3 pcs
- Current transformers (optional)

Voltage cables, Current cables:

- Probe tips, 3 pcs
- Alligator clips, 4 pcs
- Voltage measurement cables, 6 pcs
- Mains cable
- RS 232 cable
- Soft carrying bag
- Instruction manual
- Product verification data
- Warranty declaration

Windows PC software:

- *PC analysis and control software package*

2.5. Optional accessories

See attached sheet for a list of optional accessories that are available on request from you distributor.

3. SPECIFICATIONS

The instrument's technical specification below details the performance standard or limit to which the instrument has been designed and tested.


3.1. INPUTS

3.1.1 AC VOLTAGES

The instrument has a three-phase AC voltage input (3 differential inputs, $L_1 - N_1$, $L_2 - N_2$, $L_3 - N_3$).


Voltage measurement is direct with internal voltage dividers.

There are no internal fuses in the voltage inputs.

-  **CAT III 600 V, 300 V to GND**
- Input range: 10 - 550 Vrms ($0.02 U_n - U_n$)
- Permissible overload: 600 Vrms
- Resolution: 0.1 V
- Accuracy: $\pm 0.5 \%$ of reading ± 2 digits
- Crest factor max. 1.4
- Frequency range : 43.-68 Hz fundamental

3.1.2 AC CURRENTS

The instrument has three AC current inputs, suitable for Clamp-on CTs or other current sensors.

- Input range: 0.02 - 1 Volt rms ($0.02 I_n - I_n$)
Equivalent to 20 - 1000 Amp with the standard Clamp-on CT.
- Resolution: 0.3 mV (0.3 Amp with the standard Clamp-on CT.)
- Accuracy: $\pm 0.5 \%$ of reading ± 6 digits plus current transformer accuracy
- Crest factor: 2.5
- Maximum permissible overload: 150 % I_n (sinusoidal current)
- Maximum input voltage: 1 Vrms
- Accuracy of standard Clamp: 1% (20 A – 1000 A) phase Error 2 - 0.5
-  **Use double insulated minimum CAT III 600V Clamp-on CTs and/or current transformers**

3.1.3 REFERENCE CONDITIONS

AC voltage for power measurements	$0.02 U_n \dots U_n$
AC current	$0.02 I_n \dots I_n$
Power factor	four quadrants ($1.00_{cap} \dots 0.00 \dots 1.00_{ind}$)
Frequency	45 ... 65 Hz
Waveform	Sinusoidal AC voltage and current
Distortion factor	$< 2 \%$
Auxiliary power supply	$230 V \pm 10 \%$
Ambient temperature	$23 ^\circ C \pm 3 ^\circ C$
Humidity	$60 \% \pm 15 \%$

3.2. OUTPUTS

3.2.1. COMMUNICATION

RS232 serial interface for connection to a PC, fully opto isolated. Selectable 2400 - 57, 600 baud. 9 pin D-type connector. Communication cable supplied.

3.2.2. DISPLAY

Graphic Liquid Crystal Display with LED backlight, 160 x 116 dots resolution.

3.3. POWER SUPPLY

3.3.1. AC POWER SUPPLY

Operating range: 230 V AC + 10 % -20 %, overvoltage category III, 45 - 65 Hz, 8 VA
Fuse: F2 T100 mA (250 V in the battery compartment)

3.3.2. DC POWER SUPPLY

Internal 4 x 1.2 V NiCd or NiMh rechargeable IEC LR14 batteries provide full operation for up to 5 hours.

Internal battery charger, charging time approx. 10 hours.

Fuse: F1 T630 mA (250 V in the battery compartment)

3.4. NON - VOLATILE MEMORY

2048 Kbytes SRAM, battery backed.

3.5. HARMONICS MEASUREMENT

The instrument computes harmonics on signals sampled with an A/D converter.

Table 1: Limits of error and resolution in Harmonics measurement:

Range I_r, U_r	Limits of error		Resolution on LCD and PC
	THD	HD	
2 ... 100%	$0.2 \% \times U_r/U (I_r/I)$	$0.2 \% \times U_r/U (I_r/I)$	0.1 %

Note: THD Total Harmonic Distortion

HD Harmonic Distortion

U_r U_{range}

I_r I_{range}

3.6. DIGITAL HARDWARE SPECIFICATIONS


A/D conversion 14 bit with 128 samples per channel per period (43 - 68 Hz).


3.7. GENERAL SPECIFICATIONS

Working temperature range	-10 °C ... +45 °C
Storage temperature range	-20 ... 70 °C
Max. humidity	85 % RH (0÷40 °C)
Pollution degree	2
Protection classification	double insulation
Overvoltage category	Voltage inputs: CAT III 600 V, 300 V to gnd AC power supply CAT III 300 V
Protection degree	IP 44
Dimensions	265 x 110 x 18.5 mm
Weight (without accessories)	2 kg

3.8. MAINTENANCE

3.8.1. BATTERIES

 Instrument contains rechargeable NiCd or NiMH batteries. Do NOT replace with alkaline cells. These batteries should only be replaced with the same type as defined on the battery cover label or in this manual.

 Hazardous voltages exist inside this Instrument. Disconnect all test leads, remove the power supply cable and switch off instrument before removing battery compartment cover.

If it is necessary to replace batteries, all four MUST be replaced. Ensure batteries are installed with the correct polarity; incorrect polarity can damage the batteries and/or the Instrument.

There may exist special environmental regulations concerning the disposal of batteries. These must be followed.

 In case of blown battery fuse (F1), this should be replaced with the same type as defined on the label close to it.

3.8.2. CLEANING

To clean the surface of instrument, use a soft cloth slightly moistened with soapy water or alcohol. Then leave the instrument to dry totally before use.

- **Do not use liquids based on petrol or hydrocarbons!**
- **Do not spill cleaning liquid over the instrument!**

3.8.3. PERIODIC CALIBRATION

To ensure correct measurement, it is essential that the Instrument be regularly calibrated. If used continuously on a daily basis, a six monthly calibration period is recommended, otherwise annual calibration is sufficient.

3.8.4. SERVICE

For repairs under warranty, or at any other time, please contact your distributor.

Distributor's address:

ND Metering Solutions
228 Bolton Road
Bradford
BD3 0QW
UK

Tel: +44 1274 729533
Fax: +44 1274 721074
E-mail sales@ndmeter.co.uk

<p>The Instrument contains no user serviceable parts. Service or calibration must only be carried out only by an authorized dealer!</p>
--

SECTION II INTERNAL OPERATION

1. INTRODUCTION

This section contains technical information on the internal operation of the Power Harmonics Analyser, including descriptions of measuring methods and recording principles.

2. MEASUREMENT METHODS

Measurement methods are based on the digital sampling of the input signals. Each input (3 voltages and 3 currents) is sampled 128 times in each input cycle. Duration of this input cycle depends on the frequency at the synchronization input (one of the 3 voltage inputs or a current input). At 50 Hz, the input cycle period is 20ms.

Basic measured values are calculated at the end of each sampling period and the results are available on the display or are recorded.

FFT based results are only calculated on every 8th input cycle (every 160ms@50Hz).

The following equations are used for computing the given quantities.

Basic calculations

Parameter	Equation for calculation	Unit	Formula N°
Phase voltage	$U_x = \sqrt{\frac{1}{128} \sum_{i=1}^{128} u_{x_i}^2}$	V	[1]
Phase current	$I_x = \sqrt{\frac{1}{128} \sum_{i=1}^{128} i_{x_i}^2}$	A	[2]
Phase active power	$P_x = \frac{1}{128} \sum_{i=1}^{128} u_{x_i} * i_{x_i}$	W	[3]
Phase to phase voltage	$U_{xy} = \sqrt{\frac{1}{128} \sum_{i=1}^{128} (u_{x_i} - u_{y_i})^2}$	V	[4]
Neutral conductor current	$I_0 = \sqrt{\frac{1}{128} \sum_{i=1}^{128} (i_{1i} + i_{2i} + i_{3i})^2}$	A	[5]

Additional calculation (using basic values)

Phase apparent power	$S_x = U_x * I_x$	VA	[6]
Phase reactive power	$Q_x = \sqrt{S_x^2 - P_x^2}$	var	[7]
Phase power factor	$PF_x = \frac{P_x}{S_x}$		[8]
Phase voltage crest factor	$Q_{x_{cr}} = \frac{U_{x_{max}}}{U_x} * 100$		[18]
Phase current crest factor	$I_{x_{cr}} = \frac{I_{x_{max}}}{I_x} * 100$		[19]

Additional calculation (using FFT transformation)

Phase voltage-current angle	$\phi = \phi_i - \phi_u$ ϕ_i, ϕ_u are calculated by FFT VI angle for the fundamental component	[9]
-----------------------------	--	-----

Phase voltage THD	$thd_{U_x} = \frac{\sqrt{\sum_{n=2}^{63} hn_{U_x}^2}}{h1_{U_x}} * 100$	%	[10]
-------------------	--	---	------

Phase current THD	$thd_{I_x} = \frac{\sqrt{\sum_{n=2}^{63} hn_{I_x}^2}}{h1_{I_x}} * 100$	%	[11]
-------------------	--	---	------

Phase voltage individual harmonics	$Hn_{U_x} = \frac{hn_{U_x}}{h1_{U_x}} * 100$	%	[12]
------------------------------------	--	---	------

Phase current individual harmonics	$Hn_{I_x} = \frac{hn_{I_x}}{h1_{I_x}} * 100$	%	[13]
------------------------------------	--	---	------

Total values

Total active power	$P_t = P_1 + P_2 + P_3$	W	[14]
--------------------	-------------------------	---	------

Total reactive power	$Q_t = Q_1 + Q_2 + Q_3$	var	[15]
----------------------	-------------------------	-----	------

Total apparent power	$S_t = \sqrt{P_t^2 + Q_t^2}$	VA	[16]
----------------------	------------------------------	----	------

Total power factor	$Pf_t = \frac{P_t}{S_t}$		[17]
--------------------	--------------------------	--	------

In a 3 ϕ systems with a normal 3 wire connection, the following values are not available for displaying and recording:

- Neutral conductor current
- Phase voltage-current angle
- Phase power factor

SECTION III OPERATION MANUAL

1. GENERAL

This section describes how to operate and programme the Instrument.

The instrument front panel consists of a graphic LCD display, nine keys and an eight position rotary switch. Measured data and current instrument status are shown on the display.




fig. 6: Keypad

ESC	To exit any procedure
ENTER	To confirm new settings, start recording procedure
SELECT	Enable selected signals
ARROW	Move cursor and select parameters
HOLD	Display screen is temporary frozen (SCOPE, METER and SPECTRUM functions only)
LIGHT	LCD backlight ON/OFF Backlight will automatically turn OFF 30 seconds after the last key operation
LIGHT + UP	Increases display contrast
LIGHT + DOWN	Decreases display contrast
HOLD	Display Freeze In SCOPE, METER and SPECTRUM functions only

NOTE: Throughout these instructions the '**up arrow**' key is called the '**UP key**', the '**right arrow**' key the '**RIGHT key**', the '**down arrow**' key the '**DOWN key**' and the '**left arrow**' key the '**LEFT key**'.

One of seven functional/operating menus can be selected with the rotary selector switch:

OFF	Power OFF
CONFIG	Instrument configuration menu
RECORD	Data Logging (Recording) menu
ENERGY	Energy measurement
SPECTRUM	Harmonic analysis menu
METER	Basic power, current & voltage measurements
SCOPE	Waveforms display & control




fig. 7: Instruments rotary selector switch

The instrument's main design function is the logging of various parameters on power distribution systems. Logging functions are selected on the right side of the rotary switch.

Recording mode	OFF	All settings are saved. Warning given if recording is in progress
	CONFIG	General configuration; Submenus cover specific functions
	RECORD	Data logging and monitoring
	ENERGY	Total and subtotal cumulative register (energy counters)

Further information on the functions available in RECORDING Mode is available under 'THEORY OF OPERATION'.

The instrument can also be used for real time measurement, available on the left side of the rotary switch. These function are independent of recording status.

Real time measurements	SPECTRUM	Harmonic Analysis
	METER	Basic measurements on three phase systems
	SCOPE	Oscilloscope displays of measured waveforms
	OFF	All settings are saved. Warning given if recording is in progress

2. OFF

Selecting **OFF** turns the instrument OFF after 2 seconds. All current settings and set parameters are saved during this period in non-volatile memory. If switching OFF occurs while the instrument is set for recording, this is treated as a POWER BREAK and the date & time of Power OFF is saved. This will also occur if the instrument loses its power supply while recording (see section II.3.5 Power Break Recording). If the instrument is set for recording, this will be indicated on the display irrespective of the position of the rotary Selector Switch:

- **Rec.On:** Recording in progress
- **Rec.Wt:** Waiting to start recording
- **SEND:** Instrument is sending data to a PC
- **HOLD:** Display contents temporarily frozen
In SCOPE, METER and SPECTRUM functions only

3. CONFIG

Use this menu to set all parameters for Recording and Real time measurement. The main screen in the **CONFIG** menu includes instrument details (Model number, software version & serial number) and shows date and time on the bottom line. From this main screen, various configuration sub-menus can be accessed, allowing instrument parameters, measurement conditions and settings to be changed.

The **HOLD** function is ignored in this menu.

Battery status is displayed at bottom of the display (see *fig.8*).

The legend "**EXTR**" is shown if the Instrument is being powered from the mains rather than from the battery.




fig. 8

The main **CONFIG** menu consists of five items. Use the **UP** and **DOWN** keys to highlight the appropriate item, then press the **ENTER** key to select it.

3.1. PASSWORD

All programming functions and recorder settings (including the starting & stopping data logging) are password protected. Unless the password is entered, the various settable parameters & functions can only be viewed. In all configuration sub-menus, pressing any edit key (**UP**, **DOWN**, **LEFT**, **RIGHT**, **SELECT**, **ENTER**) will activate password input procedure. The password must be entered before the **SYSTEM** sub-menu is selected.

PASSWORD: * * * *

Default password

LEFT, SELECT, RIGHT, ENTER

The password is automatically cleared 5 minutes after the last key operation.

3.2. SYSTEM sub-menu :

This sub-menu allows setting of the password, the serial port baud rate and the instrument date & time. The fourth choice is to totally reinitialise the Instrument.

ENABLE PASSW.	If the password is enabled → Or by pressing SELECT	CHANGE PASSW.
SER. PORT RATE		GSM / SMS PARAM.
DATE/TIME	Or by pressing SELECT	UPGRADE
LANGUAGE		
SYSTEM REINIT.		
CLR.REC.MEM.		

Use **UP** or **DOWN** keys to select the required menu item, then press the **ENTER** key.

CHANGE PASSW Enter a new four key combination and repeat it for confirmation.
(The LCD key is not a valid password key)

SER PORT RATE Set the baud rate for serial communication port by using **SELECT** key. (from 2400 to 57,600 baud)

GSM/SMS PARAM. See **Section VII** for modem configuration

Note: *Applicable only if modem option is enabled*

DATE/TIME Use the **LEFT** or **RIGHT** key to select between Date and Time and the **UP** & **DOWN** keys to set a new date or time.
Only valid date/time values will be accepted.

Press **ENTER** to confirm the settings or **ESC** to cancel any changes.

SYSTEM REINIT Clears all settings and sets defaults values as below.

- Recorder START/STOP : MANUAL
- Statistic: ON
- Periodic: ON
- Anomalies: ON, fixed
- Main IP: 1 min
- Power sub IP: 1
- Nominal voltage: 230 V
- Up/Down limits: 10 %
- Buffer mode: roll-over
- Selected channels: none

- Selected harmonic: none
- Voltage multiplier(K): 1
- Current range: 1000 A
- Connection: 4w
- Sync. frequency: 50 Hz
- Sync. input: AUTO
- Serial port rate: 57600

UPGRADE The possibility for later implementation of modem by order. The instrument serial number must be attached to an order for the code.

Use **UP / DOWN** keys for increment / decrement number of selected place and **LEFT / RIGHT** to select place.

Note: *It is only necessary to enter the code once and is valid also for later software upgrades.*

3.3. RECORDER (Data Logging) sub-menu

Use this sub-menu to set Data Logging parameters and log START/STOP conditions. Note that actual starting or stopping can only be effected from the main **RECORD** menu.




fig. 9

Use **UP** or **DOWN** key to select the appropriate parameter.

START and STOP

There are two ways of starting and stopping recording.

In **Manual** mode, recording starts immediately if period recording is OFF.

If Periodic Recording is ON, there is a "null" seconds delay.

STOP in manual mode is immediate.

In **Auto** mode, START and STOP occur at user preset dates and times.

Recording can be stopped manually at any time.

Use **SELECT** key to toggle between **MANUAL** and **AUTO** mode.

In **AUTO** start/stop, use **LEFT** or **RIGHT** keys to select between Date and Time and the **UP & DOWN** keys to set a new date or time.

Only valid date/time values will be accepted.

STAT. and PER.

STAT. Statistical Analysis

PER. Periodic Analysis

Use the **SELECT** key to enable (ON) or disable (OFF) the selected function.

ANOM.WINDOW

Recording of Voltage Anomalies

Use the **SELECT** key to toggle between Disable (OFF), FIXED Window or VARIABLE Window recording.

In **FIXED** window mode, the window (and the Upper & Lower Limits) is set around the nominal voltage and remains fixed during recording session.

In **VARIABLE** window mode, the window (and the Upper & Lower Limits) is set around an average voltage dynamically calculated. Use the **LEFT** and **RIGHT** keys to adjust the averaging period for calculating new values of average voltage (1 to 900 sec).

Voltage Anomaly recording is only available for those voltages selected for recording (see 3.2.4 SIGNALS) even if Periodic Analysis is disabled. If no voltage is selected, there will be no logging of Voltage Anomalies.

MAIN INTEGR.PER.

Integration (time) period for Periodic Analysis.

Use the **LEFT** and **RIGHT** keys to set the integration period (between 1 second and 30 minutes).

POWER SUB.I.P.

Averaging sub period for power measurement. (Power sub IP)

Used in Periodic Analysis to average readings (see PERIODIC ANALYSIS and the accompanying figure). Settable between 1 and 20 mains cycles.

Use the **LEFT** and **RIGHT** keys to set the required value.

NOMINAL VOLTAGE

The nominal voltage used as a reference in Voltage Anomaly recording.

In **FIXED** window mode, this is the actual voltage used.

In **VARIABLE** window mode, this is the start value of voltage, later modified to the average value of voltage during the previous Integration Period while recording.

Use the **LEFT** and **RIGHT** keys to set the required nominal voltage (from 58.0 V to 450.0 V).

UPPER and LOWER limits

These are the limits which define the pass window for Voltage Anomaly recording.

Any voltage value outside the specified limits is detected and stored as an anomaly.

Use the **LEFT** and **RIGHT** keys to set the required limit (1% to 30% of nominal voltage).

BUFFER MODE

The data storage in the data logging (recorder) function can be performed in two ways: LINEAR or ROLLOVER.

In **Linear** mode, recording stops when the memory is filled.

In **Rollover** mode, recording only stops when the auto stop date/time is reached, or when manually stopped.

Once memory is filled, the oldest data is over-written.

Neither mode will affect any memory allocated for Statistical Analysis.

Press **ENTER** to confirm the new settings or **ESC** to cancel.

Starting or Stopping of Data Logging is effected from the RECORD menu.

3.4. SIGNALS and HARMONICS sub-menus

These menus allow selection of signals, harmonics and calculated parameters for storage while Data Logging (recording). A maximum of 64 signals can be selected; the number of free locations is shown in the upper right corner of the display.

RECORDER : signals +51				
L1	U	S+	Pfc+	Pfc - Qi +
	I	S-	Pfi +	Pfi - Qi -
	P+	P-	Qc+	Qc - dPf
L2	U	S+	Pfc+	Pfc - Qi +
	I	S-	Pfi +	Pfi - Qi -
	P+	P-	Qc+	Qc - dPf
L3	U	S+	Pfc+	Pfc - Qi +
	I	S-	Pfi +	Pfi - Qi -
	P+	P-	Qc+	Qc - dPf
T	Pt+	Pftc+	Pfti+	Freq S+
	Pt-	Pftc-	Pfti-	Inul S-
	Qtc+	Qtc-	Qti+	Qti - Uu

fig. 10: Signal Sub-menu

RECORDER : harmonics +47				
enabled on : L1 L2 L3				
thd : thdU thdI				
harmonics :				
U	02	03	04	05
	06	07	08	09
	10	11	12	13
	14	15	16	17
	18	19	20	21
	22	23	24	25
	26	27	28	29
	30	31	32	33
	34	35	36	37
	38	39	40	41
I	02	03	04	05
	06	07	08	09
	10	11	12	13
	14	15	16	17
	18	19	20	21
	22	23	24	25
	26	27	28	29
	30	31	32	33
	34	35	36	37
	38	39	40	41

fig. 11: Harmonics Sub-menu

Use **LEFT**, **RIGHT**, **UP** and **DOWN** keys to select the required signal. Enable or disable the signal for recording with the **SELECT** key.

Signals sub-menu Select per-phase and/or total 3 ϕ values.

Selecting a voltage signal U will also automatically enable logging of Voltage Anomalies for that phase (if Voltage Anomaly recording mode is selected as **FIXED** or **VARIABLE**).

Harmonics sub-menu The selected harmonics are valid for all the selected phases (L₁, L₂, L₃ as shown at the top of the screen).

It is not possible to set different combinations for individual phases.

Selecting one or more harmonics will automatically select THD measurement.

Press **ENTER** to confirm the new settings or **ESC** to cancel.

3.5. METER sub-menu

This menu allows setting of various input parameters. These parameters are used for calculating the true rms values of all measured and calculated quantities, for scaling input signals and for synchronisation.




fig. 12: Meter Configuration Sub-menu

Use the **UP** and **DOWN** keys to select the required parameter.

U_{nomin.}(V) Nominal measuring range of instrument voltage inputs. It is used for calculation and display of results only.
Default value is 230.0 V (Range from 50.0 V to 450.0 V).

U_{inp.K.}(*) Scaling factor for voltage inputs.
This allows for external voltage transformers or dividers that may be used and ensures that readings are related to the primary.
e.g. for 11 kV / 110 V, the multiplication factor must be set to 100.
Use the **LEFT** and **RIGHT** keys to set U_{inp.K.} (from 1 to 800). Standard value is 1.

I_{range} (1V) Scale factor for current inputs.
Defines the current equivalent to a 1 V input signal.
Use the **LEFT** and **RIGHT** keys to set I_{range} (1 V) (1 A to 24 kA).
Standard value is 1000 A.

NOTE: Settings for U_{inp.K.} and I_{range} affect all displayed values (powers, energies, harmonic components, etc).

Connection Defines the method of connecting the Instrument to the 3φ systems:

4w 3φ 4 wire system (with a Neutral conductor).
All voltage and current inputs are used.

3w 3 ϕ 3 wire system (without Neutral conductor)
3 CTs used.

AARON 3 ϕ 3 wire system (without Neutral conductor)
(also known as the '2 wattmeter method')
2 CTs used.

Sync.freq. Default mains frequency for input cycle period/scanning.
It is ignored if the instrument detects a valid synchronisation frequency on the selected sync. input.

Sync.inp. Default synchronisation input.
Use fixed input (L₁, L₂, L₃, I₁) for synchronisation or select AUTO mode (automatic scanning for a valid sync. input).

Press **ENTER** to confirm new settings or press **ESC** to cancel.

4. RECORDER (DATA LOGGING)

Use this function to display the present data logging (recording) status and set the main Data Logging parameters.

Recording can be started or stopped from this screen.

To START or STOP Data Logging:

Press **SELECT** key. The password entry screen is opened.

Enter the password.

After confirming the password, press **ENTER** to start or stop Data Logging (depending on current status).

If START is selected, the instrument checks the currently set recording parameters before starting to log data.

rec.stat:	STOP
buf.mode:	READY (c i r c.)
start:	AUTO
	18.05.1999 14:25:00
stop:	MANUAL
	20.05.1999 10:38:10
statist:	OFF
periods:	14
max:	2384
power off/on:	0
anomal:	3
int.pr:	60s
remain:	17s
20.05.1999	12:44:39

fig. 13: Recorder (Data Logging) Menu

rec.stat. Present recorder status:

WAIT	Recorder (in AUTO mode) is waiting for start date & time
RUN	Recorder is running
STOP	Recorder (in AUTO mode) has been stopped manually. Recording aborted.
COMPLETE	Recording completed

buf.stat. Present recorder memory status:

EMPTY	No data in memory
READY	Data present; awaiting download
SAVED	Data present; previously downloaded

Buffer operating status/mode:

lin.	Memory in Linear mode
circ.	Memory in Roll-over mode
cir./laps	Memory in Roll-over mode, current Lap number

start: If the instrument is in **Rec.Wait** mode and the memory is empty, the programmed START date & time is displayed.
If instrument is in **Rec.Run** mode, the actual recording start date & time (as opposed to programmed) is displayed.

stop: If the instrument is in **Rec.Wait** or **Rec.Run** mode, the programmed STOP date & time is displayed.
If the instrument is in **Rec.Stop** or **Rec.Complete** mode, the actual recording stop date & time (as opposed to programmed) is displayed.
Under certain circumstances, the instrument also displays the reason for stopping the recording:

MANUAL BREAK	Manual stop in AUTO stop mode
END OF MEM.	Memory full (in linear memory mode)

statist. Statistical Analysis enabled (ON) or disabled (OFF).

anomal. The number of detected and saved Voltage Anomalies.
If currently in a Voltage Anomaly, a blinking arrow points to the number.

For Periodic Analysis, there are four further information lines:

periods.	Number of recorded periods from start of data logging.
int.pr.	Current integration period (IP) in seconds
max.	Aprox max. number of periods that can be saved (in Linear Buffer mode only)
remain	Remaining time in the current integration period

powerN° of power ON/OFF events during the current recording period.

5. ENERGY

This function displays the various energy registers.

EP:	000000000.0	kWh
EQC:	000000000.0	kVAr h
EQi:	000000000.0	kVAr h
SUBTOTAL		
EP:	000000000.0	kWh
EQC:	000000000.0	kVAr h
EQi:	000000000.0	kVAr h
LAST IP		
EP+:	00000.0	kWh
EQc+:	00000.0	kVAr h
EQi+:	00000.0	kVAr h
EP-:	00000.0	kWh
EQc-:	00000.0	kVAr h
EQi-:	00000.0	kVAr h

fig. 14: Energy Registers

- Top three lines: **Total** cumulative registers of
 - Active energy **Ep** in kWh
 - Reactive capacitive energy **EQC** in kvar
 - Reactive inductive energy **EQi** in kvar
- SUBTOTAL lines: **Subtotal** cumulative registers of
 - Active energy **Ep** in kWh
 - Reactive capacitive energy **EQC** in kvar
 - Reactive inductive energy **EQi** in kvar

To reset the Total and / or Subtotal registers:

1. Press **SELECT** key. The password entry screen is opened.
2. Enter the password
3. After confirming the password, press **ENTER** to reset the **Subtotals** or **ESC** to quit.
4. After resetting subtotals, press **ENTER** to reset the **Totals** or **ESC** to quit.

- LAST IP lines: Display energy in last integration period (if data logging is active):
 - Active positive energy **Ep+** in kWh
 - Reactive positive capacitive energy **EQc+** in kvar
 - Reactive positive inductive energy **EQi+** in kvar
 - Active negative energy **Ep+** in kWh
 - Reactive negative capacitive energy **EQc+** in kvar
 - Reactive negative inductive energy **EQi+** in kvar

NOTE: At least one signal from Signal Sub-menu (*fig. 10*) and Periodics ON from Configuration Sub-menu (*fig. 9*) must be selected.

6. SPECTRUM (HARMONIC ANALYSIS)

This function displays the results of Fast Fourier Transformation (FFT) calculations, both as values and in graphic mode.

Graphs are auto scaled in order to ensure maximum resolution.

The top line provides information on the selected input (U_1 , I_1 , U_2 , I_2 , U_3 , I_3), its absolute value and the synchronisation frequency.

The bottom line provides details of the selected harmonic component and its absolute and percentage values. The equivalent bargraph is identified by a blinking cursor.




fig. 15: Harmonic Analysis

Use **LEFT** and **RIGHT** keys to select the required bargraph, and the **SELECT** key to choose the required input signal (U_1 , I_1 , U_2 , I_2 , U_3 , I_3).

7. METER

This function displays the basic measured quantities (AC) in the 3 ϕ system. The display format and legends (V, kV, A, kA, W, kW, MW, etc.) are automatically selected appropriate to the measured values. The following quantities are displayed:

Phase rms voltage (U_1 , U_2 , U_3).

Phase rms current (I_1 , I_2 , I_3).

Per phase signed active, apparent and reactive powers ($\pm P$, $\pm S$, $\pm Q$).

Power Factors with indication of direction (capacitive or inductive).

Phase angle between voltage and current.

rms phase to phase voltage (V_{1-2} , V_{2-3} , V_{3-1}).

Total 3 ϕ signed active, apparent and reactive powers ($\pm P_t$, $\pm S_t$, $\pm Q_t$).

Total 3 ϕ Power Factor with indication of direction (capacitive or inductive).

System frequency.

Current in neutral conductor, rms value.

4W	L 1 :	L 2 :	L 3 :	HOLD
U :	234.5	234.5	234.5	V
I :	854.3	854.3	854.3	A
P :	132.22	132.22	132.22	kW
S :	200.33	200.33	200.33	kVA
Q :	-150.49	-150.49	-150.49	kVAr
Pf :	0.66c	0.66c	0.33i	
ϕ :	0.72	0.72	0.72	
Uu :	407.6	407.6	407.6	V
TOTALS: SEQ:123 - Pow?				
Pt :	400.44	kW	Fr :	50.02 Hz
St :	554.22	kVA	In :	7.3 A
Qt :	383.15	kVAr	Pft :	0.72i
20.05.1999.				18:44:00

fig. 16: Meter Display Screen

Note: In 3 ϕ systems with a 3wire connection, the Instrument does not display values for the 3rd phase.

The central (TOTALS) line may then display two additional messages:

seq? When three phase system is not connected in the correct phase sequence (L₁-L₂-L₃).

pow? When active power in one or more phase is negative.

Note: Frequency will be displayed in inverse if the instrument is unable to find a valid sync. input. The default sync. frequency (as defined elsewhere) is used.

8. SCOPE (OSCILLOSCOPE FUNCTION)

This function provides signal waveform displays together with summary details of the signal. The displayed signals are auto-scaled to suit the display, and may vary dependant on the total harmonic distortion.

The top line provides information about the selected input (U₁, I₁, U₂, I₂, U₃, I₃), its value and the synchronisation frequency.




fig. 17: Scope Display without display of additional information

Use the **SELECT** key to toggle between the signal display options (L₁, L₂, L₃, 3U, 3I, L₁...). Display of additional information is controlled by toggling the **ENTER** key.

To scale voltage waveforms:

Use **LEFT** or **RIGHT** keys

To scale current waveforms:

Use **UP** or **DOWN** keys




fig. 18: Scope Display with display of additional information

9. FREQUENCY AND OVERLOAD INFORMATION METER, SCOPE AND SPECTRUM SCREENS

The synchronisation frequency is measured on the input selected in the meter configuration menu (L_1 , L_2 , L_3 or I_1). If no valid frequency can be detected (after software filtering) the Instrument will, if in AUTO mode, scan the other channels for signal that could be used for synchronisation. If no stable frequency signal can be found, the Instrument will use the default (50-60Hz) frequency selected in the METER configuration menu and display this frequency value in inverse.

If an input overload is detected (voltage input > 550 V ac or current input > 2 V ac), or if there is a peak over-range (770 V for voltage inputs and 2.5 V for current), this will be indicated on the instrument display by a black arrow pointing to the particular input.

SECTION IV

CONNECTION TO POWER SYSTEMS



Warning



This Instrument requires connection to dangerous voltages

This instrument can be connected to the 3 ϕ system in 3 ways:

- 3 ϕ four wire system $L_1, L_2, L_3, N; I_1, I_2, I_3$
- 3 ϕ three wires system $L_{12}, L_{23}, L_{31}; I_1, I_2, I_3$
- Aaron (2 wattmeter) 3 ϕ connection L_{12}, L_{32}, I_1, I_2

The actual connection scheme must be defined in METER Configuration menu (see fig 19 below).




fig. 19: Meter Configuration Menu

Use **LEFT** and **RIGHT** keys to select the appropriate connections scheme.

When connecting the instrument, it is essential that both current and voltage connections are correct. In particular, the following rules must be observed:

- **Current Clamp-on CTs**

The arrow marked on the Current Clamp-on CTs must point in the direction of current flow, from supply to load.

If a Clamp-on CT is connected in reverse, the measured power in that phase would normally appear negative.

- **Phase Relationships**

The Clamp-on CT connected to current input connector I_1 **MUST** be measuring the current in the phase to which the voltage probe from L_1 is connected.

Wiring connections are shown in *fig. 20*, *fig. 21* and *fig. 22* below.

On systems where the voltage is measured on the secondary side of a voltage transformer (say 11 kV / 110 V), a scaling factor taking account of that voltage transformer ratio must be entered in order to ensure correct measurement (see Section III 3.2.5 METER Configuration).

1. 3 ϕ 4 wire system (with Neutral conductor)




fig. 20: 3 ϕ 4 wire system

2. 3 ϕ 3 wire system with 3 CTs (no Neutral conductor)




fig. 21: 3 ϕ 3 wire system with 3 CTs

3. 3 ϕ 3 wire system with 2 CTs (2 Wattmeter connection)




fig. 22: 3 ϕ 3 wire system with 2 CTs (2 Wattmeter connection)

WARNING**Connecting to Current Transformers**

The secondary of a current transformer must NOT be open circuited when on a live circuit.

An open circuit secondary can result in a dangerously high voltage across the terminals.




fig. 23: Connecting to existing CTs on a high voltage system

SECTION V

PC software

The Power Harmonic Analyser is supplied complete with a powerful suite of Windows software that can be used for:

- Configuring the Instrument
- Setting measurement parameters
- Download of recorded data
- Off-line analysis of recorded data
- On-line capture and analysis of current voltage and power signals.

The software also provides the necessary tools to allow measured data etc to be included in various reports.

The Minimum requirement for running the software is the ability of the PC to run Windows 98




fig. 24: Basic opening screen

The Basic opening screen is the starting point for all actions. It provides general information about the Instrument and - by clicking on 'toolbar buttons' or selecting pull-down menus - access to all functions. The buttons provide access to:

- Download of data
- Setting Instrument configuration parameters
- Analysis of downloaded or previously saved data
- Direct Link - Operating on-line with the Instrument
- Data Logging START/STOP

To set the instrument configuration parameters, double click on **Settings**; the programme will download current settings from the instrument and display them on the screen.

1. INSTRUMENT SET-UP

To set the instrument configuration parameters, double click on **Settings**; the program will download current settings from the instrument and display them on the screen.

Instrument settings	
Manufacturer	
Type of instrument	
Serial number	
Last calibr. date	
User note	
Instrument baud rate	57600
U factor	1
U nominal (V)	230
I range (A)	1000
Connection	4 wires
Frequency (Hz)	50
Sync. input	auto
Type of recording	Periodics

Details

Send Read Close Help

fig. 25: Instrument settings screen

The Instrument settings screen contains the instrument data and parameters fields and buttons. Buttons are:

Details	To edit the parameters of Periodics
Send	To send Set-up parameters to the instrument
Read	To download Set-up parameters from the instrument
Close	To close this settings screen
Help	To run online help

To change values on parameter fields, double click on the specific field and select between the available options.

User note	This field is available for entry of any text Name, Survey Reference, etc.
Instrument Baud Rate	Increment / Decrement the value using PgUp / PgDown keys or double click to the following dialog, see Fig. 26.



fig. 26: Baud Rate Set-up screen

- U factor** **Voltage Transformer Ratio**
Increment / Decrement the value using PgUp / PgDown keys.
- U nominal** **Nominal Voltage**
Increment / Decrement the value using PgUp / PgDown keys.
- I range (A)** **Scale Factor for the Current Transformers**
Increment / Decrement the value using PgUp / PgDown keys.
- Connection** Select the System Connection.
Note: Aaron is a 3 wire measurement with 2 current transformers



fig. 27: Connection screen

Frequency (Hz) To toggle between 50 Hz and 60 Hz, double click on the Frequency field.

Sync. Input **Frequency Synchronization Input**
Select the input using PgUp / PgDown keys.

Type of recording Select the type of Data Analysis (available for higher instruments).




fig. 28: Recording Set-up screen

To view and set details on the Periodics recording click on DETAILS button.

A detailed configuration window titled "Periodics" with a close button (X) in the top right corner. It is divided into several sections:


- Recording time (dd.mm.yyyy. hh:mm)**: Contains "Start" (10.01.2000. 00:00) and "Stop" (MANUAL) text boxes.
- Enable recording for**: A group box containing three checked checkboxes: "Statistics", "Periodics", and "Anomalies".
- Buffer mode**: A group box containing two radio buttons: "linear" and "circular" (selected).
- Anomalies settings**: A group box containing:
 - Two radio buttons: "Fixed" (selected) and "Variable with average time" (with a value of 0 s).
 - "Low limit is" set to 10 % under nominal voltage.
 - "High limit is" set to 10 % over nominal voltage.
- Parameters**: A section with four spin boxes: "Main IP" (600 sec), "Power sub Ip" (1 per), "U nominal (V)" (230), and "Selected signals" (64 with a selection icon).

At the bottom are "OK", "Cancel", and "Help" buttons.

fig. 29: Details screen for 'periodic' recording

Periodic Analysis

Recorded data can be analysed in numerical form.



The screenshot shows a window titled "Periodics" with a sub-header "Execute". It displays a table with 7 columns: Time, U1 (V) Min, U1 (V) Avg, U1 (V) Max, U2 (V) Min, U2 (V) Avg, and U2 (V) Max. The data spans from 16.06.1999 05:21:38 to 16.06.1999 05:22:07. The table is scrollable, and the row for 16.06.1999 05:21:44 is highlighted.

Time	U1 (V) Min	U1 (V) Avg	U1 (V) Max	U2 (V) Min	U2 (V) Avg	U2 (V) Max
16.06.1999. 05:21:38	228,04	228,13	228,33	225,97	226,07	226,35
16.06.1999. 05:21:39	228,13	228,33	228,42	226,16	226,26	226,45
16.06.1999. 05:21:40	228,23	228,33	228,42	226,26	226,26	226,45
16.06.1999. 05:21:41	228,23	228,33	228,42	226,26	226,26	226,45
16.06.1999. 05:21:42	228,33	228,42	228,61	226,35	226,45	226,64
16.06.1999. 05:21:43	228,42	228,52	228,61	226,45	226,45	226,64
16.06.1999. 05:21:44	228,33	228,42	228,61	226,35	226,45	226,54
16.06.1999. 05:21:45	228,33	228,42	228,61	226,35	226,35	226,54
16.06.1999. 05:21:46	228,33	228,33	228,52	226,26	226,35	226,54
16.06.1999. 05:21:47	228,23	228,33	228,42	226,16	226,26	226,35
16.06.1999. 05:21:48	228,13	228,23	228,42	226,16	226,26	226,45
16.06.1999. 05:21:49	228,13	228,23	228,33	226,16	226,16	226,35
16.06.1999. 05:21:50	228,04	228,13	228,33	226,07	226,16	226,35
16.06.1999. 05:21:51	228,13	228,23	228,42	226,16	226,16	226,35
16.06.1999. 05:21:52	228,13	228,23	228,42	226,07	226,16	226,45
16.06.1999. 05:21:53	228,13	228,33	228,42	226,16	226,26	226,45
16.06.1999. 05:21:54	228,13	228,23	228,42	226,16	226,26	226,45
16.06.1999. 05:21:55	228,23	228,33	228,42	226,26	226,26	226,45
16.06.1999. 05:21:56	228,23	228,33	228,42	226,26	226,26	226,45
16.06.1999. 05:21:57	228,23	228,23	228,42	226,16	226,26	226,45
16.06.1999. 05:21:58	228,23	228,33	228,52	226,26	226,26	226,45
16.06.1999. 05:21:59	228,13	228,23	228,42	226,16	226,26	226,35
16.06.1999. 05:22:00	228,13	228,23	228,42	226,16	226,26	226,45
16.06.1999. 05:22:01	228,13	228,23	228,52	226,16	226,26	226,45
16.06.1999. 05:22:02	228,23	228,33	228,42	226,26	226,26	226,45
16.06.1999. 05:22:03	228,13	228,23	228,42	226,16	226,26	226,35
16.06.1999. 05:22:04	228,13	228,23	228,33	226,07	226,16	226,35
16.06.1999. 05:22:05	228,13	228,23	228,42	226,16	226,26	226,35
16.06.1999. 05:22:06	228,23	228,33	228,42	226,26	226,26	226,45
16.06.1999. 05:22:07	228,23	228,33	228,42	226,26	226,26	226,35

fig. 34: Tabular Data Analysis screen

Data can also be graphed, with advanced navigating and search facilities.




fig.35: Graphic Data Analysis screen

Voltage Anomalies

Recordings of Voltage Anomalies (or Voltage Breaks) can be displayed in both numerical and graphic format.




fig. 36: Voltage Anomalies and Breaks screen

A full listing of all Voltage Anomalies is provided, together with the set-up information, and an analysis of each record can be quickly viewed in both graphic and tabular form.

Statistical Analysis

A Statistical Analysis of recorded data can be displayed in both numerical and graphic format.




fig. 37: Statistical Analysis screen

3. DIRECT LINK

The Direct Link facility allows direct on-line operation, with real-time values from the voltage and current inputs displayed on the screen. Complex calculation can be carried out and selected input signals waveforms can be saved, can be exported to an ASCII file or to the Clipboard for use with third party analysis tools.

To open the connection to the instrument, click on the '**go!**' button.




fig. 38: Direct Link oscilloscope screen

To read **Energies** from the instrument, click on the '**Eng**' button. A small window showing the current values of the energies is displayed.

To look at Harmonics, both Voltage & Current, click on the '**Mag**' button. The harmonic analysis screen is displayed, with six histograms – three voltage and three current – showing harmonics up to the 63rd.

To zoom in any histogram, click on **Execute** and **Show Table**. Click on separate histogram to enlarge it.

To alter the scaling of any of the graphs, click on the vertical axis:

Near the top to increase the range.

Near the bottom to expand the scale.

To also show the harmonics in tabular form, select '**Show Table**' from the '**Execute**' menu. Moving the mouse pointer along any of the graphs will activate a cursor, which identifies a single harmonic, with the tabular display scrolling in sympathy with the cursor position.

To return to the main **Direct Link** screen, select '**Close**' from the '**Execute**' menu.




fig. 39: Direct Link Harmonic Analysis Screen with tabular display

NOTE: If the display appears to become frozen, there is insufficient time for the display to process all the acquired data.

The 'Request Time' (in the 'Execute' menu) should be increased.

For a Baud rate of 57600, a Request Time at least 1300 ms is recommended.

SECTION VI

Theory of operation

1 GENERAL

Data recording is one of the main functions of the instrument. However, while recording data for later analysis, the Instrument can also carry out the following functions:.

- **Statistical analysis – Statistical analysis of the measured signals.**
- **Periodic analysis – On line recording and analysis of various measured signals over preset periods.**
- **Voltage anomalies - Detection and recording of voltage anomalies.**
- **Power breaks – Detection and recording of supply interruptions.**

Apart from power break recording, which is always enabled, all the other functions are independent and can be disabled or enabled by the user. The measuring principles are the same in all recording functions and are described in Section II-2 below. Averaging and statistical techniques are described later in this section.

Data is stored in non-volatile memory and can be download to a PC for further analysis and printing. Downloading can be carried out either on-line while recording and / or after recording has finished. Independent of the recording status, the Instrument can send all samples of an input signal to a PC (for external analysis and viewing) every second.

2. STATISTICAL ANALYSIS

The input range (from 0 to full scale) for each value is divided in 256 divisions (100 for PF and $\cos\phi$). Measured values are scaled accordingly. The result is a statistical table, a Gaussian function, that can be analysed using the PC software (see section V below). Statistical analysis is carried out only on signals selected in the Signals submenu. Statistical analysis cannot be applied to Harmonic measurements.

3. PERIODIC ANALYSIS

Periodic Analysis is carried out over a programmable integration period (IP). This can be set (from 1 second to 30 minutes) by the user. During the integration period, the instrument calculates maximum, minimum and average values of selected quantities. At the end of the Period, these values are stored in memory together with the Period Start date/time and synchronization input.

Stored values differ for the various parameters:

- | | |
|---|----------------------------------|
| • For THD measurement | Only maximum and average values. |
| • For voltage harmonics and voltage-current angle | Only maximum and minimum values. |
| • For current harmonics | Only maximum values. |
| • All other Parameters | Minimum, maximum and average. |

Active power is divided in two quantities: Import (positive) and Export (negative).
 Reactive power and power factor are divided in four quantities: positive inductive (+i), positive capacitive (+c), negative inductive (-i) and negative capacitive (-c).
 Neutral conductor current (I_0) is ignored when measuring in 3 wire connection.
 For power, voltage and current measurements, values are stored for each input cycle.
 Harmonics and THD values are computed on samples of each 8th input cycle.
 For calculation of Average Voltage, voltages less than 2 % of full scale ($0.02 \times U_N$) are treated as voltage interruptions and are excluded from any calculations.


The stored maximum and minimum values are based on values calculated during each input cycle, while average values (except for voltage, power & harmonics) are calculated at the end of each IP and are based on the number of input cycles in the period.
 Average values for power, voltage and harmonic components ignore input cycles where the voltage is lower than $0.02 \times U_N$. Further, if a Power Break or a Power Up occurs during an IP or the IP starts during a Power Break, the Instrument will start a new cycle (see also Power Break recording below).
 The following figures and table offer a detailed descriptions of the values used for recording.

The meaning of abbreviations is described below.

SYMBOL DEFINITIONS

General symbols	
U	rms voltages
I	rms currents
P	active power
S	apparent power
Q	reactive power
I_0	rms neutral conductor current
PF	power factor
Cosφ	voltage - current phase angle
THD	total harmonic distortion
H	individual harmonics (%)
h	individual harmonic (V or A)
IP	integration period
dPF	power factor of basic harmonic

Additional symbols	
x	phase
t	total
i	inductive (with P, Q or PF symbol)
c	capacitive (with P, Q or PF symbol)
+	positive (with P, Q or PF symbol)
-	negative (with P, Q or PF symbol)
n	harmonic number (with H or h symbol)
a	average (with any general symbol)
m	max. or min (with any general symbol)
na	not available
pn	N° of input cycles in integration period (IP)
hpn	N° of input cycles for harmonics in IP ($pn/8$)
ppn	N° of input cycles for powers
upn	N° of input cycles for voltages
PC	personal computer
cr	crest factor
pb	power break time inside IP




Input Cycles used for calculation under various Power Break situations

fig. 40

When measuring Power and Power Factor, values can be calculated for each individual cycle or averaged over a period (the 'Power sub IP') which can be set at any value between 1 and 20 cycles (a 400 ms window at 50Hz).

If the Instrument is recording a power, it automatically calculates and records the energy of the selected power in an IP.

Values used for the calculation of maximum and minimum Powers and Power Factors are the average values calculated on power sub IP values (see *fig. 35* below). Recording of voltage or current THD is automatically enabled if one or more individual voltage or current harmonics are selected.



Examples of calculation of Maximum & Minimum values for various 'Power sub IP' periods

fig. 41

Minimum & Maximum PER PHASE Values

	LOAD TYPE				
VALUE	CONSUMING		GENERATING		Note
	inductive	capacitive	inductive	capacitive	[formula]
m P_{x+}	P_x		0		[3]
m P_{x-}	0		P_x		[3]
m Q_{xi+}	Q_x	0	0	0	[7]
m Q_{xc+}	0	0	0	Q_x	[7]
m Q_{xi-}	0	0	Q_x	0	[7]
m Q_{xc-}	0	Q_x	0	0	[7]
m PF_{xi+}	PF_x	1	na	na	[8]
m PF_{xc+}	na	na	1	PF_x	[8]
m PF_{xi-}	na	na	PF_x	1	[8]
m PF_{xc-}	1	PF_x	na	na	[8]
m U_x	U_x				[1]
m I_x	I_x				[2]
m U_{xthd}	U_{xthd}				[10] -max only
m I_{xthd}	I_{xthd}				[11] -max only
m $\cos\phi_x$	$\cos\phi_x$				[9]
m U_xH_n	U_xH_n				[12]
m I_xH_n	I_xH_n				[13] -max only

Available Maximum & Minimum per phase Values for each Input Cycle


Note: U_{xthd} , I_{xthd} , $\cos\phi_x$, $U_x H_n$, $I_x H_n$ are calculated every 8th input cycle

Minimum & Maximum TOTAL (3 ϕ) Values

	LOAD TYPE					
VALUE	CONSUMNIG		GENERATING		Note	
	inductive	capacitive	inductive	capacitive	[formula]	
m Pt+	P _t		0		[14]	
m Pt-	0		P _t		[14]	
m St+	S _t		0		[16]	
m St-	0		S _t		[16]	
m Qti+	Q _t	0	0	0	[15]	
m Qtc+	0	0	0	Q _t	[15]	
m Qti-	0	0	Q _t	0	[15]	
m Qtc-	0	Q _t	0	0	[15]	
m PFti+	PF _t	1	na	na	[17]	
m PFtc+	na	na	1	PF _t	[17]	
m PFti-	na	na	PF _t	1	[17]	
m PFtc-	1	PF _t	na	na	[17]	
m I ₀	I ₀					
m Freq	Freq					

Available Maximum & Minimum 3 ϕ Values for each Input Cycle

Note: P_t , S_t and Q_t are average values in power sub integration period which is from 1 to 20 input cycles. PF_t is also a result of those values



Import/Export and Inductive/Capacitive Phase/Polarity Diagram

fig. 42

Per Phase Values (averaged at the end of an IP)**WATTS**

$$aP_x^+ = \frac{\sum_{j=1}^n (P_x^+)_j}{pn}$$

$$aP_x^- = \frac{\sum_{j=1}^n (P_x^-)_j}{pn}$$

VAR

$$aQ_{xi}^+ = \frac{\sum_{j=1}^n (Q_{xi}^+)_j}{pn}$$

$$aQ_{xc}^+ = \frac{\sum_{j=1}^n (Q_{xc}^+)_j}{pn}$$

VAR

$$aQ_{xi}^- = \frac{\sum_{j=1}^n (Q_{xi}^-)_j}{pn}$$

$$aQ_{xc}^- = \frac{\sum_{j=1}^n (Q_{xc}^-)_j}{pn}$$

PF

$$aPf_{xi}^+ = \frac{aP_x^+}{\sqrt{(aQ_{xi}^+)^2 + (aP_x^+)^2}}$$

$$aPf_{xc}^+ = \frac{aP_x^+}{\sqrt{(aQ_{xc}^+)^2 + (aP_x^+)^2}}$$

PF

$$aPf_{xi}^- = \frac{aP_x^-}{\sqrt{(aQ_{xi}^-)^2 + (aP_x^-)^2}}$$

$$aPf_{xc}^- = \frac{aP_x^-}{\sqrt{(aQ_{xc}^-)^2 + (aP_x^-)^2}}$$

Volts & Amps

$$aU_x = \frac{\sum_{j=1}^n (U_x)_j}{upn}$$

$$aI_x = \frac{\sum_{j=1}^n (I_x)_j}{pn}$$

HARMONICS

$$aU_{xthd} = \frac{\sqrt{H_y U_x}}{H_1 U_x} * 100; \quad H_y U_x = \frac{\sum_{z=1}^n \left(\sqrt{\sum_{j=2}^{63} (U h_n)_j^2} \right)_z}{hpn}; \quad H_1 U_x = \frac{\sum_{z=1}^n U_x h_1}{hpn}$$

$$aI_{xthd} = na$$

$$a \cos \varphi_x = na$$

$$aU_x H_n = na$$

$$aI_x H_n = na$$

Note: If power breaks occur, periods 'pn' (for power calculations) and 'upn' (for voltage calculations) are modified to:

$$pn = \frac{IP}{ic} - \frac{pb}{ic}$$

$$upn = \frac{IP}{ic} - \frac{pb}{ic} - ic_l$$

Where: ic = input cycle time

pb = power break time inside the IP

ic_l = number of cycles with U_x < 0.02 U_{range}

Total 3φ Values (averaged at the end of an IP)

Watts	$aP_t^+ = \frac{\sum_{j=1}^n (P_t^+)_j}{pn}$	$aP_t^- = \frac{\sum_{j=1}^n (P_t^-)_j}{pn}$
--------------	--	--

VA_r	$aQ_{ii}^+ = \frac{\sum_{j=1}^n (Q_{ii}^+)_j}{pn}$	$aQ_{tc}^+ = \frac{\sum_{j=1}^n (Q_{tc}^+)_j}{pn}$
-----------------------	--	--

VA_r	$aQ_{ii}^- = \frac{\sum_{j=1}^n (Q_{ii}^-)_j}{pn}$	$aQ_{tc}^- = \frac{\sum_{j=1}^n (Q_{tc}^-)_j}{pn}$
-----------------------	--	--

VA	$aS_t^+ = \sqrt{(aP_t^+)^2 + (aQ_{ii}^+ + aQ_{tc}^+)^2}$	$aS_t^- = \sqrt{(aP_t^-)^2 + (aQ_{ii}^- + aQ_{tc}^-)^2}$
-----------	--	--

PF	$aPf_{ii}^+ = \frac{aP_t^+}{\sqrt{(aQ_{ii}^+)^2 + (aP_t^+)^2}}$	$aPf_{tc}^+ = \frac{aP_t^+}{\sqrt{(aQ_{tc}^+)^2 + (aP_t^+)^2}}$
-----------	---	---

PF	$aPf_{ii}^- = \frac{aP_t^-}{\sqrt{(aQ_{ii}^-)^2 + (aP_t^-)^2}}$	$aPf_{tc}^- = \frac{aP_t^-}{\sqrt{(aQ_{tc}^-)^2 + (aP_t^-)^2}}$
-----------	---	---

Current & Frequency	$aI_0 = \frac{\sum_{j=1}^n I_{0j}}{pn}$	$aFreq = \frac{\sum_{j=1}^n Freq_j}{pn}$
------------------------------------	---	--

Note: If power breaks occur, period 'pn' (for power calculations) is modified to:

$$pn = \frac{IP}{ic} - \frac{pb}{ic}$$

Where: ic = input cycle time
pb = power break time inside the IP

4. VOLTAGE ANOMALY RECORDING

Voltage anomalies occur when a voltage exceeds preset boundaries. The rms voltages of each half input cycle are used for comparison. For every Voltage Anomaly detected, the Instrument stores:

- Date & time when the anomaly started.
- The nominal voltage.
- Minimum or maximum voltage during the anomaly.
- The previous 64 rms values, calculated on half input cycles (half periods), before the anomaly occurred.

Voltage Anomaly recording is enabled on selected voltage inputs and can be calculated based either on a fixed tolerance window or on a variable tolerance window.

In **Fixed Tolerance Mode**, the nominal voltage is set by user and the high and low limits are set as a percentage of nominal voltage.

In **Variable Tolerance Mode**, the nominal voltage is calculated and is the average voltage during the previous anomaly integration period (settable between 1 and 900 seconds). The new nominal reference voltage can be up to $\pm 30\%$ of programmed nominal voltage. High and low limits are set as a percentage of the nominal voltage and can be between $\pm 1\%$ and $\pm 30\%$ of the nominal voltage.




fig 43




fig 44

5. POWER BREAKS RECORDING

If data logging is in progress, the start of every OFF state of the instrument is treated as a Power Break. This OFF state occurs either if the instrument is switched OFF (using the rotary switch) or if it lose its power supply.

For each Power Break, the instrument logs the date & time of both the beginning and end of the power break, and the cause of the power break (manual or loss of supply).

Note: The battery must be in the instrument otherwise its power supply drops to fast and it can not records Power Break.

6. MEMORY USAGE

The non-volatile memory in the Instrument can be used in one of two ways:

- **Linear mode**

In **linear mode** recording, the Instrument stores data in memory until full and then stops recording. Thus the oldest data is always preserved irrespective of the amount of recordable data.

- **Roll-over mode**

When recording in **roll-over mode**, the Instrument will over-write old data when memory is filled. Thus, the latest data is always preserved irrespective of the amount of data recorded, with the older data being possibly lost.

Data logging capacity in **linear mode** depends on the number of channels selected for recording, the type of data recorded, the IP and the number of voltages anomalies detected. It is automatically calculated by the PC software when selecting channels for logging and is given by the following equation:

Maximum number of records in Periodic Analysis (Rn_{max}) is given by:

$$Rn_{max} = \frac{(2032 - N_{Stat}) * 1024 - N_{ano} * 164}{R_{len}}$$

Where:

R_{len} Record length $R_{len} = 12 + X * 6 + Y * 12$

N_{Stat} N° of channels selected for Statistical Analysis
(All being selected for Periodic Analysis, but excluding harmonics).

N_{ano} N° of voltage anomalies which occurred while recording.

X N° of channels selected excluding power channels ($\pm P_x$, $\pm Q_x$, $\pm P_{tot}$, $\pm Q_{tot}$, $\pm S_{tot}$).

Y Power channels

Note: Estimating Voltage Anomalies:

N_{ano} can be estimated with experience. It depends on the quality of voltage supply and on the user defined limits for detection of anomalies. Selection of excessively narrow limits, or a wrong nominal voltage reference, can produce large numbers of recorded events and reducing memory capacity.

Example 1:

The Instrument will be set to log for 7 days.

The requirement is to monitor both voltage and current changes, and harmonic distortion, with as much detail as possible.

For optimum memory usage, just 12 channels should be set for periodic analysis.

$U_1, U_2, U_3, I_1, I_2, I_3, thd_{U1}, thd_{U2}, thd_{U3}, thd_{I1}, thd_{I2}, thd_{I3}$.

With this setting, the Instrument can save 24,771 records (values for 24,771 IPs).

Increasing number of channels and/or enabling Statistical Analysis would decrease number of saved IPs.

$$Rn_{max} = (2032) * 1024 / (12 + 12 * 6) = > 24,771$$

(Record Length = $12 + 12 * 6 = 84$ bytes)

Thus, over a week (604,800 seconds) instrument can save a record every 30 seconds (an IP interval of 30 seconds).

$$604,800 \text{ seconds} / 24771 = 24.4 \text{ seconds} \quad \text{Set IP} = 30 \text{ seconds}$$

Thus, monitoring the above 12 parameters with an IP of 30 seconds will produce 20,160 records per week in memory. This will leave the following memory free:

$$\begin{aligned} \text{FREE Memory} &= \text{Memory Capacity} - \text{Memory Used} \\ &= 2032 * 1024 - 20,160 * 84 \text{ bytes} \\ &= 387,328 \text{ bytes.} \end{aligned}$$

This 'FREE Memory' is enough for recording 2361 Voltage Anomalies. Adding a further channel to the recording (e.g. frequency) would leave the following memory free:

$$\begin{aligned} \text{FREE Memory} &= \text{Memory Capacity} - \text{Memory Used} \\ &= 2032 * 1024 - 20,160 * (84 + 12) \\ &= 145,408 \text{ bytes. (Sufficient for 886 Voltage Anomalies)} \end{aligned}$$

Example 2:

The same set-up as above but:

Statistical Analysis is enabled

Phase 1 voltage harmonics (as many as possible) are to be logged.

The Instrument can calculate a Statistical Analysis for all recorded parameters except current and voltage harmonics; thus 12 channels are required for recording statistics. A maximum of 64 channels can be selected for data logging. The settings for Example 1 above require 12 channels, leaving 48 channels free. The Instrument can record harmonics up to 41st, requiring 40 channels (all possible harmonics from the 2nd to the 41st will be recorded). Thus a total 52 channels need to be set for Periodic Analysis.

The number of records that the Instrument can store with this setting is given by:

$$\begin{aligned} Rn_{max} &= (2032-12) * 1024 / (12 + 52 * 6) = > 6384 \\ &(\text{Record Length} = 12 + 52 * 6 = 324 \text{ bytes}) \end{aligned}$$

Thus, if recording is required over one week (604,800 seconds), the shortest recording interval is given by:

$$\begin{aligned} \text{Interval} &= 604,800 \text{ seconds} / 6384 \\ &= 94.7 \text{ seconds} \end{aligned}$$

Thus setting an IP of 2 minutes will produce 5040 record per week in memory. This will leave the following memory free:

$$\begin{aligned} \text{FREE Memory} &= \text{Memory Capacity} - \text{Memory Used} \\ &= (2032 - 12) * 1024 - 5040 * 324 \\ &= 435,520 \text{ bytes.} \end{aligned}$$

This would allow recording over a further 44 hours (with no Voltage Anomalies), or for recording 2655 Voltage Anomalies.

SECTION VII

MODEM DATA TRANSFER

1. INTRODUCTION

Modem data transfer enables remote handling of the instrument and its data. When the instrument has to be located on distant or hardly accessible place, the modem is the only practical solution for fast access to the instrument. It is only necessary to connect modem to the instrument at the location where measurements are performed and activate modem control. The instrument and modem are connected via RS232 interface.

Minimum requirements for the instrument and modem interface:

Equipment	PC Software ver.	Firmware ver.
Power Harmonics Analyzer MI 2092	Power Link 4.0	Ver 5.00 + modem option
Power Quality Analyzer MI 2192	Power Link 4.0	Ver 5.00 + modem option
Power Quality Analyzer Plus MI 2292	Power Link 4.0	Ver 5.00

Minimum requirements for PC:

- PC Pentium, Windows 98 or higher

2. MODEMS

It is possible to use a range of standard (analog) and GSM modems with a PC and the instrument. The following table shows possible combinations for remote measuring system:

On PC side	On measuring place
Standard (analog) internal modem	GSM terminal modem or Standard (analog) external modem
Standard (analog) external modem	
GSM terminal modem	

All PC external modems and modems for the instrument must have RS232 interface. GSM modem connected to the instrument needs a PIN card with included DATA number (VOICE number is included by default but it is not needed). Please contact your GSM provider for the DATA number.

Application described in this manual is based on 'Siemens TC35 GSM terminal' modem and 'US Robotics – Faxmodem' standard (analog) modem. For a third party modem device, apply appropriate settings as required by modem vendor.

We recommend preparing a test system for verification and training before performing actual measurements at the remote place.

Required accessories

Standard (analog) modem (external): <ul style="list-style-type: none"> - Modem - RS232 interface cable - Modem power supply - Active standard phone line 	GSM modem: <ul style="list-style-type: none"> - Modem - RS232 interface cable - Modem power supply - Antenna - PIN card with active data (mandatory) and voice (optional) phone numbers
--	--

Notes:


- For GSM system, pay attention to install its antenna at the appropriate place with good signal condition.
- If modem communication is enabled, it is not possible to transfer data from the instrument to the PC using RS232 connection. To enable direct RS 232 connection between the instrument and PC, you should disable modem communication in Power Link and on the instrument.

3. MODEM, INSTRUMENT AND POWER LINK CONFIGURATION

3.1. Power Link configuration

Power Link software should be configured before establishing modem communication. The following procedure is required:

- Run Power Link application.
- Select **Communication Settings** menu and enable modem communication (see the following figure).



- Select **GSM** or **Standard modem** for local and standard modem.
- Enter PIN codes for local modem (connected to PC) and target modem (connected to the instrument) if required.
- Enter the phone number of the target modem (connected to the instrument) the program will communicate with.
- Set suitable baud rate.
- Save the settings.

Note:

- Serial port baud rate is automatically set to 9600 Bauds (for GSM modem) and cannot be set to any other rate.
- Take care that all devices (PC, both modems and instrument) are set to the same baud rate.

3.2. Modem configuration at the PC side


The modem connected to the PC should be configured before use. The PC with internal modem does not need any external extension. For external modem do the following:

- Connect the modem to the unused COM port of the PC using RS232 interface cable. The modem and PC should be switched off when connecting them together.
- Switch them on and wait until the PC finishes its initialization sequence.
- Insert PIN card in the case of using GSM modem.
- Connect telephone line to the modem in the case of using standard modem.

3.3. Modem configuration at the instrument side

The modem connected to the instrument should be configured before use. Use the Power Link and do the following configuration procedure:

- Insert PIN card into modem (for GSM modem).
- Connect modem to the PC, run Power Link and click "**Modem / Configure target modem**" (see the following figure).



- Disconnect the modem from the PC and connect it to the instrument with special RS232 cable (see chapter 4 for connection diagram) , both must be in the power off state (switched off).

When the modem is being configured with Power Link the following settings are executed:

- disable PIN for GSM modem (AT+CPIN=XXXX and AT+CLCK="SC",1,XXXX,
- enable automatic answering (AT&D0),
- set automatic answering after 2 RINGS (ATS0=2),
- set ECHO answering to OFF (ATE0),
- disable "Wait for dial tone" option (ATX0),
- set PORT baud rate for standard (analog) modem,
- save parameters (AT&W),
- activate saved parameters (ATZ).

When the third party modem requires different settings we recommend using the Hyper Terminal program for modem configuration. It is part of standard Windows setup. You can find it on your PC: Programs / Accessories / Communications / Hyper Terminal.

3.4. Instrument configuration for modem communication

Instrument should be configured before communicating with the PC via modem communication. The following procedure is required:

- Modem should be connected to the instrument.
- Switch the instrument on.
- Switch the modem on.
- In **SYSTEM** menu select **SER.PORT RATE / GSM/SMS PARAM.** / DISABLED for Standard (analog) modem.
- In **SYSTEM** menu select **SER.PORT RATE / GSM/SMS PARAM.** / ENABLED for GSM modem (it enables sending of SMS messages).



ENABLE PASSW.	=>	ENABLED >> DISABLE
GSM/SMS PARAM.		CPIN : XXXX
DATE/TIME		DEST:
LANGUAGE		USERID:
SYSTEM REINIT.		SEND TEST MESSAGE
CLR.REC.MEM.		

- Enter PIN code using cursor keys: UP/DOWN to increment/decrement selected number and LEFT/RIGHT to select previous or next number (for GSM modem).
- Press ENTER to confirm entry or ESC to discard it.

If you want to disable sending of SMS messages (when using GSM modem) you should set GSM/SMS PARAM. to DISABLED and set SERIAL PORT RATE to 9600.

If a GSM modem is used on the PC side and Standard modem is used on the instrument side, baud rate of 9600 bps must be used for the standard modem.

4. MODEM CONNECT. WITH PC AND INSTRUMENT



MODEM, INSTRUMENT and PC connection

5. CONNECTING AND DISCONNECTING MODEMS

When the modems are connected and suitably set at the instrument and the PC, just click the **“Make modem connection”** button in Power Link toolbar or select **“Make modem connection”** in **Modem** menu. It takes a few seconds (up to 30 s) to establish communication link. The instrument operates as it is connected directly to the PC via RS232 interface. It means that all interface functions are active, e.g.: receive / transmit instrument settings, data download, manipulating of the recording function, clear memory.

To disconnect just click on **“Hang-up modem connection”** button on Power Link toolbar or select **“Hang-up modem connection”** in **Modem** menu.

6. SMS MESSAGES

The instrument has possibility to send an SMS message to the mobile phone when GSM modem communication is enabled. Messages are intended to inform the operator about some events regarding the instrument.

The following events can be sent as SMS messages:

- Less than 50% of recording memory is free.
- Less than 20% of recording memory is free.
- Recording memory is full.
- WAVEFORM, FAST LOGGING, TRANSIENT, EN50160 or PERIODICS recording is finished.

For SMS messaging prepare the following configuration:

ENABLE PASSW.	=>	ENABLED >> DISABLE
GSM/SMS PARAM.		CPIN :
DATE/TIME		DEST: XXXXXXXXXXXXX
LANGUAGE		USERID: XXXXXXXXXXXX
SYSTEM REINIT.		SEND TEST MESSAGE
CLR.REC.MEM.		

- Enter Destination phone number **“DEST:”** (phone number of the mobile phone that will receive SMS messages from the instrument) using cursor keys.
- Enter user ID **“USER ID”**: (optional instrument identification string) using cursor keys as described in chapter 3.4.
- Provide PIN card of modem terminal with the number of your local.
- It can be done with **“SEND TEST MESSAGE”** command in GSM/SMS PARAMETERS menu of the instrument.

Press Enter to confirm settings or ESC to discard them.

Note:

- SMS message cannot be sent if modem communication is established.
- If you do not want the instrument to send SMS, disable GSM/SMS PARAM. and set baud rate to 9600.